

# Cordless Angle Grinder

## DGA506

### REPAIR MANUAL



## 1 INDEX

1	INDEX.....	2
2	CAUTION.....	2
3	NECESSARY REPAIRING TOOLS.....	2
4	LUBRICANT AND ADHESIVE APPLICATION.....	3
5	Rotor, Ball bearing 629LLB/ 607LLB, Spiral bevel gear 10.....	4
5-1	Disassembling.....	4
5-2	Assembling.....	6
6	Spiral bevel gear 37, Ball bearing 696ZZ, Ball bearing 6201DDW.....	8
6-1	Disassembling.....	8
6-2	Assembling.....	10
7	Shaft lock.....	12
7-1	Disassembling.....	12
7-2	Assembling.....	12
8	Stator complete.....	13
8-1	Assembling.....	13
9	Switch.....	14
9-1	Assembling of Slide switch.....	14
9-2	Assembling of Paddle switch.....	15
10	Circuit diagram.....	16
10-1	Slide switch models.....	16
10-2	Paddle switch models.....	16
11	Wiring diagram.....	17
11-1	Slide switch models.....	17
11-2	Paddle switch models.....	18

## 2 CAUTION

Repair the machine in accordance with “Instruction manual” or “Safety instructions”.

## 3 NECESSARY REPAIRING TOOLS

Code No.	Description	Use for
1R003	Retaining pliers ST-2N	removing/ assembling Ring spring 11
1R026	Bearing setting pipe 16-8.2	removing Ball bearing 6201DDW
1R028	Bearing setting pipe 20-12.2	press-fitting Spindle/ Spindle A
1R029	Bearing setting pipe 16-8.2	press-fitting Spiral bevel gear 37
1R032	Bearing setting plate 8.2	press-fitting Ball bearing 607LLB
1R036	Bearing setting plate 17.2	press-fitting Spiral bevel gear 37 Ball bearing 6201DDW/ 696ZZ
1R038	Armature holder 32 set for use with vise	clamping Rotor with a vise to remove M6 Hex nut
1R164	Ring spring setting tool A	press-fitting Ball bearing 6201DDW
1R212-A	Tip for Retaining ring pliers	use with 1R003
1R212-B	Plate set (with Screws)	use with 1R003
1R220	Ratchet head 9.5 (for 1R219)	assembling M6 Hex nut
1R222	Socket adapter	assembling M6 Hex nut
1R248	Round bar for Arbor 22-100	removing Felt ring 16
1R252	Round bar for Arbor 30-100	press-fitting Felt ring 16
1R254	Torque wrench shaft FT 2-6 N·m	assembling M6 Hex nut
1R258	V block	removing Spiral bevel gear 37
1R268	Spring pin extractor M3	removing Shoulder pin 4
1R269	Bearing extractor	removing Ball bearing 607LLB/ 696ZZ
1R284	Round bar for Arbor 10-50	removing Spiral bevel gear 37
1R291	Retaining ring S and R pliers	removing/ assembling Retaining ring R-32/ R-26
1R401	Bearing extractor	removing Rotor

#### 4 LUBRICANT AND ADHESIVE APPLICATION


Apply lubricant and adhesive to the designated portions.

	Lubricant
	Makita grease R No.00

Fig. 4-1



Fig. 4-2




## 5 Rotor, Ball bearing 629LLB/ 607LLB, Spiral bevel gear 10

### 5-1 Disassembling


5-1-1

Remove four 4x30 Tapping screw, then remove Gear housing together with Bearing box.




5-1-2

Insert a slotted screwdriver to the slit of Gear housing cover, then pry the gear housing cover open. Remove Gear housing cover together with Rotor ass'y.





5-1-3

Hold Rotor ass'y in between 1R038 with a vise, then turn M6 Hex nut counterclockwise with an offset wrench 10. Spiral bevel gear 10 is removed.



5-1-4

Remove Rotor ass'y from Gear housing cover with 1R401.



5-1-5

Push out Ball bearing 629LLB from Gear housing cover.




Rotor side



5-1-6

Remove 607LLB from Rotor ass'y.



5-1-7





**Note:** When handling or storing multiple Rotors, be sure to keep a proper distance between Rotors as shown below left.. Because Rotor is a strong magnet, failure to follow this instruction could result in:

- Finger injury from being pinched between Rotors
- Magnetic loss of Rotors or damage to Rotors. (See below right.)




## 5-2 Assembling

Assemble by reversing the disassembly procedure.  
Also, refer to the following points.




5-2-5



**Note:** As for **Slide switch models**, the notch of Gear housing cover and Spindle must be faced toward the opposite of Switch knob.

Spindle / Spindle A\*  
\*Spindle A is used for Canada,,Colombia, Panama, USA.

**Note:** As for **Paddle switch models**, the notch of Gear housing cover and Spindle must be faced toward Switch lever complete.







Spindle/ Spindle A\*  
\*Spindle A is used for Canada, Colombia, Panama, USA.





## 6 Spiral bevel gear 37, Ball bearing 696ZZ, Ball bearing 6201DDW


### 6-1 Disassembling

**Note:** The above parts can be removed without disassembling Motor section.














## 6-2 Assembling

Assemble by reversing the disassembly procedure.  
Also, refer to the following points.




6-2-6

Receive Lead flange/ Lead flange A/Lead flange B on 1R036, then press-fit Spindle into Spiral bevel gear 37.

Press the boss portion around the hole of Spiral bevel gear 37 with 1R029.




Spiral bevel gear 37




6-2-7

Fit Ring spring 11 into the groove of Spindle/ Spindle A using 1R003 with 1R212-A and 1R212-B.





6-2-8

Receive Lead flange/ Lead flange A/ Lead flange B on 1R036, then press-fit Spindle/ Spindle A into Ball bearing 696ZZ.



## 7 Shaft lock

### 7-1 Disassembling





### 7-2 Assembling

Assemble by reversing the disassembly procedure.  
Be careful about **Note in Fig. 7-1-2**

## 8 Stator complete


### 8-1 Assembling



## 9 Switch


### 9-1 Assembling of Slide switch

As for Slide switch version, hook Switch knob to Switch lever.  
Put Torsion spring 2 into Lever, then pass Pin 2 through the holes of Lever and Torsion spring 2.




9-1-2

Protrude the bars of Lever from the triangle hole of Switch lever.




9-1-3

Turn the bars counterclockwise to place the long bar and the short bar onto the depressions on the triangle corners of Switch bar.



9-1-4


Insert one end of Pin 2 into the hole of Housing L. and put the one end of Torsion spring 2 on the rib of Housing L.  
The other end of Pin 2 should be inserted into the hole of Housing R.



## 9-2 Assembling of Paddle switch


9-2-1

Refer to the following Parts breakdown and 10-2-1 in page 16 and 11-2-1/ 11-2-2 in page 18.




## 10 Circuit diagram

### 10-1 Slide switch models




### 10-2 Paddle switch models





# 11 Wiring diagram



## 11-1 Slide switch models



## 11-2 Paddle switch models

11-2-1

Assemble the plate portion of Non-insulated terminal to No. 3 terminal of Switch as drawn left. (The right drawing is wrong. Be careful.) Also, refer to the paddle switch model circuit diagram of section No. 10-2 in page 16.



Lead wires (covered with Tube) of Stator complete must be routed between Rib A and Boss A, Rib B and Rib C, Rib B and Rib D, Boss B and Pin A.

11-2-2

