

MOTORE MONOFASE
(SINGLE PHASE MOTOR)
230Vac 50/60Hz

LISTA COMPONENTI / СЪСТАВНИ ЧАСТИ


- SW1: SELETORE ON - OFF
ON - OFF превключвател
- F1: INTERRUTTORE TERMICO
Термо превключвател
- LP1: LUCE SPA VERDE "MOTORE IN MARCIA"
зелена лампа "работещ мотор"
- C1: CONDENSATORE
кондензатор

ВНИМАНИЕ:
Контролният панел трябва да бъде свързан от квалифициран персонал - електро - специалист.
Ел. помпа и панелът трябва да бъдат включени към ефективна заземляваща система, в съответствие с ел.реглации.
Действащи в конкретната страна.
Линията на напрежението трябва да бъде защитена с диференциален магнитно - термичен ключ, настроен в съответствие с ел.реглации, действащи на местно ниво.

CAUTION:

The control panel must be connected by a qualified electrician.
The electric pump and the panel must be connected to an efficient grounding system in compliance with the electrical regulations locally in force.
The line of supply current must be protected with a differential magnetic switch measured in accordance with the regulations locally in force.

SCHEMA COLLEGAMENTI
Диаграма на свързване



Model / Type
OEM

Date / Date
18/02/2005

Page / Page
1 of 1