

Assembly

 Disconnect the power before installation.


One Way Switch




- ① Touch to the button with screwdriver



- ② Push the mechanism and remove the cover as shown in the picture



- ③ Place the connections and tighten the screws



- ④ Mount to the wall with fixation screws




Backside appearance of the product


Schuko Socket Outlet



- ① Remove the cover with screwdriver



- ② Place the connections and tighten the screws



- ③ Mount to the wall with fixation screws



Backside appearance of the product