

1

## **Bosch Motor Housing**

Product Reference: F016L74178

## 3/3

Bosch Switch Product Reference: 2607202375

5

Bosch Connecting Terminal Product Reference: F016L72733

## 9

Bosch Manufacturer'S Nameplate Product Reference: F016L74296

## 11

Bosch Handle Product Reference: F016L74181

18

Bosch Air-Deflector Ring Product Reference: F016L74179 23

Bosch Protective Shield Product Reference: F016L74182

30

Bosch Cap Product Reference: F016F05161

31



Bosch Tank Product Reference: F016F05162

38

Bosch Sealing Rubber Product Reference: F016L74457

42



0

Bosch Tensioner Parts Set Product Reference: F016F05168

43

Bosch Sealing Washer Product Reference: F016L74462

48

Bumper Product Reference: F016F05785

53

Bosch Screw Product Reference: F016L74468

54

Bosch Screw Product Reference: F016L74469

57

Bosch Screw Product Reference: F016L74467

651



BOSCH 2607337199 BATTERY PACK

Product Reference: 2607337199

653

Bosch Fast Charger Product Reference: 2607225965 653



BOSCH 2607225967 CHARGER Product Reference: 2607225967

653

Bosch Charger Product Reference: 2607225969

687



Bosch Guide Cover Product Reference: F016L74192

689



Bosch Bosch Chain Product Reference: F016F05190

690

<u>Guide Rail</u> Product Reference: F016F05787 802

Bosch Dc Motor Product Reference: F016F05154



803

Bosch Electronic Module Product Reference: F016F05155

807

Bosch Plastic Covering Product Reference: F016F05158

808

<u>Nameplate</u> Product Reference: F016F05782

812



Bosch Output Shaft Product Reference: F016F05167

820

Bosch Set Of Handles Product Reference: F016F05159

822

Bosch Protective Cover Product Reference: F016F05166

824

<u>Trigger</u> Product Reference: F016F05786

832

Bosch Pump Product Reference: F016F05163

836

Bosch Feeding Device Product Reference: F016F05164

850



**Bosch Sprocket Wheel** Product Reference: F016F05165