

Illustration - Type - E





Illustration - Type - E

3 600 HD2 200
Issue | 25-01-13
Stand | **Fig./Abb. 2**



Modifications reserved
Änderungen vorbehalten
Modifications réservées
Salvo modificaciones

Spare parts list

Item	Part Number	Description	Illustration	Price	Quantity
1	F 016 F06 408	Housing Section	1	-	1
4	F 016 L79 073	Compression Spring	1		3
7	F 016 F06 084	Nameplate	1	-	1
8	F 016 F06 072	Trigger	1		1
9	F 016 L78 284	Compression Spring	1		1
11	F 016 F06 139	Motor Housing	1		1
12	F 016 F06 140	Electronics Module	1		1
13	F 016 F06 632	Label	1	-	1
14	F 016 L78 266	Blower tube	1		1
15	F 016 F04 198	Screw	1		19
16	F 016 F06 068	Protective Grille	1		1
17	F 016 F06 069	button	1		1
18	F 016 F06 070	Compression Spring	1		1
19	F 016 F06 124	Seat	1		1
20	F 016 F06 125	Screw	1		1
21	F 016 F06 631	Warning Label	1	-	1
22	F 016 F06 065	Decorative Cover	1		1
23	F 016 F06 066	Decorative Cover	1		1
25	F 016 L78 267	Safety Guard	1		1
26	F 016 L78 285	Spindle	1		1
27	F 016 L78 279	Roller	1		1
31	F 016 L78 787	Screw	1		1
656	F 016 F06 353	Nozzle	2	-	1
657	F 016 F06 354	Nozzle	2	-	1
658	F 016 F06 355	Nozzle	2	-	1