

SPARE PARTS LIST

MODEL NO. BGD800

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	424380-4	INSULATION COVER	1	
002	763668-0	COLLET NUT	1	
003	763670-3	COLLET CONE 6	1	
004	317999-5	BEARING RETAINER	1	
005	443124-3	FELT RING 17	1	
006	267329-9	FLAT WASHER 18	1	
007	326010-2	SPINDLE	1	
008	210106-8	BALL BEARING 6001LLB	1	
009	961052-5	RETAINING RING S-12	1	
010	318000-9	BARREL	1	
011	266361-0	TAPPING SCREW 4X30	4	
012	210042-8	BALL BEARING 629LLB	1	
013	324639-8	COUPLING	1	
014	421942-9	SPACER	1	
015	267126-3	FLAT WASHER 22	1	
016	619284-5	ARMATURE INC. 17	1	
017	421977-0	RUBBER RING 13	1	
018	631714-6	LED CIRCUIT	1	
019	638627-2	YOKE UNIT	1	
020	*****	*****	***	*****
021	868960-0	BGD800 NAME PLATE	1	
022	265995-6	TAPPING SCREW 4X18	5	
023	419566-3	SWITCH KNOB	1	
024	188761-3	HOUSING SET INC. 29	1	
025	419519-2	SWITCH LEVER	1	
026	650579-7	SWITCH 1246.3223	1	
027	*****	*****	***	*****
028	643838-6	TERMINAL	1	
029	188761-3	HOUSING SET INC. 24	1	
030	191971-3	CARBON BRUSH CB-430	1	
031	643929-3	BRUSH HOLDER CAP	2	
032	419518-4	HOLDER CAP COVER	2	
033	326009-7	COUPLING	1	
034	210042-8	BALL BEARING 629LLB	1	
035	213445-5	O-RING 26	1	
036	961005-4	RETAINING RING S-9	1	
037	317821-6	GEAR HOUSING COVER	1	
A01	781039-9	WRENCH 13	2	
A02	*****	*****	***	*****
A03	*****	*****	***	*****
A04	194204-5	BATTERY BL1830 SET	2	
A05	*****	*****	***	*****
A06	*****	*****	***	*****
A07	*****	*****	***	*****
A08	*****	*****	***	*****

SERVICE DRAWING

MODEL NO. BGD800

