


Model No.DF333D CORDLESS DRIVER DRILL




Model No.DF333D CORDLESS DRIVER DRILL

Item No.	Parts No.	Description
001	183K90-5	HOUSING SET
C10	252126-6	HEX. LOCK NUT M4-7
001		INC. 21
001	183L84-6	HOUSING SET
002	855E35-4	DF333D NAME PLATE
003	266429-2	TAPPING SCREW 3X16
004	459026-3	SPEED CHANGE LEVER
004-1	413F37-8	SPEED CHANGE LEVER
005	232493-5	LEAF SPRING
006	127127-2	CHANGE LEVER ASSEMBLY
006		INC. 7
006-1	122B84-1	CHANGE LEVER ASSEMBLY
006-1		INC. 7
007	233025-1	COMPRESSION SPRING 2
008	456039-5	F/R CHANGE LEVER
009	632J76-5	SWITCH UNIT
C10	620625-0	LED CIRCUIT
C20	688161-2	LINE FILTER
012	127125-6	GEAR ASSEMBLY
013	763238-5	KEYLESS DRILL CHUCK 10
014	251468-5	- FLAT HEAD SCREW M6X22
018	629395-8	DC MOTOR
019	644813-5	TERMINAL
020	855E42-7	DF333D SERIAL NO. LABEL
021	183K90-5	HOUSING SET
C10	252126-6	HEX. LOCK NUT M4-7
021		INC. 1
021	183L84-6	HOUSING SET
A01	251314-2	+ TRUSS HEAD SCREW M4X12
A02	346909-5	HOOK
A03	784244-7	+ BIT 2-50
A04	821661-1	PLASTIC CARRYING CASE
C10	417724-5	LATCH
A04	456128-6	BATTERY COVER
A04	821762-5	PLASTIC CASE
C10	162315-4	LATCH
A04	831497-0	TOOL BAG
A05	818P79-1	DF333DWYE MODEL NO. LABEL
A05	818P85-6	DF333DSAE MODEL NO. LABEL
A05	818P87-2	DF333DWAE MODEL NO. LABEL
A05	818P89-8	DF333DSME MODEL NO. LABEL
A05	818P91-1	DF333DWME MODEL NO. LABEL
A05	***DC10WD	DC10WD BATTERY CHARGER
A05		COMPO-PARTS
A05	819F36-2	DF333DWYL1 MODEL NO. LABEL
A06	197396-9	BATTERY BL1021B SET
A06-1	197396-9	BATTERY BL1021B SET

A07	D-63921	17PCS. DRILL & SCREW BIT SET
A08	456128-6	BATTERY COVER
A08	198254-2	COOLER BOX TYPE 3 SET
C10	457247-1	LATCH
C20	424934-7	SEAL BOTTOM
C30	424935-5	SEAL TOP
C40	457237-4	INNER CASE(BOTTOM) TYPE 4
C50	161576-3	SHOULDER BELT
A09	***DC10WD	DC10WD BATTERY CHARGER
A09		COMPO-PARTS
A09	***DC10SB	DC10SB BATTERY CHARGER
A09	ATAADP08	USB ADAPTER
A10	197393-5	BATTERY BL1016 SET
A10	197396-9	BATTERY BL1021B SET
A10	197406-2	BATTERY BL1041B SET
A10	819F61-3	DF333DWAX6 PLASTIC CASE LABEL
A10-1	197396-9	BATTERY BL1021B SET
A10-1	197406-2	BATTERY BL1041B SET
A11	819F62-1	DF333DWAX6 INDICATION LABEL
A11	DEZML106	CORDLESS LED FLASHLIGHT BULKEU
A11-1	DEBML106	CORDLESS LED FLASH LIGHT
A12	832035-1	TOOL BAG
E01	632N11-7	LINE FILTER UNIT
F40	347C56-3	HOOK

Model No.TD110D CORDLESS IMPACT DRIVER



TD110D CORDLESS IMPACT DRIVER

Item No.	Parts No.	Description
001	183B49-8	HOUSING SET
C10	252126-6	HEX. LOCK NUT M4-7
001		INC. 31
002	851G86-7	TD110D NAME PLATE
002-1	851G85-9	TD110D NAME PLATE
003	266429-2	TAPPING SCREW 3X16
005	456039-5	F/R CHANGE LEVER
006	632F42-8	SWITCH UNIT
C10	620463-0	LED CIRCUIT
C20	632F64-8	LINE FILTER UNIT
006-1	632J76-5	SWITCH UNIT
C10	620625-0	LED CIRCUIT
C20	632F64-8	LINE FILTER UNIT
C21	688161-2	LINE FILTER
008	644813-5	TERMINAL
009	231965-7	RING SPRING 10
010	267143-3	FLAT WASHER 11
011	233005-7	COMPRESSION SPRING 13
012	324711-6	BIT SLEEVE
013	424737-9	BUMPER
014	143277-5	HAMMER CASE COMPLETE
015	261140-1	NYLON WASHER 20
016	216019-1	STEEL BALL 3
017	324895-0	ANVIL M
018	324894-2	HAMMER
019	216019-1	STEEL BALL 3
020	267380-9	FLAT WASHER 20
021	234064-4	COMPRESSION SPRING 21
022	267813-4	WASHER 21
023	216002-8	STEEL BALL 4.8
024	227213-0	SPUR GEAR 17
025	324897-6	SPINDLE
026	268217-3	PIN 3.5
027	253052-2	FLAT WASHER 12
028	227215-6	INTERNAL GEAR 43
029	158671-8	BEARING BOX COMPLETE
030	629163-9	DC MOTOR
031	183B49-8	HOUSING SET
C10	252126-6	HEX. LOCK NUT M4-7
031		INC. 1
033	688164-6	LINE FILTER
033-1	632F64-8	LINE FILTER UNIT
C10	688164-6	LINE FILTER
A01	266622-8	+ TRUSS HEAD SCREW M4X12
A02	346909-5	HOOK
A03	784244-7	+ BIT 2-50
A04	456128-6	BATTERY COVER

A05	***DC10SA	DC10SA BATTERY CHARGER
A05		COMPO-PARTS
A05-1	***DC10SB	DC10SB BATTERY CHARGER
A05-1		COMPO-PARTS
A05-1	***DC10WD	DC10WD BATTERY CHARGER
A06	197394-3	BATTERY BL1020B SET
A06	197402-0	BATTERY BL1040B SET
A06-1	197396-9	BATTERY BL1021B SET
A06-1	197406-2	BATTERY BL1041B SET
A06-2	197396-9	BATTERY BL1021B SET
A06-2	197406-2	BATTERY BL1041B SET
A07	821661-1	PLASTIC CARRYING CASE
C10	417724-5	LATCH
F03	197390-1	BATTERY BL1015 SET
F04	197391-9	BATTERY BL1015 SET
F05	197393-5	BATTERY BL1016 SET
F06	197394-3	BATTERY BL1020B SET
F07	197395-1	BATTERY BL1020B SET
F08-1	197396-9	BATTERY BL1021B SET
F09-1	197397-7	BATTERY BL1021B SET
F12	197402-0	BATTERY BL1040B SET
F13	197403-8	BATTERY BL1040B SET
F14	197404-6	BATTERY BL1040B SET
F15-1	197406-2	BATTERY BL1041B SET
F16-1	197407-0	BATTERY BL1041B SET
F33	198968-3	BATTERY BL1016 SET
F34	198969-1	BATTERY BL1016 SET (2PIECES)
F35-1	198970-6	BATTERY BL1021B SET (2PIECES)
F36-1	199002-2	BATTERY BL1041B SET (2PIECES)
F40	347C56-3	HOOK