



BS 18 Quick / 02217000 / TV 05 / -

| Pos. | Part No. | Description | Quant. |
|-------------|-----------------|--------------------------------|---------------|
| 2 | 315418320 | Gear housing compl 10.8V Quick | 1 |
| 4 | 317004720 | Motor compl.,18V | 1 |
| 5 | 341704710 | Screw,ST2,9x13 | 8 |
| 6 | 315014980 | Motor housing | 1 |
| 7 | 343410580 | Switch,R+L | 1 |
| 8 | 343083380 | LED lense | 1 |
| 9 | 343410610 | Switch | 1 |
| 10 | 342021670 | Spring clip | 1 |
| 11 | 343397990 | Pressure plate | 1 |
| 12 | 343394790 | Switch slide | 1 |
| 13 | 338064020 | Rating plate BS 18 Quick | 1 |
| 14 | 343434940 | Switch slide | 1 |
| 15 | 339136400 | hook | 1 |
| 20 | 301003330 | quick chuck | 1 |
| 95 | 343439680 | Cover cap | 1 |
| 850 | 627259000 | Quick Chuck Futuro Plus H1 | 1 |
| 1001 | 338504870 | Wiring diagram | 1 |