



WB 18 LTX BL 125 Quick / 13077000 / TV 05 / -

Pos.	Part No.	Description	Quant.
1	339151230	Baffle	2
3	338129940	Indication label	1
4	341100940	Hexagon nut w.recess	1
5	316057770	Bevel gear and pinion	1
6	141110460	Fillister head screw	2
7	316068460	Housing with motor compl.	1
9	344101750	Rubber buffer	4
10	343084550	Electronic unit,WE 18 BL	1
11	316065550	Battery housing compl.	1
12	338065050	Rating plate 13077000 WB 18 LTX	1
14	342003030	Pressure spring	1
15	343430520	Locking piece	1
16	343430530	Switch slide	1
17	141120070	Fill. head screw	3
18	141123920	Fillister head screw Duo-Taptite	1
19	344097550	O-ring 48 x 1	1
20	339060160	Compensating Washer	2
21	343438510	Switch rod	1
22	143192540	O-ring	1
23	141113180	Self-tap. fill. h. screw	7
25	342004000	Tension spring	1
26	339203490	Wheel guard,D 125	1
28	341031160	Clamping flange	1
29	316064680	Quicknut,M14	1
30	343412110	Switch slide, red	1
31	141116020	Self-tap fill h screw	4
32	316040610	Spindle stop compl.	1
33	316046070	Gear housing compl.	1

WB 18 LTX BL 125 Quick / 13077000 / TV 05 / -

Pos.	Part No.	Description	Quant.
34	316047590	Clamping lever compl.	1
35	316092970	Spindle compl.	1
36	316092980	Flange compl.	1
37	316046590	Side support handle compl.	1
38	316062620	Filter compl.	1
39	338126780	Type label,Features13077000 WB 18 125	1
40	338127740	Indication label Fast Brake	1
75	343411790	Defond μ -switch DMU-112D-006	1
95	343439680	Cover cap	2
880	344130910	Grease 100G	1
1001	338510160	Wiring diagram	1