



NP 18 LTX BL 5 / 19002000 / TV 05 / -

Pos.	Part No.	Description	Quant.
1	339137270	Hook	1
2	341212750	tube	1
3	344113990	O-ring	1
4	339149130	Housing f. jaw	1
5	316097200	cage with jaw	1
6	341212760	PRESSURE BAR	1
7	342024320	Spring	1
8	341212770	Latch f. housing f. jaw	1
9	316097210	hook compl.	1
10	341723100	SCREW	4
11	341166820	Guide rail	1
12	343086760	Terminal	1
13	343447610	Housing	1
14	341723110	PAN HD.PLASTIC SCREW	11
15	341723120	zAN HD.PLASTIC SCREW	4
16	315107650	Gear Housing with SC	1
17	341166830	Gear f. jaw	1
18	343447620	Guide tube	1
19	341723130	PAN HD.PLASTIC SCREW	1
20	316097220	LED compl.	1
21	341166840	Gear	1
22	316097230	Motor compl.	1
23	343447630	Switch trigger	1
24	344114000	Rubber plug	1
25	343447640	Heat shrink tube f. spindle	1
26	343447650	Mandrel container	1
27	341166850	Retaining nosepiece 2,4mm	1
28	341166860	Retaining nosepiece 3,2mm	1

**NP 18 LTX BL 5 / 19002000 / TV 05 / -**

<b>Pos.</b>	<b>Part No.</b>	<b>Description</b>	<b>Quant.</b>
29	341166870	Retaining nosepiece 4,0mm	1
30	341212740	Retaining nosepiece 4,8mm	1
31	341723090	Square nut	3
32	342024280	Spring	1
33	343438580	Locking slide	1
34	338069800	Rating plate	1
35	343411860	Switch	1
37	343430520	Locking piece	1
38	341166980	standard nosepiece 2,4mm	1
39	341166990	standard nosepiece 3,2mm	1
40	341167000	standard nosepiece 4,0mm	1
41	341167010	standard nosepiece 4,8mm	1
42	339149160	Spring Bushing	1
45	338129640	Indication label	1
95	343439680	Cover cap	1
1001	338510220	Wiring diagram	1