



SE 18 LTX 6000 / 20049000 / TV 05 / -

Pos.	Part No.	Description	Quant.
1	343410220	Electronic switch, 18V	1
2	143160080	Toroidal Ferrite OD11.5*ID5*9	1
3	343433300	Locking slide	1
4	343430520	Locking piece	1
5	342003030	Pressure spring	1
6	343435420	Insert	1
7	339137270	Hook	1
8	343434390	Housing w.cover	1
9	343434440	Locking catch	1
10	342003950	Pressure spring	1
11	141113180	Self-tap. fill. h. screw	7
12	141117060	Self-tap. fill. h. screw	3
15	338063210	Rating plate	1
16	338125880	Type label,SE 18 LTX 6000, 20049XXX	2
17	338129940	Indication label	1
41	341604640	Shaft	1
75	316058130	Motor compl.	1
76	316057010	Gear housing compl.	1
77	316057040	Gear flange compl.	1
80	344099610	Seal	1
81	342003960	Pressure spring	1
82	143113820	Axial needle bearing	1
83	343434400	Adaptor	1
85	143193920	O-ring	1
87	340013050	Claw wheel	1
88	341161570	Claw disc	2
89	316054470	Tiefenanschlag vollst.	1
90	143120020	Ball	1

Pos.	Part No.	Description	Quant.
91	143114760	Thrust washer	1
92	343434410	Sleeve	1
93	141119900	Self-tapp. fill. h. screw	1
94	141113600	Cap screw	2
95	343439680	Cover cap	1
96	316055470	Bit holding sleeves	1
97	342003940	Index bolt	1
882	344130800	Grease FG 126	1
1001	338505930	Wiring diagram	1