



27	ADAPTOR		1	
26	HANDLE RIGHT	ABS+7PE	1	
25	DC JACK	PA88	1	
24	SPRING OF SPIN BUTTON	Φ8.0x1.0x0.7	1	
23	SPIN BUTTON	ABS	1	
22	BATTERY-LI		1	
21	SWITCH PCB		1	
20	CONTACT PLATE		1	
19	CONTACT PLATE		1	
18	SWITCH		1	
17	F/R LEVER	ABS	1	
16	HANDLE LEFT	ABS+7PE	1	
15	SPRING	Φ6.4x3.0x0.7	1	
14	SWITCH BUTTON	ABS	1	
13	BRAND LABEL		1	
12	SCREW	ST3x12	10	
11	RIGHT HOUSING	ABS	1	
10	BATTERY INDICATOR PCB		1	
9	LED LIGHT	Φ3	1	
8	LEFT HOUSING	ABS	1	
7	BRAND LABEL		1	
6	GEAR-BOX ASS'Y	KG33	1	
5	STAMPING SPRING PLATE	65Mn	1	
4	CLUTCH GAP	PA88+OF30	1	
3	R-RING		2	
2	SPRING OF QUICK CHANGE CHUCK		1	
1	QUICK CHANGE CHUCK		1	
Item	Part Description	Specification	Qty	