


EXPLODED VIEW



SPARE PARTS

Nº	spare part	qty
1	Lock nut	1
2	Rubber interface	1
3	o-rings	1
4	Crossover sub	1
5	O-ring (large)	1
6	Plug the spring	1
7	Rubber plug	1
18	Tapping screw	1
27	chassis	1
28	Tapping screw	10
29	The silicone Φ 4	2
30	clamp	2
31	Rubber hose Φ 7.5	1
43	Hair dryer handle	1
44	Button in the spring	1
45	Transparent lampshade	1
A	Pump gear box	1
8	Shock absorbing rubber ring	1
9	Gear box body	1
10	cup	1
11	Leaf spring	1
12	Φ 3 axis circlip (opening)	1
13	Small gasket	1
14	The piston rod	1
15	Balance weight	1
32	Φ 3.5 axis circlip (opening)	1
33	696Z high speed bearing	1
34	The output shaft	1
35	Big gear	1
36	Oil bearing collar	1
37	Cross grooved disc head screw	2
38	Gearbox cover plate	1
39	Cross round head screw	4
40	The motor gear	1
41	The motor	1
42	The blades	1
B	Pump circuit board welding	1
16	Sensing a	1
17	O-ring (small)	1
19	Control circuit board	1
20	Tapping screw	4
21	Good dragon switch	1
22	Square inductance	1
23	stents	1
24	According to the button	3
25	Display panel	1
26	The white light is on	1
46	Tapping screw	2