


## SPARE PARTS LIST OF PRUNING SHEARS RD-PSH01

1	oil needle
2	bolt
3	screw 3x8
4	screw 2.5x8
5	gear box cover
6	right housing
7	screw 2x10
8	micro switch
9	screw 3x10
10	seat
11	screw 3x6
12	blade gear
13	cylinder
14	top blade
15	down blade
16	trigger
17	trigger spring
18	bearing 688
19	axle gear
20	key
21	big gear
22	left housing
23	nut M8
24	fixing plate
25	screw 5x12
26	small gear
27	bearing 686
28	gear seat
29	inner ring
30	gear plate II
31	driving gear
32	gear plate I
33	driving gear
34	flat pat
35	motor assy
36	power indicator

37	screw 3x6
38	controller
39	foot
40	battery
41	charger



EXPLODED VIEW OF PRUNING SHEARS RD-PSH01