


Exploded Drawing of Cordless chain saw RDP-SCHS20 Art. No. 075710



Spare part list of RAIDER Cordless Chain Saw RDP-SCHS20 Art. No. 075710

No	Description	
1	anti self lock button	1
2	pushing rod spring	1
3	button spring	1
4	trigger	1
5	screw 3x8	2
6	brake spring plate	1
7	assist handle	1
8	screw 4x16	14
9	motor back cover	1
10	fan cover	1
11	left handle	1
12	washer Ø5xØ16x1.5	1
13	screw 3x50	2
14	front guard	1
15	motor	1
16	small gear	1
17	support plate	1
18	screw 4x12	10
19	screw M5x8	2
20	nut M6	1
21	bearing 608	1
22	big gear	1
23	axle sleeve	1
24	brake torsion spring	1
25	output shaft	1
26	gear worm	1
27	bearing 6000	1
28	dust proof	1
29	brake lever fixing plate	1
30	screw 4x12	7
31	screw 4x12	1
32	connecting rod	1
33	brake rod	1
34	brake spring	1
35	washer Ø5xØ10x1mm	1

36	fuel tank cap	1
37	cap seal ring	1
38	hanger	1
39	fuel tank	1
40	fuel tank connector block	1
41	sponge	1
42	fuel tank connector	1
43	fuel tank seal ring	1
44	inlet pipe	1
45	screw 3x10	2
46	oil pump	1
47	oilout pipe	1
48	oilout nozzle	1
49	seal ring	2
50	sponge	1
51	right handle	1
52	screw 5x16	5
53	seal ring	1
54	spike bumper	1
55	sproket	1
56	retainer ring	1
57	fixing plate of handle	1
58	bar screw	1
59	bar	1
60	saw chain	1
61	bar cover	1
62	pushing plate	1
63	cam	1
64	sproket cover	1
65	adjusting sleeve	1
66	adjusting knob	1
67	pressing knob	1