


# EXPLODED VIEW & SPARE PARTS LIST

## CORDLESS DRILL RDP-PBCD20 Set



**SPARE PARTS LIST**

No	Name
1	Screw
2	Chuck
3	Gear Box Assembly
4	Button
5	Gear
6	Stator
7	Rotor
8	Lampshade
9	Button
10	Left House
11	Left Pin
12	Battery
13	Splice Support
14	Right Pin
15	Screw
16	Right House
17	Rear Cover