


RDI-AGB61 Set Exploded View and spare parts list



1	920380114	Grinding wheel	1	Q235
2	6103810102	Pressure plate	1	45
3	6103810101	Upper Plate	1	45
4	646810011	Coverl	1	Q235
5	630810011	Dust cover	1	Q235
6	663401202	Tool screw	4	20
7	645010011	Cover	1	ZAL512
8	665261011	Deep groove ball bearings	1	IGR15
9	630810031	Waveform gasket	1	65NIN
10	630810041	Bend with perforated shaft	1	65NIN
11	620810011	Output axis	1	40Cr
12	665081001	Semi-round key	1	40Cr
13	6103810103	Big gear	1	40Cr
14	664300001	Shaft gear	1	65mm
15	665808001	Roller bearings	1	IGR15
16	580810101	Handle	1	4
17	661402501	Self-propelled screw	4	20
18	6650810011	Shaft lock spring	1	65mm
19	6650810011	Shaft lock pin	1	40Cr
20	550810101	Shaft lock cap	1	PA6-6F30
21	6450810031	Head shell	1	ZAL512
22	665808001	Deep groove ball bearings	1	Q235
23	630810041	gasket	1	65mm
24	666140001	circclip	1	PA6-6F30
25	550810201	Wind guide	1	PA6-6F30
26	550810301	Switch push	1	PA6-6F30
27	550810401	Brushless motor rotor	1	PA6-6F30
28	550810501	Switching lever	1	PA6-6F30
29	727118001	Brushless motor stator	1	1
30	727118001	Deep groove ball bearings	1	1
31	6662606001	switch	1	1
32	739810011	Control panel	1	1
34	550210701	Large body bracket	1	PA6-6F30
35	550810601	Deactivator cover(left and right wind Windows)	1	PA6-6F30
36	510810101	Shell	1	PA6-6F30
37	536209011	Battery pack	1	1
38	739215901	Charger	1	1