

SPARE PARTS LIST

NO.	Description	Materials	Quantity
1	Lower platen	45	1
2	Grinding wheel disc (125mm)		1
3	Upper platen	45	1
4	Grinding wheel cover	Q235A	1
5	Output shaft	40Cr	1
6	Semicircular key 9*3.7*3		1
7	Retaining rings for shafts 10		1
8	Deep groove oil bearing	6000-2RS	1
9	large bevel gear	40Cr	1
10	Needle roller bearings	HK0808	1
11	lock pin	45	1
12	Lock pin spring	65Mn	1
13	lock button	PA6-GF30	1
14	Right head shell	PA6-GF30	1
15	Cross pan head self-tapping screws	ST3.5*14 black, head ϕ 5.6	11
16	Right housing + rubber coating	PA6-GF30/TPE	1
17	Bushing	Copper-based powder metallurgy	1
18	Wire retaining ring 7		1
19	small bevel gear	40Cr	1
20	Deep groove ball bearing	628-2Z	1
21	transmission shaft	40Cr	1
22	Blade components	PA6-GF30	1
23	Phillips countersunk head screws	M5*8 galvanized	2
24	Motor fixing plate	Q235A	1
25	887 motor		1
26	Forward and reverse dial button	PA6-GF30	1
27	switch button	PA6-GF30	1
28	Key spring	65Mn	2
29	Micro Switch		1
32	Hexagonal nut M8		2
33	Rubber bulkhead	Nitrile rubber	2
34	left head shell	PA6-GF30	1
35	Left housing + rubber coating	PA6-GF30/TPE	1
36	125 cutting disc		1
37	Auxiliary handle (with external hexagonal bolt M8X20, white zinc plated)	PA6-GF30	1
38	Wrench (white zinc plated)	Q235-A	1

EXPLODED VIEW

