



Model No	Position No	Material No	Description	QTY	Remarks	Recommended order ratio	Serial No
DX17	1	60058250	Left Threaded Screw M*25	1		3%	
DX17	2	60058251	Chuck(13Mm)	1		3%	
DX17	3	60058252	Output Spindle	1		3%	
DX17	4	60058253	Steel Ball Φ3	1		5%	
DX17	5	60058254	Rolling Bearing 6001 2Z	1		3%	
DX17	6	60058255	Ring 12	1		3%	
DX17	7	60058256	Driven Gear	1		5%	
DX17	8	60058257	Spring	1			
DX17	9	60058258	Wearing Washer	1			
DX17	10	60058259	Needle Bearing	1			
DX17	11	60058260	Steel Plate	1		1%	
DX17	12	60058261	Function Shift Knob	1			
DX17	13	60058262	Central Support Bracket	1			
DX17	14	60058263	Rolling Bearing 608 2Z	1		3%	
DX17	15	60058264	Rotor	1		3%	
DX17	16	60058265	Rolling Bearing 607 2Z	1		3%	
DX17	17	60058266	Bearig Bushings	1			
DX17	18	60058267	Stator	1		3%	
DX17	20	60058268	Upper/Lower Housing Body	1			
DX17	21	60058269	Carbon brush(pair)	1		5%	
DX17	22	60058270	On The Brush Housing	1			
DX17	23	60058271	Roll Sprin	2			
DX17	24	60058272	Inductor	1			
DX17	25	60058273	Forwarder/Reverse Knob	1			
DX17	26	60058274	Switchfa2 6/1Bek	1		5%	
DX17	27	60058275	Capacitor 0.22Uf 250V	1			
DX17	28	60058276	Cable Protector	1			
DX17	29	60058277	Cord & Plug	1	for BR,PY,CL,UY,PE		
DX17	29	60067002	Cord & Plug	1	for EU		
DX17	29	60068656	Cord & Plug	1	for RU		
DX17	29	60064749	Cord & Plug	1	for CN		
DX17	29	60064748	Cord & Plug	1	for AR		
DX17	29	60066317	Cord & Plug	1	for AE-VDE		
DX17	29	60066318	Cord & Plug	1	for AE-BS		
DX17	30	60058278	Under The Brush Holder	1			
DX17	31	60058279	Self Tapping Screw ST3*12	4			
DX17	32	60058280	Self Tapping Screw ST4*16	9			
DX17	36	60058282	Auxiliary Handle	1			
DX17	37	60058283	Depth Stop	1			
DX17	38	60058284	Throwerring	1			