


[11] PART LIST

[PART1]




PART 1-PART LIST

NO.	PART NO.		PART NAME	Q'ty
1	MA100M30	A01	SPINDLE	1 no
2	MA100M30	A02	BALL BEARING 6907 ZZ	2 nos
3	MA100M30	A03	OIL SEAL	1 no
4	MA100M30	A04	MAIN GEAR 38T	1 no
5	MA100M30	A05	BALL BEARING 6005 2RSC3	1 no
6	MA100M30	A06	SNAP RING	1 no
7	MA100M30	A07	PIN	2 nos
8	MA100M30	A08	GEAR BOX	1 no
9	MA100M30	A09	NEEDLE BEARING NK 1012	1 nos
10	MA100M30	A10	SNAP RING	1 no
11	MA100M30	A11	FIRST GEAR 42T	1 no
12	MA100M30	A12	KEY	1 nos
13	MA100M30	A13	SNAP RING	2 no
14	MA100M30	A14	FIRST GEAR H33T	1 no
15	MA100M30	A15	SNAP RING	1 no
16	MA100M30	A16	FIRST CLUTCH	1 no
17	MA100M30	A17	FIRST PINION	1 no
18	MA100M30	A18	SNAP RING	1 no
19	MA100M30	A19	FIRST GEAR L 22T	1 no
20	MA100M30	A20	SNAP RING	1 no
21	MA100M30	A21	BEARING 6800ZZ	2nos
22	MA100M30	A22	FIRST CHANGE BLOCK	1 no
23	MA100M30	A23	SOCKET BOLT M3	4 nos
24	MA100M30	A24	GEAR CHANGE KNOB	2 nos
25	MA100M30	A25	PIN $\Phi 3 \times 8L$	2 nos
26	MA100M30	A26	GUIDE BRACKET	2 nos
27	MA100M30	A27	SNAP RING	2 nos
28	MA100M30	A28	GUIDE PIN	2nos
29	MA100M30	A29	INNER COVER	1 no
30	MA100M30	A30	NEEDLE BEARING NK 1012	1 no
31	MA100M30	A31	SECOND PINION GEAR 16T	1 no

NO.	PART NO.		PART NAME	Q'ty
32	MA100M30	A32	SECOND PINION	1no
33	MA100M30	A33	KEY	1no
34	MA100M30	A34	SECOND GEAR 27T	1 no
35	MA100M30	A35	SNAP RING	1 no
36	MA100M30	A36	BEARING 6800 ZZ	2 nos
37	MA100M30	A37	NEEDLE BEARING NK1012	1 no
38	MA100M30	A38	SNAP RING	1 no
39	MA100M30	A39	THIRD GEAR H 36T	1 no
40	MA100M30	A40	SNAP RING	1 no
41	MA100M30	A41	THIRD CLUTCH	1 no
42	MA100M30	A42	THIRD PINION	1 no
43	MA100M30	A43	SNAP RING	1 no
44	MA100M30	A44	THIRD GEAR L 42T	1 no
45	MA100M30	A45	SNAP RING	1 no
46	MA100M30	A46	BEARING 6901 ZZ	2 nos
47	MA100M30	A47	THIRD CHANGE BLOCK	1 no
48	MA100M30	A48	=====	-
49	MA100M30	A49	=====	-
50	MA100M30	A50	BEARING 6201 RSC3	1 no
51	MA100M30	A51	SNAP RING	1 no
52	MA100M30	A52	SNAP RING	1 no
53	MA100M30	A53	FAN	1 no
54	MA100M30	A54	ARMATURE ASS'Y	1 no
55	MA100M30	A55	RUBBER BUSHING	1 no
56	MA100M30	A56	BEARING 6200 ZZC3	1 no
57	MA100M30	A57	FAN GUIDE	1 no
58	MA100M30	A58	STATOR	1 no
59	MA100M30	A59	MOTOR HOUSING	1 no
60	MA100M30	A60	CARBON BRUSH HOLDER	2 nos
61	MA100M30	A61	CARBON BRUSH	2 nos
62	MA100M30	A62	CONNECTOR MOUNT	2 nos
63	MA100M30	A63	WIRING CONNECTOR	2 nos

NO.	PART NO.		PART NAME	Q'ty
64	MA100M30	A64	HOUSING CAP	4 nos
65	MA100M30	A65	HEX SOCKET BOLT M4	1 no

[PART2]



MAGPRO100M30 PART2				
NO	PART NO.		PART NAME	Q'ty
1	MA100M30	B01	MOTOR & GEARBOX ASS'Y,	1
2	MA100M30	B02	HEX SOCKET BOLT M6-L20	2
3	MA100M30	B03	SLIDE	1
4	MA100M30	B04	GIB	2
5	MA100M30	B05	HEX SOCKET BOLT M6-L15	3
6	MA100M30	B06	O-RING ASSEMBLED STOPPER BOLT	5

NO	PART NO.		PART NAME	Q'ty
7	MA100M30	B07	WINGBOLT ASS'Y M6-L10	1
8	MA100M30	B08	RACK GEAR	1
9	MA100M30	B09	HEX SOCKET BOLT M6-L15	4
10	MA100M30	B10	RAIL BAR	2
11	MA100M30	B11	CABLE GLAND	2
12	MA100M30	B12	CABLE	1
13	MA100M30	B13	COOLANT TANK ASS'Y	1
14	MA100M30	B14	COOLANT HANGER	1
15	MA100M30	B15	ROUND HEAD BOLT M4-L10	2
16	MA100M30	B16	MAIN FRAME	1
17	MA100M30	B17	WARNING PANEL	1
18	MA100M30	B18	TRUSS HEAD BOLT M4-L10	8
19	MA100M30	B19	CONTROL PANEL ASS'Y	1
20	MA100M30	B20	HANDLE GEAR ASS'Y	1
21	MA100M30	B21	HANDLE JOINT	1
22	MA100M30	B22	HANDLE BAR ASS'Y	3
23	MA100M30	B23	HANDLE REAR CAP	1
24	MA100M30	B24	HEX TIGHTENING BOLT M8-L30	1
25	MA100M30	B25	HEX SOCKET BOLT M5-L30	6
26	MA100M30	B26	HEX SOCKET BOLT M5-L75	2
27	MA100M30	B27	ELECTROMAGNET	1
28	MA100M30	B28	HEX SOCKET BOLT M6-L30	4
29	MA100M30	B29	POWER CABLE	1
30	MA100M30	B30	CABLE GLAND ASS'Y	1
31	MA100M30	B31	HEX SOCKET BOLT M4-L10	2
32	MA100M30	B32	HEX WRENCH BOLT M5-L10	4
33	MA100M30	B33	ARBOR STOPPER	1