



1-⊕

Parts List DCR020 SITE RADIO 1

Item	Part Number	Qty	Part Description	General Description	Other Info	Repair Inst	Markets
1	1004694-44	1	KNOB			No	QS
2	1004694-45	1	COVER SA			No	QS
3	1004696-61	1	BUTTON SA			No	QS
4	1004694-47	1	SPEAKER			No	QS
5	1004777-26	1	PCB SA		FROM WK	No	QS
5	1004696-62	1	PCB SA		31 2020 TO WK 31	No	QS
6	1004696-63	1	PCB SA		2020 TO WK 31	No	QS
6	1004777-25	1	PCB SA		2020 FROM WK	No	QS
7	1004694-50	1	HANDLE SA		31 2020	No	QS
8	1004696-64	1	CAGE			No	QS
9	1004694-52	1	CAGE			No	QS
10	1004694-53	1	KIT			No	QS
11	1004694-54	1	PCB SA			No	QS
12	1004730-36	1	PCB SA		TO WK 31	No	QS
12	1004777-28	1	PCB SA		2020 FROM WK	No	QS
13	1004694-56	1	PCB SA		31 2020	No	QS
14	1004696-66	1	TRANSFORMER			No	QS
15	1004696-67	1	ANTENNA			No	QS
16	1004777-24	1	PCB SA		FROM WK	No	QS
16	1004696-68	1	PCB SA		31 2020 TO WK 31	No	QS
17	1004694-61	1	HOUSING REAR		2020	No	QS
18	1004694-62	1	BATTERY CONNECTOR			No	QS
19	1004696-69	1	COVER			No	QS
20	1004694-64	1	DOOR			No	QS
21	1004694-65	1	CORDSET (EURO)			No	QS
22	1004696-70	1	COVER			No	QS
23	1004694-69	1	BRACKET SA			No	QS
24	1004696-71	1	HOUSING SA			No	QS
51	5140112-26	1	BATTERY			No	QS