




Item No.	Type	Sub	Part No.	Description	Qty	Unit
001			TC00000001	FRONT BAR	2	PC.
002			TC00000002	VOLUME KNOB	1	PC.
003			TC00000003	USB COVER HOLDER	1	PC.
004			TC00000004	USB COVER	1	PC.
005			TC00000005	SCREW M6X45	4	PC.
006			TC00000006	FRONT CABINET BLUE	1	PC.
007			TC00000162	FRONT INNER CABINET ASSY	1	PC.
		INC.		Item No. 15-20		
009			TC00000009	SCREW M4X15	4	PC.
010			TC00000011	SCREW M3X8	1	PC.
011			TC00000012	VOLUME HOLDER COVER	1	PC.
012			TC00000011	SCREW M3X8	2	PC.
013			TC00000010	WIRE CLAMP	1	PC.
014			TC00000011	SCREW M3X8	4	PC.
015			TC00000013	MIDDLE KEY	1	PC.
016			TC00000014	MIDDLE KEY HOLDER	1	PC.
017			TC00000016	TOP KEY	1	PC.
018			TC00000017	TOP KEY HOLDER	1	PC.
019			TC00000015	SCREW M1.7X5	4	PC.
020			TC00000015	SCREW M1.7X5	5	PC.
021			TC00000019	COVER PCB	2	PC.
022			TC00000011	SCREW M3X8	4	PC.
023			TC00000020	PCBA-DISPLAY	1	PC.
024			TC00000178	FLAT CABLE	1	PC.
025			TC00000011	SCREW M3X8	10	PC.
026			TC00000163	PCBA-USB1 ASSY	1	PC.
027			TC00000022	PCBA-MAIN C	1	PC.
028			TC00000027	SHIELD	1	PC.
029			TC00000026	SCREW M3X8	2	PC.
030			TC00000011	SCREW M3X8	3	PC.
031			TC00000026	SCREW M3X8	2	PC.
032			TC00000029	PCBA-USB2	1	PC.
033			TC00000011	SCREW M3X8	2	PC.
034			TC00000030	PCBA CHARGING	1	PC.
035			TC00000011	SCREW M3X8	2	PC.
036			TC00000031	PCBA-CXT BATTERY	1	PC.
037			TC00000032	SCREW M2.6X6	2	PC.
038			TC00000011	SCREW M3X8	2	PC.
039			TC00000033	PCBA-SWITCH	1	PC.
040			TC00000011	SCREW M3X8	2	PC.
041			TC00000034	LXT TERMINAL HOLDER BLUE	1	PC.
042			TC00000011	SCREW M3X8	2	PC.
043			TC00000036	PCBA-LXT BATTERY	1	PC.
044			TC00000010	WIRE CLAMP	2	PC.
045			TC00000037	CXT TERMINAL	1	PC.
046			TC00000038	BAT SWITCH BUTTON BLUE	2	PC.
047			TC00000040	LXT SPRING	4	PC.
048			TC00000041	LXT TERMINAL	1	PC.
049			TC00000042	FRONT INNER CABINET RUBBER	1	PC.
050			TC00000045	SPEAKER BRACKET	1	PC.
051			TC00000032	SCREW M2.6X6	1	PC.
052			TC00000046	LEAD UNIT	1	PC.
053			TC00000047	SPEAKER RUBBER	1	PC.
054			TC00000048	SPEAKER L	1	PC.
055			TC00000049	SPK COVER	1	PC.
056			TC00000050	SCREW M6X14	4	PC.
057			TC00000051	RUBBER RING	4	PC.
058			TC00000052	SCREW M3X10	1	PC.
059	2		TC00000199	ANTENNA LEAD UNIT	1	PC.
060			TC00000053	FM ANTENNA	1	PC.
061			TC00000054	RUBBER RING	1	PC.

Item No.	Type	Sub	Part No.	Description	Qty	Unit
062			TC00000032	SCREW M2.6X6	1	PC.
063	2		TC00000186	LEAD UNIT	1	PC.
064			TC00000055	PCBA-DC JACK	1	PC.
065			TC00000015	SCREW M1.7X5	2	PC.
066			TC00000056	DC JACK HOLDER BLUE	1	PC.
067			TC00000058	BACK CABINET SHAFT	1	PC.
068			TC00000059	DC JACK COVER	1	PC.
069			TC00000060	SCREW M3X14	1	PC.
070			TC00000045	SPEAKER BRACKET	1	PC.
071			TC00000047	SPEAKER RUBBER	1	PC.
072			TC00000174	SPEAKER R	1	PC.
073			TC00000049	SPK COVER	1	PC.
074			TC00000051	RUBBER RING	4	PC.
075			TC00000050	SCREW M6X14	4	PC.
076			TC00000061	BATTERY PLUS PLATE	1	PC.
077			TC00000062	BATTERY MINUS PLATE	1	PC.
078			TC00000063	BATTERY MINUS PLUS PLATE	1	PC.
079			TC00000064	BATTERY COVER BLUE	1	PC.
080			TC00000066	HEXA SOCKET SCREW T15 3X45	2	PC.
081			TC00000067	MIDDLE CABINET RUBBER	1	PC.
082			TC00000068	SCREW M6X19	2	PC.
083			TC00000069	COMPRESSION SPRING	4	PC.
084			TC00000070	STEEL BALL	4	PC.
085			TC00000071	HANDLE PLATE R	1	PC.
086			TC00000072	HANDLE PLATE L	1	PC.
087			TC00000073	HANDLE L BLUE	1	PC.
088			TC00000075	GRIP	1	PC.
089			TC00000076	HANDLE R BLUE	1	PC.
090			TC00000078	SCREW M6X20	2	PC.
091			TC00000026	SCREW M3X8	1	PC.
092			TC00000175	BATTERY RUBBER PAD	1	PC.
093			TC00000011	SCREW M3X8	4	PC.
094			TC00000080	BOTTLE OPENER BACK COVER BLUE	1	PC.
095			TC00000082	RUBBER RING	1	PC.
096			TC00000085	BOTTLE OPENER	1	PC.
097			TC00000086	HOLDER	1	PC.
098			TC00000011	SCREW M3X8	2	PC.
099			TC00000087	PHONE POCKET BLUE	1	PC.
101			TC00000089	SCREW M3X8	1	PC.
102			TC00000090	RUBBER RING	1	PC.
103			TC00000011	SCREW M3X8	2	PC.
104			TC00000091	BACK CABINET BLUE	1	PC.
105			TC00000093	SHAFT SHORT	1	PC.
106			TC00000094	HINGE BLUE	1	PC.
107			TC00000096	SHAFT LONG	1	PC.
108			TC00000097	LATCH BLUE	1	PC.
109			TC00000099	HOOK	1	PC.
110			TC00000100	CABINET HOLDER L BLUE	1	PC.
111			TC00000068	SCREW M6X19	2	PC.
112			TC00000102	CABINET HOLDER R BLUE	1	PC.
113			TC00000104	CABINET HOLDER BLUE	1	PC.
114			TC00000068	SCREW M6X19	2	PC.
115			TC00000179	4P WIRE	1	PC.
116			TC00000180	8P WIRE	1	PC.
117			TC00000181	2P/4P WIRE ASSY	1	PC.
122			TC00000169	LEAD UNIT	1	PC.
126			TC00000164	CXT TERMINAL ASSY	1	PC.
		INC.		INC 36,45,63		
127			TC00000165	LXT TERMINAL ASSY BLUE	1	PC.
		INC.		Item No. 41,43,47,48		
128			TC00000168	MIDDLE CABINET ASSY BLUE	1	PC.
		INC.		Item No. 76,77,122		
129			TC00000172	DC JACK ASSY BLUE	1	PC.

Item No.	Type	Sub	Part No.	Description	Qty	Unit
130		INC.	TC00000176	Item No. 64-66 BACK CABINET ASSY BLUE	1	PC.
		INC.		Item No. 101,102,104-109		
<u>ACCESSORIES</u>				- Visit www.makita.ca for more accessories information -		
A01			TC00000133	AC ADAPTER A	1	PC.
A02			TC00000145	AC CORD D	1	PC.
A03			-----	BATTERY CHARGER	1	PC.
A04			-----	12V MAX CXT LI-ION SLIDE BATTERY	1	PC.
A05			-----	14.4V - 18V LI-ION BATTERY	1	PC.