


Exploded drawing of Inverter Welding Machine RD-LMIW220



SPARE PART LIST

NO.	Components	NO.	Components
1	Handle	12	Machine Frame
2	Cover	13	Transformer B
3	Transformer A	14	Transformer C
4	Capacitor	15	Cooling Fin C
5	Rectifier bridge	16	Diode
6	IGBT	17	Main transformer
7	Cooling Fin A	18	Heating sensor
8	Cooling Fin B	19	Digital display
9	Power Cable	20	Potentiometer
10	Switch	21	Quick Connector
11	Fan		