


# EXPLODED VIEW



**SPARE PARTS**

1.	Flame retardant caps	1.
2.	jet nozzle	1.
3.	Steel ball	1.
4.	Check valve spring	1.
5.	Check ring back	1.
6.	o-rings	1.
7.	Heating tube limit ring	1.
8.	Heating tube	1.
9.	Pipe run	1.
10.	Locking spring	1.
11.	The slider	1.
12.	Push button switch	1.
13.	The heater	1.
14.	baffle	1.
15.	Heating block	1.
16.	Fuselage guard	1.
17.	Heating block wire	1.
18.	stents (18V)	1.
19.	Toggle switch	1.
20.	Casing cover	1.
21.	The switch handle	1.
22.	screw ST3*12	10.
23.	The bottom of the chassis	1.
24.	Square red lamp	1.
25.	Reset tension spring	1.
26.	Connecting rod	1.
27.	The slider	1.
28.	Sealing ring	1.
29.	screw $\varnothing$ 2.5*6	2.