

SPARE PARTS CATALOGUE

LAWN MOWERS: CONSUMER WALK-BEHINDS: HUSQVARNA LC 140SP


Spare Parts List

SPARE PARTS LIST

LAWN MOWERS: CONSUMER WALK-
BEHINDS

HUSQVARNA LC 140SP


B LC 140SP
CHASSIS



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599349369	CHASSIS	CHASSIS	1
2	599349371	COVER KIT	FRONT COVER	1
3	599349373	FLAP	REAR DOOR	1
4	599349409	PLATE KIT	(blank)	1
5	599349423	WHEEL	REAR WHEEL	1
6	599349386	AXLE	WHEEL AXLE	1
7	599349420	TRANSMISSION KIT	REAR TRANSMISSION	1
8	599349396	GEAR WHEEL	WHEEL DRIVE	2
9	599349367	WHEEL	FRONT WHEEL	1
10	599349387	AXLE	WHEEL AXLE	2
11	599349382	AXLE	FRONT AXLE FIXING	1
12	599349399	HANDLE KIT	HEIGHT ADJUSTMENT HANDLE	1
13	599349363	PLATE KIT	HEIGHT ADJUSTMENT PLATE	1
14	599349366	SPRING	HEIGHT ADJUSTMENT SPRING	1
15	599349364	ROD	HEIGHT ADJUSTMENT ROD	1


D LC 140SP
GRASS HANDLING



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599349378	GRASS BAG ASSY	GRASS BAG KIT	1


C LC 140SP
ENGINE



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	TBD	TBD		1
2	599349407	INSTALLATION KIT	BOLTS AND NUTS	1
3	599349413	PULLEY	DRIVE PULLEY	1
4	599349376	COVER	BELT COVER	1
5	529737101	BLADE SUPPORT	BLADE ADAPTER	1
6	599349389	BELT	BELT	1
7	599349374	BLADE		1

B LC 140SP
HANDLE



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599349362	BAIL ARM ASSY	BAIL ARM	1
2	599349415	ROD	DRIVE ROD	1
3	599349403	HANDLE KIT	HANDLE AND SHEATH	1
4	599349397	HANDLE	LOWER HANDLE	1
5	599349361	BAIL ARM ASSY	BAIL ARM	1
6	529853401	HANDLE KIT	HANDLE	1
7	599349360	KNOB ASSY	KNOB	1
8	599349391	CABLE	FLAMEOUT CABLE	1
9	599349393	CABLE ASSY	DRIVE CABLE ASSY	1
10	599349379	CLIP	CABLE CLIP	1
11	529596001	KNOB ASSY	KNOB	1
12	599349380	SUPPORT KIT	HANDLE BRACKET	1
13	599349418	SLEEVE	ANTI FRICTION SLEEVE	1