


RAIDER®

Exploded view drawing RD-GBC07S



PARTS LIST RD-GBC07S

NO	Part Name	Qty
1	Cylinder	1
2	Spark Plug	1
3	Gasket	1
4	Insulator	1
5	Gasket	1
6	Carburetor	1
7	Air Filter Holder	1
8	Air Filter	1
9	Holder	1
10	Spring Washer	2
11	Bolt M5×55	2
12	Air Filter Lid	1
13	Bolt M5×20	10
14	Bolt M5×20	4
15	Gasket	1
16	Bolt M5×20	2
17	Ring	2
18	Piston	1
19	Snap Ring	2
20	Crank Shaft	1
21	Bearing	1
22	Pin	1
23	Key	1
24	Gasket	1
25	Bearing	2
26	Bolt M5×30	4
27	Crankcase	1
28	Seal	1
29	Iginition Coil	1
30	Flywheel	1
31	Nut	1

NO	Part Name	Qty
32	Washer	2
33	Clutch	1
34	Hex Screw	2
35	Bolt	2
36	Flywheel Housing	1
37	Pin	2
38	Fuel Tank Keeper	1
39	Rubber Pad	1
40	Fuel Tank	1
41	Guard	1
42	Pin	2
43	Crankcase	1
44	Seal	1
45	Washer	1
46	Starter Wheel	1
47	Gasket	1
48	Starter	1
49	Bolt M5×12	3
50	Gasket	1
51	Muffler	1
52	Spring Washer	2
53	Bolt M6×50	2
54	Cover	1
55	Cover	1
56	Cap	1