

Parts List Rotary Hammer RDP-HD12H

NO.	DESCRIPTION		DESCRIPTION
15261	ASSISTANT HANDLE ASM.	45	CYLINDER PIN
1	SCREW,CLAMP	46	WASHER ANTIFRICHTION
2	GASKET,CLAMP	47	GASKET SEALING
3	GRIP BASE	16263	FIXTURE COMPONENTS
4	GRIP COMPLETE	48	BEARING SLEEVE
5	DEPTH GAUDE	49	BEARING AXIAL HK0808
15262	SDS ASM.	50	HOLDER
6	HOLDER TIP	51	"O"RING ϕ 23.6 \times 2.65
7	SLIDING GOLLAR	52	BOARD SLIDE
8	BALL, STEEL ϕ 7	53	KNOB FUNCTION-SHIFT
9	HOLDER SPRING	261	SA SPRING
10	CLAMP METAL	54	SPRING BEVEL
11	SPRING TOWER	55	GASKET METAL
16261	FRONT CHASSIS COMPONENT	16264	SAINTERSHAFT
12	TAPPING SCREW ST4.2 \times 33	56	CLAMP METAL SPRING CLUTCH
13	CASE GEAR	57	CLUTCH
14	RETAINER	58	SPRING CLUTCH
15	TAPPING SCREW NST4.5-F \times 10	59	SHAFT INTERMEDIATE
16	SEAL OIL	60	WOBBLE BEARING
17	BEARING 606-2Z	61	THURST WASHER AS0919
18	GASKET METAL IMPACT SHAFT	62	BEARING,AXIAL AS0919
16262	OUTSIDE KONB COMPONENT	63	SMALL GEAR
19	"O"RING KONB	221	ASK0817 ASM.
20	BUTTON KONB MODE SELECTOR	64	THURST WASHER AS0817
21	SPING KONB SELECTOR	65	BEARING,AXIALAXK0817
22	KONB MODE SELECTOR	16265	SA,ARMATURE
11261	SA SHAFT	66	RING,SEALING
23	CLAMP METAL ϕ 28.5	67	BEARING 609-2RS/C3
24	CLAMP METAL	68	ARMATURE
25	SPRING RETURE	69	BEARING 607-2Z
26	SLEEVE SHAFT	70	STATOR
27	GEAR SLIDE	71	SLEEVE BEARING
28	PRESS SPRING	72	BACK HOUSING
29	GASKET, METAL	73	LABEL
30	CLAMP,METAL ϕ 34	74	TAPPING SCREWST4.2 \times 19
31	SHAFT,IMPACT	3261	SA,FIELE
32	PIN ϕ 3 \times 23.8	75	ELECTRIC CARBON BRUSH
33	SEAL,OIL9 \times 16 \times 4	76	HOLDER BRUSH
34	BLOCK POSITION	77	SLEEVE,HOLDER BRUSH
35	COLUMN IMPACT	78	CARBON BRUSH EXTENSION LINE <input type="checkbox"/>
36	SLEEVE BLOCK	79	CARBON BRUSH EXTENSION LINE <input type="checkbox"/>
37	"O"RING 18 \times 3.5	80	SWITCH
38	"O"RING 18 \times 3.15	81	CAPACITOR
39	SLEEVE RETAINING	82	TAPPING SCREW ST4.2 \times 16
40	CLAMP METAL	83	CLAMP,CORD
41	RAM	84	CASE,GEAR
42	"O"RING RAM	85	NAME LABEL
43	CYLINDER PIN	86	SLEEVE,CORD
44	WASHER CYLINDER PIN	87	POWER CORD