


RD-WP43 exploded view



www.raider.bg

-

	, i i i i i i i i i i i i i i i i i i i
2	O-ring
3	plastic cover
4	screw
5	pump body
6	O-ring
7	plastic cover
8	difuser
9	O-ring
10	impeller
11	mechanical seal
12	SS-flange
13	swing ring
14	bracket
15	bearing
16	rotor
17	bearing
18	stator
19	main body
20	wave gasket
21	motor back cover
22	body screw
23	fan
24	clamp spring
25	handle cover
26	fan cover
27	screw
28	screw
29	spring washer
30	flat gasket
31	supporting foot
32	switch box-basic
33	screw
34	seal
35	screw

cable buckle 36 cable jacket 37 switch box-cover 38 39 screw 40 seal switch 41 42 switch-cover switch bracket 43 capacitance 44 45 capacitance buckle 46 cable

PARTS LIST RD-WP43