


RDP-WP26 exploded view



PARTS LIST RDP-WP26

NO.	Description	Qty	NO.	Description	Qty
1	power line	1	29	O ring	1
2	floating switch	1	30	adjusting gasket	
3	tapping screw	2	31	impeller	1
4	handle	1	32	screw	1
5	rear pump shell	1	33	main pump shell	1
6	pipping cord	2	33-1	steel ball	1
7	cable sheath	1	34	O ring	2
8	cable sheath	1	35	elbow	1
9	cable briquetting	1	36	outpur connector	1
10	cable briquetting	1	37	metal net	1
11	16uF capacitance	1	38	metal net	1
12	cable briquetting	1	39	tapping screw	4
13	tapping screw	3	40	O ring	1
14	ground connection cover	1	41	base	1
15	nylon close-end wiri	2	42	cross plate tapping screw	4
15	nylon close-end wiri	3			
16	rubber press	1			
17	ribbon	1			
18	rear cover	1			
18-1	wire jacket	1			
18-2	washer	1			
18-3	yellow-green line	1			
18-4	lug plate	1			
18-5	washer	1			
18-6	screw	1			
19	corrugated gasket	1			
20	bearing	2			
21	rotor	1			
22	stator	1			
23	ring gasket	1			
24	gasket	1			
25	skeleton seal ring	3			
26	Aluminium bush	1			
27	O ring	1			
28	front cover	1			