


GX100U

E-3 CYLINDER BARREL



Z4E0E0300A

Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	12000-Z0D-405	BARREL ASSY., CYLINDER			001	0	0
2	12201-Z0D-305	GUIDE ASSY., EX. VALVE (O.S.)			001	0	0
3	12204-Z0D-305	GUIDE, IN. VALVE (O.S.)			001	0	0
4	12311-Z0D-000	COVER, HEAD			001	0	0
5	12355-Z0D-000	COVER COMP. A, BREATHER			001	0	0
6	12365-Z0D-000	COVER COMP. B, BREATHER			001	0	0
7	15171-Z0D-V00	PIPE, BREATHER			001	0	0
8	15571-Z0D-V71	VALVE, OIL OUTLET			001	0	0
9	15572-ZM7-000	PLATE, STOPPER			001	0	0
11	90008-ZM7-000	BOLT, 4X10			001	0	0
12	90014-952-000	BOLT, FLANGE, 6X14 (CT200)			006	0	0
13	91202-KJ9-003	OIL SEAL, 20X32X6			001	0	0
14	93500-03005-0A	SCREW, PAN, 3X5			001	0	0
15	98056-55757	PLUG, SPARK (U16FSR-UB)			001	0	0
15	98056-55777	PLUG, SPARK (CR5HSB)			001	0	0


E-6 CRANKCASE COVER



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	11300-Z4E-305	COVER ASSY., CRANKCASE			001	0	0
5	15600-ZM3-003	CAP ASSY., OIL FILLER			001	0	0
6	15625-ZE1-003	PACKING, OIL FILLER CAP			001	0	0
7	16510-ZL8-000	GOVERNOR ASSY.			001	0	0
8	16531-ZE1-000	SLIDER, GOVERNOR			001	0	0
9	16541-Z0D-000	SHAFT, GOVERNOR ARM			001	0	0
10	90121-952-000	BOLT, FLANGE, 6X25 (CT200)			008	0	0
11	90131-ZE1-000	BOLT, DRAIN PLUG			001	0	0
12	90451-ZE1-000	WASHER, THRUST, 6MM			001	0	0
13	90601-ZE1-000	WASHER, DRAIN PLUG, 10.2MM			001	0	0
14	90602-ZE1-000	CLIP, GOVERNOR HOLDER			001	0	0
15	91202-KJ9-003	OIL SEAL, 20X32X6			001	0	0
16	91231-891-003	OIL SEAL, 6X11X4 (ARAI)			001	0	0
19	94101-06800	WASHER, PLAIN, 6MM			002	0	0
20	94251-08000	PIN, LOCK, 8MM			001	0	0
21	94301-08200	DOWEL PIN, 8X20			002	0	0
25	96100-62040-00	BEARING, RADIAL BALL, 6204			001	0	0

GX100U


E-7 CRANKSHAFT



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
8	91001-Z0D-V01	BEARING, RADIAL BALL, 6204C			001	0	0
9	13310-Z0D-V70	CRANKSHAFT COMP.			001	0	0

GX100U


E-8 PISTON/CONNECTING ROD



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	13010-Z0D-003	RING SET, PISTON			001	0	0
2	13101-Z0D-000	PISTON			001	0	0
3	13111-ZE0-000	PIN, PISTON			001	0	0
4	13200-Z0D-000	ROD ASSY., CONNECTING			001	0	0
4	13200-Z0D-305	ROD ASSY., CONNECTING (UNDER SIZE)			(1)	0	0
5	90001-ZM7-000	BOLT, CONNECTING ROD			002	0	0
6	90551-ZE0-000	CLIP, PISTON PIN, 13MM			002	0	0

GX100U


E-9 CAMSHAFT PULLEY



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	12209-KT7-013	SEAL, VALVE STEM			001	0	0
2	14320-Z0D-010	PULLEY COMP., CAMSHAFT			001	0	0
3	14324-Z0D-000	SHAFT, CAM PULLEY			001	0	0
4	14400-Z0D-003	BELT, TIMING (61YU7 G-200)			001	0	0
5	14431-Z0D-000	ARM, IN. VALVE ROCKER		1307732	001	0	0
5	14431-Z0D-010	ARM, IN. VALVE ROCKER	1307733		001	0	0
6	14441-Z0D-000	ARM, EX. VALVE ROCKER		1307732	001	0	0
6	14441-Z0D-010	ARM, EX. VALVE ROCKER	1307733		001	0	0
7	14461-ZL8-000	SHAFT, ROCKER ARM			002	0	0
8	14711-Z0D-000	VALVE, IN.			001	0	0
9	14721-Z0D-000	VALVE, EX.			001	0	0
10	14751-Z0D-000	SPRING, VALVE			002	0	0
11	14771-ZM3-010	RETAINER, VALVE SPRING			002	0	0
12	90012-333-000	SCREW, TAPPET ADJUSTING			002	0	0
13	90206-001-000	NUT, TAPPET ADJUSTING			002	0	0
14	91301-ZM0-V31	O-RING, 6.8X1.9 (ARAI)			001	0	0

GX100U


E-11-1 RECOIL STARTER (2)



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	28400-Z0D-V03ZA	STARTER ASSY., RECOIL *NH1 * (NH1 BLACK)		1188240	001	0	0
1	28400-Z0D-V04ZA	STARTER ASSY., RECOIL *NH1* (NH1 BLACK)	1188241		001	0	0
2	28410-Z0D-V02ZA	CASE COMP., RECOIL STARTER *NH1* (NH1 BLACK)			001	0	0
3	28421-Z0D-V02	REEL, RECOIL STARTER			001	0	0
4	28422-ZG0-W02	RATCHET, STARTER			002	0	0
5	28433-ZG0-W02	GUIDE, RATCHET			001	0	0
6	28441-ZW6-003	SPRING, FRICTION			001	0	0
7	28442-ZH8-003	SPRING, RECOIL STARTER			001	0	0
8	28461-ZH8-003	KNOB, RECOIL STARTER		1188240	001	0	0
8	28461-ZH8-013	KNOB, RECOIL STARTER	1188241		001	0	0
9	28462-Z0D-V03	ROPE, RECOIL STARTER			001	0	0
10	28467-Z0D-V02	PLATE, SIDE			001	0	0
11	28468-Z0D-V02	PLATE, SLIDE			001	0	0
12	90003-ZH8-003	SCREW, SETTING			001	0	0
13	95701-06008-00	BOLT, FLANGE, 6X8			003	0	0

GX100U

E-12 FAN COVER




Z4EGE1200C

Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	19610-Z4E-S11ZA	COVER COMP., FAN *NH1 * (NH1 BLACK)			001	0	0
2	35120-Z0D-V81	SWITCH ASSY., ENGINE STOP			001	0	0
4	90014-952-000	BOLT, FLANGE, 6X14 (CT200)			003	0	0
6	16191-Z4E-800	STAY, WIRE			001	0	0
7	90018-ZE1-000	BOLT, FLANGE, 6X23 (CT200)			001	0	0

GX100U


E-14-2 CARBURETOR (RAMMER FLOATLESS)



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	16010-Z4E-802	GASKET, METERING DIAPHRAGM			001	0	0
2	16011-Z0D-V02	GASKET, PUMP			001	0	0
3	16013-Z4E-802	DIAPHRAGM ASSY., METERING			001	0	0
4	16014-Z0D-V02	DIAPHRAGM, PUMP			001	0	0
5	16018-ZM3-004	SCREEN, INLET			001	0	0
6	16019-ZM3-004	VALVE, INLET NEEDLE			001	0	0
7	16022-ZM3-014	PIN, METERING LEVER			001	0	0
8	16023-Z0D-V02	LEVER, METERING			001	0	0
9	16030-ZM3-004	SPRING, PUMP			001	0	0
10	16040-Z4E-802	COVER, PUMP			001	0	0
11	16041-Z0D-V02	SCREW			001	0	0
12	16042-Z0D-V02	SPRING			001	0	0
13	16043-Z4E-802	COVER, METERING DIAPHRAGM			001	0	0
14	16044-Z4E-802	SCREW			001	0	0
15	16045-Z0D-V02	STOPPER, THROTTLE LEVER			001	0	0
16	16046-Z0D-V73	LEVER, THROTTLE			001	0	0
17	16048-Z0D-V02	SPACER, THROTTLE LEVER			001	0	0
18	16049-Z4E-S12	SCREW, IDLE ADJUSTING			001	0	0
19	16050-Z0D-V02	SPRING			001	0	0
20	16051-Z0D-V02	VALVE, THROTTLE			001	0	0
21	16052-Z0D-V02	SHAFT, THROTTLE			001	0	0
22	16053-Z0D-V02	CLIP, THROTTLE SHAFT			001	0	0
23	16054-Z0D-V02	SCREW, VALVE			002	0	0
24	16055-Z0D-V02	SCREW ASSY.			001	0	0
25	16056-Z0D-V02	SPRING			001	0	0
26	16057-Z0D-V02	BALL			001	0	0
27	16058-Z0D-V72	SHAFT ASSY., CHOKE			001	0	0
28	16059-Z0D-V03	VALVE, CHOKE			001	0	0
29	16060-Z0D-V02	SCREW			001	0	0
30	16061-Z0D-V02	SEAL, DUST			002	0	0
31	16100-Z4E-802	CARBURETOR ASSY. (HDA 275)		1197558	001	0	0
31	16100-Z4E-803	CARBURETOR ASSY. (HDA 275A)	1197559	1356294	001	0	0
31	16100-Z4E-804	CARBURETOR ASSY. (HDA 275B)	1356295		001	0	0
38	16552-896-650	COLLAR, LEVER			001	0	0
41	99101-Z0D-0520	JET (#52)			(1)	0	0
41	99101-Z0D-0540	JET (#54)			(1)	0	0
41	99101-Z4E-0560	JET (#56)			001	0	0
41	99101-Z4E-0580	JET (#58)			(1)	0	0


49	16055-Z4E-802	SCREW ASSY.	004	0	0
50	06116-Z4E-800	DIAPHRAGM KIT	(1)	0	0

GX100U
E-15 AIR CLEANER



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
4	17228-Z0D-V01	PACKING, AIR CLEANER			001	0	0
11	94050-05000	NUT, FLANGE, 5MM			002	0	0
15	90042-Z4E-S30	BOLT, STUD, 5X95			002	0	0


E-16-1 MUFFLER (2)



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	18310-Z0D-V20	MUFFLER COMP.			001	0	0
2	18321-Z0D-V21	PROTECTOR, MUFFLER		1188240	001	0	0
2	18321-Z0D-V22	PROTECTOR, MUFFLER	1188241		001	0	0
3	18350-ZL8-000	ARRESTER COMP., SPARK			(1)	0	0
4	18381-Z0D-000	GASKET, MUFFLER			001	0	0
6	90014-952-000	BOLT, FLANGE, 6X14 (CT200)			003	0	0
7	90048-Z0D-V00	BOLT, STUD, 6X78 (CT200)			002	0	0
8	90055-ZE1-000	SCREW, TAPPING, 4X6			(1)	0	0
9	90343-ZE6-000	NUT, SELF-LOCK, 6MM			002	0	0

GX100U


E-19 FLYWHEEL/IGNITION COIL



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	13331-ZM7-000	KEY, SPECIAL			001	0	0
2	28451-Z0D-V03	PULLEY, STARTER			001	0	0
3	30500-Z0D-V02	COIL ASSY., IGNITION			001	0	0
5	30564-ZA5-000	GROMMET, CORD			001	0	0
6	30700-Z0D-V01	TERMINAL ASSY., HIGH TENSION			001	0	0
8	31110-Z0D-003	FLYWHEEL COMP.			001	0	0
10	90022-888-010	BOLT, FLANGE, 6X20 (CT200)			002	0	0
12	94050-12000	NUT, FLANGE, 12MM			001	0	0

GX100U

E-19-10 OIL ALERT/OIL LEVEL SWITCH



Z4E0E1910C



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
2	32195-Z4E-S10	CORD, STOP SWITCH			001	0	0
4	35480-Z4E-S11	SWITCH ASSY., OIL LEVEL			001	0	0
5	90014-952-000	BOLT, FLANGE, 6X14 (CT200)			004	0	0
7	90682-959-661	CLIP B, CABLE (9MM BLACK)			001	0	0
8	90681-959-003	CLIP A, CABLE (NIFCO) (3.8MM BLACK)			002	0	0
9	91302-ZL8-003	O-RING, 11.8X2.4			001	0	0
11	32112-Z4E-S11	BRACKET, OIL ALERT UNIT			001	0	0
13	36103-ZE1-000	HOLDER, STOP SWITCH CORD			001	0	0
14	90002-MC7-000	BOLT, FLANGE, 5X8			002	0	0
15	90683-SA0-003	CLIP, WIRE HARNESS, 25MM			001	0	0
16	34150-Z4E-801	ALERT UNIT, OIL (START LED)			001	0	0
17	91540-S30-003	CLIP, HARNESS BAND (NATURAL) (151.5MM)			001	0	0

E-22-1 CONTROL (2)



<u>Refnr</u>	<u>Part Number</u>	<u>Description</u>	<u>from</u>	<u>to</u>	<u>Unit Qty</u>	<u>Order Qty</u>	<u>Repair Qty</u>
3	16550-Z0D-V01	ARM COMP., GOVERNOR			001	0	0
5	16555-Z0D-V00	ROD, GOVERNOR			001	0	0
6	16561-Z0D-V00	SPRING, GOVERNOR			001	0	0
7	16562-Z4E-S10	SPRING, THROTTLE RETURN			001	0	0
8	16594-883-010	HOLDER, WIRE			001	0	0
10	90014-952-000	BOLT, FLANGE, 6X14 (CT200)			002	0	0
11	90015-ZE5-010	BOLT, GOVERNOR ARM			001	0	0
12	90605-230-000	CIRCLIP, 5MM			001	0	0
13	92301-05020-0A	BOLT, RECESSED, 5X20			002	0	0
14	93500-04006-0H	SCREW, PAN, 4X6			001	0	0
17	94050-06000	NUT, FLANGE, 6MM			001	0	0
18	16500-Z4E-S10	CONTROL ASSY.			001	0	0
20	94001-05000	NUT, HEX., 5MM			002	0	0

