



GX390T2
E-2 CYLINDER HEAD



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	12210-Z5T-416	HEAD COMP., CYLINDER			001	0	0
2	12204-ZE2-306	GUIDE, IN. VALVE (O.S.)			001	0	0
3	12205-ZE2-305	GUIDE, EX. VALVE (O.S.)			001	0	0
4	12216-ZE2-300	CLIP, VALVE GUIDE			001	0	0
5	12251-Z5T-003	GASKET, CYLINDER HEAD (NIPPON LEAKLESS)			001	0	0
6	12310-ZE2-020	COVER COMP., HEAD			001	0	0
7	12391-ZE2-020	PACKING, HEAD COVER			001	0	0
9	92900-08032-0E	BOLT, STUD, 8X32			002	0	0
10	90014-Z5T-000	BOLT, HEAD COVER			001	0	0
11	90042-ZK6-D70	BOLT, STUD, 8X115			002	0	0
12	90441-ZE2-010	WASHER COMP., HEAD COVER			001	0	0
13	94301-12200	DOWEL PIN, 12X20			002	0	0
14	95701-10080-00	BOLT, FLANGE, 10X80			004	0	0
15	98079-55855	PLUG, SPARK (W16EPR-U) (DENSO)			001	0	0
15	98079-55876	PLUG, SPARK (BPR5ES) (NGK)			001	0	0

GX390T2
E-3 CYLINDER BARREL




Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	12000-Z5T-405	BARREL ASSY., CYLINDER (SELFSTARTER+ALERT)			001	0	0
3	16541-ZE3-010	SHAFT, GOVERNOR ARM			001	0	0
6	90131-883-000	BOLT, DRAIN PLUG, 12X15			002	0	0
7	90446-KE1-000	WASHER, 8.2X17X0.8			001	0	0
8	91201-Z1C-003	OIL SEAL, 35X52X8 (NOK)			001	0	0
9	91203-952-771	OIL SEAL, 8X14X5			001	0	0
10	91353-671-004	O-RING, 14MM (NOK)			001	0	0
11	94050-10000	NUT, FLANGE, 10MM			001	0	0
12	94109-12000	WASHER, DRAIN PLUG, 12MM			002	0	0
13	94251-10000	PIN, LOCK, 10MM			001	0	0
14	95701-06012-00	BOLT, FLANGE, 6X12			002	0	0
15	96100-62020-00	BEARING, RADIAL BALL, 6202			001	0	0
16	35480-ZF6-003	SWITCH ASSY., OIL LEVEL			001	0	0

E-6 CRANKCASE COVER (1)



no items found

GX390T2
E-40-1 OTHER PARTS (2) (FUEL COCK)




Z1C0E4001E

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	16173-001-004	O-RING			001	0	0
2	16950-ZB4-015	COCK ASSY., FUEL			001	0	0
3	16952-ZB4-005	SCREEN SET, FUEL STRAINER			001	0	0
4	16958-397-771	O-RING, 9.0X1.3			001	0	0
5	16959-471-831	FILTER, CUP			001	0	0
6	16967-GA6-671	CUP, FUEL STRAINER			001	0	0
11	50319-ZB2-000	RUBBER, TANK MOUNTING			002	0	0
16	95001-45150-40	TUBE, FUEL, 4.5X150 (95001-45001-60M)			001	0	0
18	95002-02080	CLIP, TUBE (B8)			002	0	0

GX390T2


E-40-3 OTHER PARTS (4) (MUFFLER)



Z1C0E4003B


Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
2	18310-Z1C-842	MUFFLER COMP.			001	0	0
3	18320-ZC2-000	PROTECTOR, MUFFLER OUTER			001	0	0
4	18325-ZB4-000	PROTECTOR, MUFFLER INNER			001	0	0
5	18329-ZB4-000	SEAL, MUFFLER PROTECTOR			002	0	0
6	18333-ZB4-801	GASKET, EX. PIPE			001	0	0
9	18355-ZB4-630	ARRESTER, SPARK			001	0	0
10	90002-Z0T-800	SCREW, TAPPING, 4X8			001	0	0

GX390T2
E-29 TOOL (1)



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
6	89216-ZB4-000	WRENCH, PLUG			001	0	0


GX390T2
E-20-1 IGNITION COIL (2)



Z1C0E2001F


Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	30500-Z5T-003	COIL ASSY., IGNITION			001	0	0
2	30700-Z1C-813	CAP ASSY., NOISE SUPPRESSOR (NGK Y-EZD)			001	0	0
3	31512-ZE2-000	GROMMET, CORD			001	0	0
4	32110-Z5K-810	HARNESS ASSY., ENGINE WIRE (SEL)	1433583		001	0	0
4	32110-Z5T-810	HARNESS ASSY., ENGINE WIRE (SEL)		1433582	001	0	0
5	90015-883-000	BOLT, FLANGE, 6X28 (CT200)			002	0	0
8	31511-ZE3-000	CLAMPER, CORD			001	0	0
10	90013-883-000	BOLT, FLANGE, 6X12 (CT200)			001	0	0
11	31630-ZE1-013	COIL ASSY., CHARGE (1A)			001	0	0
12	90014-ZE6-000	BOLT, FLANGE, 6X35 (CT200)			002	0	0
17	90630-751-000	CLIP, PURSE LOCK			001	0	0

GX390T2
E-22 CONTROL (1)




Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
2	16555-ZE3-000	ROD, GOVERNOR			001	0	0
3	16561-ZK6-D70	SPRING, GOVERNOR			001	0	0
4	16562-ZE3-700	SPRING, THROTTLE RETURN			001	0	0
15	16584-883-300	SPRING, CONTROL ADJUSTING			001	0	0
18	90013-883-000	BOLT, FLANGE, 6X12 (CT200)			002	0	0
19	90015-Z5T-000	BOLT, GOVERNOR ARM			001	0	0
26	94050-06000	NUT, FLANGE, 6MM			001	0	0
29	16550-ZE3-700	ARM COMP., GOVERNOR			001	0	0
30	16500-Z5T-890	CONTROL ASSY.			001	0	0
31	93500-05035-0A	SCREW, PAN, 5X35			001	0	0

GX390T2
E-14-2 CARBURETOR (3)



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	16010-ZE3-701	GASKET SET			001	0	0
2	16011-ZA0-931	VALVE SET, FLOAT			001	0	0
3	16013-Z1C-003	FLOAT SET			001	0	0
4	16015-ZA0-931	CHAMBER SET, FLOAT			001	0	0
6	16016-ZH8-W01	SCREW SET			001	0	0
7	16024-124-760	SCREW SET, DRAIN			001	0	0
8	16028-ZA0-931	SCREW SET			001	0	0
9	16100-Z1C-922	CARBURETOR ASSY. (BE89W A)			001	0	0
10	16124-ZE0-005	SCREW, THROTTLE STOP			001	0	0
11	16148-141-881	CAP, CHOKE DUST			001	0	0
12	16166-Z5T-U41	NOZZLE, MAIN			001	0	0
13	16172-ZE3-W10	COLLAR, SETTING			001	0	0
14	16211-ZBH-700	INSULATOR, CARBURETOR			001	0	0
15	16221-Z5T-000	PACKING, CARBURETOR			001	0	0
16	16212-Z5T-000	PACKING, CARBURETOR INSULATOR			001	0	0
17	16230-ZE3-702	VALVE ASSY., SOLENOID			001	0	0
18	16260-ZE3-D22	STAY ASSY., MANUAL CHOKE			001	0	0
19	16261-ZE2-702	STAY COMP., SOLENOID			001	0	0
20	16262-ZE2-711	LEVER, CHOKE			001	0	0
21	16263-ZA0-000	JOINT, ROD			001	0	0
22	16264-ZE2-701	ROD, CHOKE			001	0	0
23	16265-ZE2-721	STOPPER, CHOKE ROD			001	0	0
24	16268-ZE2-721	SPRING, MANUAL CHOKE			001	0	0
26	16400-ZE2-704	DIAPHRAGM ASSY.			001	0	0
28	16613-893-000	GROMMET, CHOKE ROD			001	0	0
29	16615-893-000	GUIDE, CHOKE ROD			001	0	0
30	36135-ZF6-D41	VALVE, DASHPOT CHECK			001	0	0
31	53149-964-003	BUSH, ARM PIVOT			001	0	0
32	88911-MJ3-000	GROMMET, FENDER			001	0	0


GX390T2
E-15-5 AIR CLEANER (6)



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	17211-899-000	ELEMENT, AIR CLEANER			001	0	0
2	17220-Z23-S30	CASE COMP., AIR CLEANER			001	0	0
3	17222-Z23-H60	STAY, AIR CLEANER			001	0	0
4	17223-Z23-000	SPRING, AIR CLEANER CASE LID			002	0	0
5	17223-Z23-S30	BASE COMP., AIR CLEANER		1434006	001	0	0
5	17223-ZBH-000	BASE COMP., AIR CLEANER	1434007		001	0	0
6	17229-Z23-H60	SEAL, AIR CLEANER CASE			001	0	0
7	17231-ZBH-000	COVER, AIR CLEANER			001	0	0
8	17233-Z23-H60	SEAL, AIR CLEANER COVER			001	0	0
9	17238-ZG9-M00	COLLAR, AIR CLEANER			002	0	0
10	17238-ZE7-710	COLLAR, AIR CLEANER			001	0	0
11	90005-ZM3-000	BOLT, FLANGE, 5X18			004	0	0
12	90802-Z6L-000	CAP, SEALING			001	0	0
13	95701-06032-08	BOLT, FLANGE, 6X32			001	0	0
15	15721-Z23-H60	TUBE, BREATHER			001	0	0
18	94050-06000	NUT, FLANGE, 6MM			002	0	0

33	90431-ZE2-700	WASHER, CHOKE LEVER	001	0	0
34	90432-ZE2-700	SEAL, CHOKE LEVER	002	0	0
35	90433-ZE2-700	WASHER, THRUST, 2.7X8	001	0	0
36	90434-ZE2-700	COLLAR, LEVER	001	0	0
37	90650-SD9-003	CLIP, WIRE HARNESS	001	0	0
39	93500-05012-0A	SCREW, PAN, 5X12	002	0	0
40	93892-05012-18	SCREW-WASHER, 5X12	002	0	0
42	94103-05000	WASHER, PLAIN, 5MM	001	0	0
43	94540-02010	E-RING, 2MM	001	0	0
44	94540-04010	E-RING, 4MM	001	0	0
45	94540-07010	E-RING, 7MM	001	0	0
47	95002-02070	CLIP, TUBE (B7)	004	0	0
49	95005-35075-10	TUBE, 3.5X75 (95005-35001-10M)	001	0	0
50	95005-35130-10	TUBE, 3.5X130 (95005-35001-10M)	001	0	0
51	99101-ZH8-0950	JET, MAIN, #95	(1)	0	0
51	99101-ZH8-1000	JET, MAIN, #100	(1)	0	0
51	99101-ZH8-1020	JET, MAIN, #102	001	0	0
52	99204-ZA004-50	JET SET, PILOT, #45	001	0	0
53	16611-ZE3-D21	ROD, CHOKE CONTROL	001	0	0
54	16220-ZA0-702	SPACER COMP., CARBURETOR	001	0	0
55	17228-Z5T-000	PACKING, AIR CLEANER	001	0	0


GX390T2
E-12 FAN COVER (1)



Z1C0E1200E

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
2	19610-Z5T-800ZA	COVER COMP, FAN *R280* (R280 POWER RED)			001	0	0
2	19610-Z5T-800ZC	COVER COMP, FAN *NH1* (NH1 BLACK)			001	0	0
3	19631-Z5T-000	SHROUD			001	0	0
6	81329-567-020	GROMMET, DRAIN HOLE			001	0	0
7	90013-883-000	BOLT, FLANGE, 6X12 (CT200)			006	0	0
9	90654-SA4-003	CLIP, WIRE HARNESS, 6MM (WHITE)			002	0	0


GX390T2
E-11 RECOIL STARTER (1)



Z1C0E1100B


Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	28400-Z5T-013ZA	STARTER ASSY., RECOIL *R280* (R280 POWER RED)			001	0	0
1	28400-Z5T-013ZB	STARTER ASSY., RECOIL *NH1* (NH1 BLACK)			001	0	0
2	28410-ZE3-W01ZB	CASE COMP., RECOIL STARTER *NH1 * (NH1 BLACK)			001	0	0
2	28410-ZE3-W01ZP	CASE COMP., RECOIL STARTER *R280 * (R280 POWER RED)			001	0	0
3	28421-ZE3-W01	PULLEY, RECOIL STARTER			001	0	0
4	28422-ZE2-W01	RATCHET, STARTER			002	0	0
5	28441-ZE2-W01	SPRING, FRICTION			001	0	0
6	28442-ZE2-W01	SPRING, STARTER RETURN			001	0	0
7	28443-ZE2-W01	SPRING, RATCHET			002	0	0
8	28444-ZE2-W01	RETAINER, SPRING			001	0	0
10	28462-ZE3-W01	ROPE, RECOIL STARTER			001	0	0
11	90004-ZE2-W01	SCREW, CENTER			001	0	0
12	90008-ZE2-003	BOLT, FLANGE, 6X10		1376506	003	0	0
12	95701-06010-00	BOLT, FLANGE, 6X10	1376507		003	0	0
13	28461-Z5T-003	GRIP, STARTER			001	0	0
14	28463-Z5T-013	GRIP, REINFORCEMENT			001	0	0

GX390T2
E-7 CRANKSHAFT




Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
6	13351-Z1C-900	WEIGHT, BALANCER	1430824		001	0	0
6	13351-ZE3-010	WEIGHT, BALANCER		1430823	001	0	0
10	91001-ZF6-013	BEARING, RADIAL BALL, 6207SH			001	0	0
11	13310-ZF6-D42	CRANKSHAFT COMP.			001	0	0

GX390T2
E-9 CAMSHAFT




Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	12209-ZE8-003	SEAL, VALVE STEM			001	0	0
2	14100-Z5T-810	CAMSHAFT ASSY.	1171624	1346119	001	0	0
3	14410-Z1C-000	ROD, PUSH			002	0	0
4	14431-ZE2-010	ARM, VALVE ROCKER			002	0	0
5	14441-ZE2-000	LIFTER, VALVE			002	0	0
6	14451-Z4M-000	PIVOT, ROCKER ARM	1562506		002	0	0
6	14451-ZE1-013	PIVOT, ROCKER ARM		1562505	002	0	0
7	14568-ZE1-000	SPRING, WEIGHT RETURN	1171624		001	0	0
8	14711-Z5T-000	VALVE, IN.		1430823	001	0	0
8	14711-Z5T-900	VALVE, IN.	1430824		001	0	0
9	14721-Z5T-800	VALVE, EX. (STELLITE)			001	0	0
10	14751-Z1C-000	SPRING, VALVE			002	0	0
11	14771-Z8S-000	RETAINER, IN. VALVE SPRING			001	0	0
12	14771-Z8S-000	RETAINER, IN. VALVE SPRING (EXHAUST SIDE)			001	0	0
13	14775-ZE2-010	SEAT, VALVE SPRING			001	0	0
15	14791-Z1D-000	GUIDE, PUSH ROD			001	0	0
16	90012-ZE0-010	BOLT, PIVOT, 8MM			002	0	0
17	90206-ZE1-000	NUT, PIVOT ADJUSTING			002	0	0
18	14100-Z5T-910	CAMSHAFT COMP. (STD.)			001	0	0

GX390T2
E-16 MUFFLER (1)



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
7	18333-Z1C-901	GASKET, EX. PIPE	1430824		001	0	0
7	18333-ZF6-W01	GASKET, EX. PIPE		1430823	001	0	0
32	18330-ZE3-710	PIPE, EX.			001	0	0
33	94050-08000	NUT, FLANGE, 8MM			002	0	0


GX390T2
E-8 PISTON



FR. →
Z1C0E0800B


Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	13010-Z5R-004	RING SET, PISTON (STD.) (TEIKOKU)			001	0	0
1	13010-Z5T-003	RING SET, PISTON (STD.) (RIKEN)			001	0	0
1	13011-Z5R-004	RING SET, PISTON (0.25) (TEIKOKU)			(1)	0	0
1	13011-Z5T-003	RING SET, PISTON (0.25) (RIKEN)			(1)	0	0
1	13012-Z5R-004	RING SET, PISTON (0.50) (TEIKOKU)			(1)	0	0
1	13012-Z5T-003	RING SET, PISTON (0.50) (RIKEN)			(1)	0	0
1	13013-Z5R-004	RING SET, PISTON (0.75) (TEIKOKU)			(1)	0	0
1	13013-Z5T-003	RING SET, PISTON (0.75) (RIKEN)			(1)	0	0
2	13101-Z1C-900	PISTON (STD.)	1458490		001	0	0
2	13101-Z5T-800	PISTON (STD.)		1458489	001	0	0
2	13102-Z5T-800	PISTON (0.25)			(1)	0	0
2	13103-Z5T-800	PISTON (0.50)			(1)	0	0
2	13104-Z5T-800	PISTON (0.75)			(1)	0	0
3	13111-Z5T-000	PIN, PISTON			001	0	0
4	13200-Z1C-000	ROD ASSY., CONNECTING (STD.)		1458489	001	0	0
4	13200-Z1C-305	ROD ASSY., CONNECTING (0.25 UNDER SIZE)			(1)	0	0
4	13200-Z1C-900	ROD ASSY., CONNECTING (STD.)	1458490		001	0	0
6	90001-ZE8-000	BOLT, CONNECTING ROD			002	0	0
7	90601-ZE3-000	CLIP, PISTON PIN, 20MM			002	0	0

GX390T2
E-21 STARTER MOTOR (1)



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	31204-ZA0-003	CONTACTOR ASSY.			001	0	0
2	31206-ZE3-003	ARMATURE COMP.			001	0	0
3	31207-ZE3-003	CLUTCH COMP., OVERRUNNING			001	0	0
4	31210-ZE3-023	MOTOR UNIT, STARTER			001	0	0
5	31211-ZE2-003	BRACKET, CENTER			001	0	0
6	31212-ZE3-003	BRACKET, FR.			001	0	0
7	31213-ZE2-003	GEAR, DRIVE PINION			001	0	0
8	31215-ZE2-003	BRUSH			002	0	0
9	31218-ZE3-003	YOKE COMP.			001	0	0
10	31219-ZE2-003	SPRING, BRUSH RETURN			004	0	0
11	31222-ZE3-791	GEAR, REDUCTION			001	0	0
12	31231-ZE2-003	HOLDER, BRUSH			001	0	0
13	31232-ZE3-003	WIRE, WATER COVER			001	0	0
14	31233-ZE2-003	INSULATOR			001	0	0
15	90007-ZE2-003	BOLT-WASHER, 5X14			002	0	0
16	90110-ZE2-003	SCREW-WASHER, 4X6			001	0	0
17	91601-ZE2-003	PACKING			001	0	0
18	93892-05032-18	SCREW-WASHER, 5X32			004	0	0
19	94070-06080	NUT-WASHER, 6MM			002	0	0
20	95701-08035-08	BOLT, FLANGE, 8X35			002	0	0
21	31219-ZE3-003	SCREW-WASHER, 4X14			002	0	0


GX390T2
E-28 LABEL (1)



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
13	87114-ZH7-000	LABEL, WARNING (NOT CERTIFIED FOR SALE)			001	0	0
15	87521-Z5T-000	EMBLEM (HONDA GX390)			001	0	0
26	87594-ZB4-A00	MARK, OIL CAUTION			001	0	0


GX390T2

E-40 OTHER PARTS (1)



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
12	35100-ZB4-023	SWITCH ASSY., COMBINATION (HONDA LOCK)			001	0	0
13	35111-880-013	KEY COMP. (HONDA LOCK)			002	0	0
20	87528-898-620	MARK, CHOKE			001	0	0
21	87533-ZC0-630	MARK, AIR CLEANER (ENGLISH)			001	0	0
22	87539-898-620	MARK, EX. CAUTION (ENGLISH/FRENCH)			001	0	0
24	95701-06012-00	BOLT, FLANGE, 6X12			007	0	0
31	30561-ZB4-000	CLIP, WIRE			001	0	0
34	32130-ZE1-000	COUPLER COMP.			001	0	0
40	38220-ZE1-000	CASE COMP., FUSE			001	0	0
41	38240-VA3-900	PROTECTOR, CIRCUIT (1.0A)			001	0	0
42	38250-898-000	LENS ASSY., PROTECTOR			001	0	0
43	38251-898-000	LENS			001	0	0
44	38252-898-000	CAP, LENS			001	0	0
45	38253-898-000	SPRING, COIL			001	0	0
46	38254-898-000	HOLDER, LENS			001	0	0
48	87522-883-660	MARK, CAUTION (ENGLISH/FRENCH/SPANISH)			001	0	0
49	90101-692-000	SCREW, GLOVE BOX			001	0	0
51	94050-06000	NUT, FLANGE, 6MM			001	0	0
53	95701-06010-00	BOLT, FLANGE, 6X10			001	0	0
54	95701-08020-00	BOLT, FLANGE, 8X20			002	0	0
55	98200-30500	FUSE, BLADE (5A)			001	0	0
57	90854-ZB3-000	RUBBER, FUEL (9X15X20)			001	0	0

GX390T2
E-19 FLYWHEEL



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	19511-ZE3-000	FAN, COOLING			001	0	0
3	28451-ZE3-W01	PULLEY, STARTER			001	0	0
6	31110-Z5T-820	FLYWHEEL COMP. (SEL-LAMP)			001	0	0
7	90201-ZE3-V00	NUT, SPECIAL, 16MM			001	0	0
8	90741-ZE2-000	KEY, SPECIAL WOODRUFF, 25X18			001	0	0