



GX160H1

E-3 CYLINDER BARREL




Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	12000-Z1T-406	BARREL ASSY., CYLINDER			001	0	0
3	16510-Z1T-000	GOVERNOR ASSY.		4980664	001	0	0
4	16511-ZE1-000	WEIGHT, GOVERNOR		4980664	002	0	0
6	16513-ZE1-000	PIN, GOVERNOR WEIGHT		4980664	002	0	0
7	16531-Z1T-000	SLIDER, GOVERNOR			001	0	0
8	16541-Z1T-000	SHAFT, GOVERNOR ARM			001	0	0
9	90131-ZE1-000	BOLT, DRAIN PLUG			002	0	0
10	90451-Z1T-000	WASHER, THRUST, 6MM			001	0	0
11	90601-ZE1-000	WASHER, DRAIN PLUG, 10.2MM			002	0	0
12	90602-ZE1-000	CLIP, GOVERNOR HOLDER			001	0	0
13	91001-Z1T-003	BEARING, RADIAL BALL, 6205 (NSK)			001	0	0
13	91001-ZF1-003	BEARING, RADIAL BALL (6205TMB) (NTN)			001	0	0
13	91001-ZF1-004	BEARING, RADIAL BALL (6205SH) (KOYO)			001	0	0
14	91202-Z1T-003	OIL SEAL, 25X41X6 (ARAI)			001	0	0
15	91353-Z7E-003	O-RING, 14MM			001	0	0
16	94050-10000	NUT, FLANGE, 10MM			001	0	0
17	94101-06800	WASHER, PLAIN, 6MM			002	0	0
18	94251-08000	PIN, LOCK, 8MM			001	0	0
19	95701-06012-00	BOLT, FLANGE, 6X12			002	0	0
20	35480-Z0T-003	SWITCH ASSY., OIL LEVEL			001	0	0
21	16510-ZDL-000	GOVERNOR ASSY.	4980665		001	0	0

GX160H1
E-2 CYLINDER HEAD



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	12204-Z1T-305	GUIDE, IN. VALVE (O.S.)			001	0	0
3	12210-Z1T-405	HEAD COMP., CYLINDER			001	0	0
4	12216-ZE5-300	CLIP, VALVE GUIDE			001	0	0
5	12251-Z1T-003	GASKET, CYLINDER HEAD (GUANGZHOU LEAKLESS)			001	0	0
5	12251-Z1T-701	GASKET, CYLINDER HEAD (NINGBO SIL GASKET)			001	0	0
6	12310-ZE1-020	COVER COMP., HEAD			001	0	0
7	12312-Z1T-701	PACKING, HEAD COVER (NINGBO SIL GASKET)			001	0	0
7	12391-ZE1-000	PACKING, HEAD COVER			001	0	0
8	15721-ZH8-000	TUBE, BREATHER			001	0	0
10	90013-883-000	BOLT, FLANGE, 6X12 (CT200)			004	0	0
11	90043-ZE1-020	BOLT, STUD, 6X112			002	0	0
12	90047-ZE1-000	BOLT, STUD, 8X32			002	0	0
13	94301-10160	DOWEL PIN, 10X16			002	0	0
14	95701-08060-00	BOLT, FLANGE, 8X60			004	0	0
15	98079-55855	PLUG, SPARK (W16EPR-U) (DENSO)			(1)	0	0
15	98079-55876	PLUG, SPARK (BPR5ES) (NGK)			(1)	0	0
15	98079-56846	PLUG, SPARK (BPR6ES) (NGK)			001	0	0
15	98079-56855	PLUG, SPARK (W20EPR-U) (DENSO)			001	0	0
16	12205-Z1T-305	GUIDE, EX. VALVE (O.S.)			001	0	0


GX160H1
E-6 CRANKCASE COVER



Z1T0-E0600A

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
2	11300-Z1T-630	COVER ASSY., CRANKCASE			001	0	0
3	11381-Z1T-701	PACKING, CASE COVER (NINGBO SIL GASKET)			001	0	0
3	11381-ZH8-801	PACKING, CASE COVER (NON ASBESTOS)			001	0	0
4	15600-Z1T-000	CAP ASSY., OIL FILLER			001	0	0
5	15600-Z1T-600	CAP ASSY., OIL FILLER			001	0	0
6	15625-Z1T-000	PACKING, OIL FILLER CAP			001	0	0
7	91202-Z1T-003	OIL SEAL, 25X41X6 (ARAI)			001	0	0
8	94301-08140	DOWEL PIN, 8X14			002	0	0
9	95701-08032-00	BOLT, FLANGE, 8X32			006	0	0
10	96100-62050-00	BEARING, RADIAL BALL, 6205			001	0	0
11	15625-Z1T-000	PACKING, OIL FILLER CAP			001	0	0

GX160H1
E-20 IGNITION COIL




FR. 
Z1T0E2000

Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	30500-Z1T-023	COIL ASSY., IGNITION (TEC)		5503062	001	0	0
2	30500-Z1T-601	COIL ASSY., IGNITION (TOYO)	5503063		001	0	0
2	30500-Z1T-701	COIL ASSY., IGNITION (KOKUSAN)	4725497		001	0	0
3	30700-Z1T-003	CAP ASSY., NOISE SUPPRESSOR (TEC)		5503062	001	0	0
3	30700-Z1T-601	CAP ASSY., NOISE SUPPRESSOR (TOYO)	5503063		001	0	0
3	30700-Z1T-701	CAP ASSY., NOISE SUPPRESSOR (KOKUSAN)	4725497		001	0	0
9	32195-Z1T-701	CORD, STOP SWITCH (370MM) (KOKUSAN)	4725497		001	0	0
9	36101-ZE1-010	CORD, STOP SWITCH (370MM)			001	0	0
12	90121-952-000	BOLT, FLANGE, 6X25 (CT200)			002	0	0

GX160H1


E-11 RECOIL STARTER (1)



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
2	28410-ZH8-003YA	CASE COMP, RECOIL STARTER *R280 * (R280 POWER RED)		3327695	001	0	0
3	28421-Z0T-003	REEL, RECOIL STARTER		3327695	001	0	0
7	28442-ZH8-003	SPRING, RECOIL STARTER		3327695	001	0	0
9	28461-ZH8-013	KNOB, RECOIL STARTER		3327695	001	0	0
10	28462-ZH8-003	ROPE, RECOIL STARTER		3327695	001	0	0
12	90008-Z1T-000	BOLT, FLANGE, 6X10		3327695	003	0	0
13	28400-Z0T-003ZB	STARTER ASSY., RECOIL *R280* (R280 POWER RED)		3327695	001	0	0
14	28422-ZH8-801	RATCHET, STARTER		3327695	002	0	0
15	28431-ZH8-801	PLATE, FRICTION		3327695	001	0	0
16	28433-ZH8-801	GUIDE, RATCHET		3327695	001	0	0
17	28441-ZH8-801	SPRING, FRICTION		3327695	001	0	0
18	28443-ZH8-801	SPRING, RETURN		3327695	002	0	0
19	90003-ZH8-801	SCREW, SETTING		3327695	001	0	0

GX160H1


E-11 RECOIL STARTER (1)



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
2	28410-ZH8-003YA	CASE COMP, RECOIL STARTER *R280 * (R280 POWER RED)		3327695	001	0	0
3	28421-Z0T-003	REEL, RECOIL STARTER		3327695	001	0	0
7	28442-ZH8-003	SPRING, RECOIL STARTER		3327695	001	0	0
9	28461-ZH8-013	KNOB, RECOIL STARTER		3327695	001	0	0
10	28462-ZH8-003	ROPE, RECOIL STARTER		3327695	001	0	0
12	90008-Z1T-000	BOLT, FLANGE, 6X10		3327695	003	0	0
13	28400-Z0T-003ZB	STARTER ASSY., RECOIL *R280* (R280 POWER RED)		3327695	001	0	0
14	28422-ZH8-801	RATCHET, STARTER		3327695	002	0	0
15	28431-ZH8-801	PLATE, FRICTION		3327695	001	0	0
16	28433-ZH8-801	GUIDE, RATCHET		3327695	001	0	0
17	28441-ZH8-801	SPRING, FRICTION		3327695	001	0	0
18	28443-ZH8-801	SPRING, RETURN		3327695	002	0	0
19	90003-ZH8-801	SCREW, SETTING		3327695	001	0	0


GX160H1

E-7 CRANKSHAFT (1)



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
9	13310-Z1T-620	CRANKSHAFT COMP.			001	0	0

GX160H1
E-9 CAMSHAFT




Z1T0-E0900



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	12209-ZH8-003	SEAL, VALVE STEM			001	0	0
2	14100-Z1T-810	CAMSHAFT ASSY.			001	0	0
3	14410-ZE1-010	ROD, PUSH			002	0	0
4	14431-Z1T-000	ARM, VALVE ROCKER	5203302		002	0	0
4	14431-ZE1-000	ARM, VALVE ROCKER			002	0	0
5	14441-ZE1-010	LIFTER, VALVE			002	0	0
6	14451-Z7E-000	PIVOT, ROCKER ARM			002	0	0
7	14568-ZE1-000	SPRING, WEIGHT RETURN			001	0	0
8	14711-ZF1-000	VALVE, IN.			001	0	0
9	14721-ZE7-000	VALVE, EX.	5197368		001	0	0
9	14721-ZF1-000	VALVE, EX.		5197367	001	0	0
10	14751-ZF1-000	SPRING, VALVE			002	0	0
11	14771-Z1T-000	RETAINER, VALVE SPRING	5197368		001	0	0
11	14771-ZE1-000	RETAINER, IN. VALVE SPRING		5197367	001	0	0
12	14771-Z1T-000	RETAINER, VALVE SPRING	5197368		001	0	0
12	14773-ZE1-000	RETAINER, EX. VALVE SPRING		5197367	001	0	0
13	14781-ZE1-000	ROTATOR, VALVE		5197367	001	0	0
14	14791-ZE1-010	PLATE, PUSH ROD GUIDE			001	0	0
15	90012-ZE0-010	BOLT, PIVOT, 8MM			002	0	0
16	90206-ZE1-000	NUT, PIVOT ADJUSTING			002	0	0

GX160H1

E-8 PISTON




FR. 
Z1T0E0800B

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	13010-Z1T-701	RING SET, PISTON (STD.) (FUJIAN DONGYA MACHINERY)			001	0	0
1	13010-Z4K-004	RING SET, PISTON (STD.) (TPR)			001	0	0
1	13010-Z4P-003	RING SET, PISTON (STD.) (RIKEN)			001	0	0
1	13011-Z1T-701	RING SET, PISTON (0.25) (FUJIAN DONGYA MACHINERY)			(1)	0	0
1	13011-Z4K-004	RING SET, PISTON (0.25) (TPR)			(1)	0	0
1	13011-Z4P-003	RING SET, PISTON (0.25) (RIKEN)			(1)	0	0
1	13012-Z1T-701	RING SET, PISTON (0.50) (FUJIAN DONGYA MACHINERY)			(1)	0	0
1	13012-Z4K-004	RING SET, PISTON (0.50) (TPR)			(1)	0	0
1	13012-Z4P-003	RING SET, PISTON (0.50) (RIKEN)			(1)	0	0
1	13013-Z1T-701	RING SET, PISTON (0.75) (FUJIAN DONGYA MACHINERY)			(1)	0	0
1	13013-Z4K-004	RING SET, PISTON (0.75) (TPR)			(1)	0	0
1	13013-Z4P-003	RING SET, PISTON (0.75) (RIKEN)			(1)	0	0
2	13101-Z1T-010	PISTON (STD.)			001	0	0
2	13102-Z1T-000	PISTON (0.25)			(1)	0	0
2	13103-Z1T-000	PISTON (0.50)			(1)	0	0
2	13104-Z1T-000	PISTON (0.75)			(1)	0	0
3	13111-Z1T-000	PIN, PISTON			001	0	0
4	13200-Z1T-305	ROD ASSY., CONNECTING (UNDER SIZE)			(1)	0	0
4	13200-Z1T-600	ROD ASSY., CONNECTING (IDENT MARK Z)			001	0	0
4	13200-Z1T-610	ROD ASSY., CONNECTING	5204061		001	0	0
5	90001-Z1T-000	BOLT, CONNECTING ROD (FOR JLH)			002	0	0
6	90551-ZE1-000	CLIP, PISTON PIN, 18MM			002	0	0

GX160H1

E-11-2 RECOIL STARTER (3)



Z1T0E1102B


Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	28400-Z1T-701ZB	STARTER ASSY., RECOIL *R280* (R280 POWER RED)	3327696	3807941	001	0	0
1	28400-Z1T-702ZB	STARTER ASSY., RECOIL *R280* (R280 POWER RED)	3807942		001	0	0
2	28410-Z1T-701ZB	CASE COMP., RECOIL STARTER *R280* (R280 POWER RED)	3327696		001	0	0
3	28421-Z1T-702	REEL, RECOIL STARTER (BLACK)	3807942		001	0	0
4	28422-Z1T-701	RATCHET, STARTER	3327696		002	0	0
5	28433-Z1T-702	GUIDE, RATCHET	3807942		001	0	0
7	28442-ZH8-003	SPRING, RECOIL STARTER	3327696		001	0	0
8	28443-Z1T-701	SPRING, RETURN	3327696		002	0	0
9	28461-ZH8-013	KNOB, RECOIL STARTER	3327696		001	0	0
10	28462-Z1T-701	ROPE, RECOIL STARTER	3327696		001	0	0
11	90003-ZH8-801	SCREW, SETTING	3807942		001	0	0
12	90008-Z1T-000	BOLT, FLANGE, 6X10	3327696		003	0	0
13	28431-ZH8-801	PLATE, FRICTION	3807942		001	0	0
14	28441-ZH8-801	SPRING, FRICTION	3807942		001	0	0
15	06280-Z1T-305	STARTER SET, RECOIL	3327696	3807941	001	0	0

E-19 FLYWHEEL



<u>Refnr</u>	<u>Part Number</u>	<u>Description</u>	<u>from</u>	<u>to</u>	<u>Unit Qty.</u>	<u>Order Qty.</u>	<u>Repair Qty.</u>
1	13331-357-000	KEY, SPECIAL WOODRUFF, 25X18			001	0	0
2	19511-Z1T-000	FAN, COOLING			001	0	0
4	28451-Z1T-700	PULLEY, STARTER	3103959		001	0	0
7	31110-Z1T-003	FLYWHEEL COMP. (KOKUSAN)			001	0	0
7	31110-Z1T-004	FLYWHEEL COMP. (YUXIN)			001	0	0
10	90201-Z1T-000	NUT, SPECIAL, 14MM			001	0	0
18	28451-Z1T-000	PULLEY, STARTER		3103958	001	0	0


GX160H1
E-12 FAN COVER



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
2	19610-Z1T-000ZA	COVER COMP., FAN *R280* (R280 POWER RED)	4654074		001	0	0
2	19610-ZE1-010ZP	COVER COMP., FAN *R280 * (R280 POWER RED)		4654073	001	0	0
5	19631-Z1T-000	SHROUD			001	0	0
7	34150-ZH7-023	ALERT UNIT, OIL (IIDA)			001	0	0
9	36100-ZF6-P82	SWITCH ASSY., ENGINE STOP			001	0	0
11	90013-883-000	BOLT, FLANGE, 6X12 (CT200)			006	0	0
12	90022-888-010	BOLT, FLANGE, 6X20 (CT200)			001	0	0
14	90601-Z1T-003	CLIP, HARNESS			001	0	0
15	95701-06008-00	BOLT, FLANGE, 6X8			001	0	0
22	19611-ZDK-810	PLATE COMP., SIDE (OIL ALERT)	5287222		001	0	0
22	19611-ZH8-810	PLATE COMP., SIDE (OIL ALERT)		5287221	001	0	0

GX160H1


E-14-1 CARBURETOR (2)



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	16010-ZE1-812	GASKET SET			001	0	0
2	16011-ZE0-005	VALVE SET, FLOAT (CARBURETOR NO.)		BE65T A	001	0	0
3	16013-Z0S-B01	FLOAT SET (CARBURETOR NO.)	BE65T A	BE65T A	001	0	0
3	16013-Z1T-711	FLOAT SET (CARBURETOR NO.)	BEA4E A		001	0	0
4	16015-ZE0-831	CHAMBER SET, FLOAT			001	0	0
5	16016-ZH7-W01	SCREW SET, PILOT (CARBURETOR NO.)		BEA4E B	001	0	0
6	16024-ZE1-811	SCREW SET, DRAIN			001	0	0
7	16028-ZDK-003	SCREW SET (CARBURETOR NO.)	BEA4E C		001	0	0
7	16028-ZE0-005	SCREW SET (CARBURETOR NO.)		BEA4E B	001	0	0
8	16044-ZE0-005	CHOKE SET			001	0	0
9	16100-Z1T-711	CARBURETOR ASSY. (BEA4E A/B/C)	3394084		001	0	0
9	16100-Z1T-W51	CARBURETOR ASSY. (BE65T A)		3394083	001	0	0
10	16124-ZE0-005	SCREW, THROTTLE STOP			001	0	0
11	16166-ZDK-003	NOZZLE, MAIN (CARBURETOR NO.)	BEA4E C		001	0	0
11	16166-ZH8-W50	NOZZLE, MAIN (CARBURETOR NO.)		BEA4E B	001	0	0
12	16173-001-004	O-RING			001	0	0
13	16211-Z1T-000	INSULATOR, CARBURETOR			001	0	0
14	16212-Z1T-701	PACKING, INSULATOR (NINGBO SIL GASKET)			001	0	0
14	16212-ZH8-800	PACKING, INSULATOR			001	0	0
15	16220-ZE1-020	SPACER COMP., CARBURETOR			001	0	0
16	16221-Z1T-701	PACKING, CARBURETOR (NINGBO SIL GASKET)			001	0	0
16	16221-ZH8-801	PACKING, CARBURETOR			001	0	0
17	16610-Z1T-000	LEVER COMP., CHOKE (STD.)			001	0	0
18	16953-ZDK-003	LEVER, COCK (CARBURETOR NO.)	BEA4E C		001	0	0
18	16953-ZE1-812	LEVER, COCK (CARBURETOR NO.)		BEA4E B	001	0	0
19	16954-ZE1-812	PLATE, LEVER SETTING			001	0	0
20	16956-ZE1-811	SPRING, COCK LEVER			001	0	0
21	16957-ZE1-812	PACKING, FUEL COCK			001	0	0
22	16967-ZE0-811	CUP, FUEL STRAINER			001	0	0

GX160H1

E-22 CONTROL (1)




FR. 
Z1T0E2200C

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
2	16500-Z1T-600	CONTROL ASSY. (REMOTE)			001	0	0
3	16551-ZE0-010	ARM, GOVERNOR			001	0	0
4	16555-ZE1-000	ROD, GOVERNOR			001	0	0
5	16561-ZE1-020	SPRING, GOVERNOR			001	0	0
6	16562-ZE1-020	SPRING, THROTTLE RETURN			001	0	0
7	16571-Z1T-000	LEVER, CONTROL			001	0	0
8	16574-ZE1-000	SPRING, LEVER			001	0	0
9	16575-ZH8-000	WASHER, CONTROL LEVER			001	0	0
10	16576-891-000	HOLDER, CABLE			001	0	0
11	16578-ZE1-000	SPACER, CONTROL LEVER			001	0	0
12	16580-ZH8-813	BASE COMP., CONTROL (REMOTE)			001	0	0
13	16584-883-300	SPRING, CONTROL ADJUSTING			001	0	0
14	16592-ZE1-810	SPRING, CABLE RETURN			001	0	0
16	90013-883-000	BOLT, FLANGE, 6X12 (CT200)			002	0	0
17	90015-ZE5-010	BOLT, GOVERNOR ARM			001	0	0
19	90114-SA0-000	NUT, SELF-LOCK, 6MM			001	0	0
19	90202-Z1T-000	NUT, SELF-LOCK, 6MM			001	0	0
20	93500-05016-0A	SCREW, PAN, 5X16			001	0	0
21	93500-05025-0H	SCREW, PAN, 5X25			001	0	0
22	94050-06000	NUT, FLANGE, 6MM			001	0	0

23	93500-03006-1H	SCREW, PAN, 3X6		002	0	0
24	94305-20122	PIN, SPRING, 2X12		001	0	0
25	99101-ZDK-0650	JET, MAIN, #65 (CARBURETOR NO.)	BEA4E C	(1)	0	0
25	99101-ZDK-0680	JET, MAIN, #68 (CARBURETOR NO.)	BEA4E C	(1)	0	0
25	99101-ZDK-0700	JET, MAIN, #70 (CARBURETOR NO.)	BEA4E C	001	0	0
25	99101-ZH8-0650	JET, MAIN, #65 (CARBURETOR NO.)	BEA4E B	(1)	0	0
25	99101-ZH8-0680	JET, MAIN, #68 (CARBURETOR NO.)	BEA4E B	(1)	0	0
25	99101-ZH8-0700	JET, MAIN, #70 (CARBURETOR NO.)	BEA4E B	001	0	0
26	99204-ZE003-50	JET SET, PILOT, #35		001	0	0
27	16016-ZDK-003	SCREW SET, PILOT (CARBURETOR NO.)	BEA4E C	001	0	0
38	16011-Z1T-711	VALVE SET, FLOAT (CARBURETOR NO.)	BEA4E A	001	0	0
39	16141-Z0S-003	WASHER, PLAIN (6.2X10.7 DRAIN)		001	0	0

GX160H1
E-26-2 REDUCTION (3)




Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	21521-883-741	CASE, REDUCTION			001	0	0
2	21591-ZH8-740	PACKING, REDUCTION CASE			001	0	0
3	21621-883-742	COVER, REDUCTION			001	0	0
4	21692-ZH7-000	PACKING, REDUCTION COVER			001	0	0
5	23710-883-740	SHAFT, P.T.O. (86T)			001	0	0
6	90002-Z1T-740	BOLT, BREATHING			001	0	0
7	90131-883-000	BOLT, DRAIN PLUG, 12X15			001	0	0
8	91202-Z1T-003	OIL SEAL, 25X41X6 (ARAI)			001	0	0
9	94109-12000	WASHER, DRAIN PLUG, 12MM			001	0	0
10	95701-08032-08	BOLT, FLANGE, 8X32			004	0	0
11	95701-08035-00	BOLT, FLANGE, 8X35			004	0	0
12	96100-62040-00	BEARING, RADIAL BALL, 6204			001	0	0
13	96100-63050-00	BEARING, RADIAL BALL, 6305			001	0	0

	GX160H1
	E-15 AIR CLEANER (1)

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	16271-ZE1-000	PACKING, ELBOW			001	0	0
2	17210-ZE1-822	ELEMENT, AIR CLEANER (DUAL)			001	0	0
3	17218-ZE1-821	FILTER, OUTER			001	0	0
4	17230-ZE1-820	COVER, AIR CLEANER (DUAL)			001	0	0
5	17232-891-000	GROMMET, AIR CLEANER			001	0	0
7	17238-ZE7-010	COLLAR, AIR CLEANER			002	0	0
8	17239-ZE1-000	COLLAR B, AIR CLEANER			001	0	0
9	17410-Z1T-000	ELBOW COMP., AIR CLEANER		3599091	001	0	0
9	17410-Z1T-010	ELBOW COMP., AIR CLEANER	3599092		001	0	0
10	90325-044-000	NUT, TOOL BOX SETTING			002	0	0
11	94050-06000	NUT, FLANGE, 6MM			002	0	0
12	95701-06020-00	BOLT, FLANGE, 6X20			001	0	0
13	17210-Z1T-621	ELEMENT, AIR CLEANER (DUAL)	4452456		001	0	0

GX160H1
E-16 MUFFLER (1)




FR. 
 Z1T0-E1600

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	18310-Z1T-000	MUFFLER COMP.		3622446	001	0	0
1	18310-Z1T-010	MUFFLER COMP.	3622447		001	0	0
1	18310-ZH8-810	MUFFLER COMP. (ARRESTER)			(1)	0	0
2	18320-Z1T-010	PROTECTOR, MUFFLER (STD.)			001	0	0
4	18355-ZE1-000	ARRESTER, SPARK			(1)	0	0
5	18381-Z1T-003	GASKET, MUFFLER			001	0	0
5	18381-Z1T-701	GASKET, MUFFLER (NINGBO SIL GASKET)			001	0	0
8	90050-ZE1-000	SCREW, TAPPING, 5X8			004	0	0
9	90055-ZE1-000	SCREW, TAPPING, 4X6			(1)	0	0
10	94001-08000-0S	NUT, HEX., 8MM			002	0	0

GX160H1


E-22 CONTROL (1)



FR. 
Z1T0E2200C

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
2	16500-Z1T-600	CONTROL ASSY. (REMOTE)			001	0	0
3	16551-ZE0-010	ARM, GOVERNOR			001	0	0
4	16555-ZE1-000	ROD, GOVERNOR			001	0	0
5	16561-ZE1-020	SPRING, GOVERNOR			001	0	0
6	16562-ZE1-020	SPRING, THROTTLE RETURN			001	0	0
7	16571-Z1T-000	LEVER, CONTROL			001	0	0
8	16574-ZE1-000	SPRING, LEVER			001	0	0
9	16575-ZH8-000	WASHER, CONTROL LEVER			001	0	0
10	16576-891-000	HOLDER, CABLE			001	0	0
11	16578-ZE1-000	SPACER, CONTROL LEVER			001	0	0
12	16580-ZH8-813	BASE COMP., CONTROL (REMOTE)			001	0	0
13	16584-883-300	SPRING, CONTROL ADJUSTING			001	0	0
14	16592-ZE1-810	SPRING, CABLE RETURN			001	0	0
16	90013-883-000	BOLT, FLANGE, 6X12 (CT200)			002	0	0
17	90015-ZE5-010	BOLT, GOVERNOR ARM			001	0	0
19	90114-SA0-000	NUT, SELF-LOCK, 6MM			001	0	0
19	90202-Z1T-000	NUT, SELF-LOCK, 6MM			001	0	0
20	93500-05016-0A	SCREW, PAN, 5X16			001	0	0
21	93500-05025-0H	SCREW, PAN, 5X25			001	0	0
22	94050-06000	NUT, FLANGE, 6MM			001	0	0


GX160H1
E-28 LABEL/TOOL



Z1T0E2800J

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
3	87521-ZH8-040	EMBLEM (GX160)			001	0	0
5	87522-Z1T-G21	LABEL, CAUTION			001	0	0
6	87528-ZE1-810	MARK, CHOKE			001	0	0
8	87532-ZH8-810	MARK, OIL ALERT (ENGLISH)			001	0	0
13	87114-ZH7-000	LABEL, WARNING (NOT CERTIFIED FOR SALE)			001	0	0

GX160H1
E-6 CRANKCASE COVER



Z1T0-E0600A

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
2	11300-Z1T-630	COVER ASSY., CRANKCASE			001	0	0
3	11381-Z1T-701	PACKING, CASE COVER (NINGBO SIL GASKET)			001	0	0
3	11381-ZH8-801	PACKING, CASE COVER (NON ASBESTOS)			001	0	0
4	15600-Z1T-000	CAP ASSY., OIL FILLER			001	0	0
5	15600-Z1T-600	CAP ASSY., OIL FILLER			001	0	0
6	15625-Z1T-000	PACKING, OIL FILLER CAP			001	0	0
7	91202-Z1T-003	OIL SEAL, 25X41X6 (ARAI)			001	0	0
8	94301-08140	DOWEL PIN, 8X14			002	0	0
9	95701-08032-00	BOLT, FLANGE, 8X32			006	0	0
10	96100-62050-00	BEARING, RADIAL BALL, 6205			001	0	0
11	15625-Z1T-000	PACKING, OIL FILLER CAP			001	0	0