





Spare parts list Generator **GSEm 6000 SB**





No	Order Code	Name	Quantity
1	8811000001123	Frame Assembly	1
2	8811000001124	Clamp	1
3	8811000001125	Fuel Switch	1
4	8811000001126	Washer, $\phi 6.5 \times 2 \times \phi 25$	4
5	8811000001127	Bolt, M6x25	4
6	8811000001128	Fuel Cap	1
7	8811000001129	Fuel Tank	1
8	8811000001130	Fuel Meter	1
9	8811000001131	Oily Sense Clip	1
10	8811000001132	Engine	1
11	8811000001133	Plug	1
12	8811000001134	Air Filter Bracket	1
13	8811000001135	Nut, M6	3
14	8811000001136	Nut, M5	2
15	8811000001137	Washer, $\phi 5$	3
16	8811000001138	Washer, $\phi 5$	3
17	8811000001139	Bolt, M5x198	2
18	8811000001140	Bolt, M8x16	6
19	8811000001141	Muffler Support	1
20	8811000001142	Bolt, M8x32	2
21	8811000001143	Washer, $\phi 8$	2
22	8811000001144	Gasket, Muffler	1
23	8811000001145	Muffler	1
24	8811000001146	Bolt, M6x12	6
25	8811000001147	Brush	1
26	8811000001148	Bolt, M5x18	3
27	8811000001149	Bolt, M5x14	6
28	8811000001150	End Cover	1
29	8811000001151	Voltage Regulator	1
30	8811000001152	Bolt, M6x165	4
31	8811000001153	Rear Bracket	1
32	8811000001154	Nut, M10x1.25	4
33	8811000001155	Damping Pad Guard	1
34	8811000001156	Circlip	2
35	8811000001157	Damping Pad	2
36	8811000001158	Nut, M8	4
37	8811000001159	Bolt, M10x1.25x250	1
38	8811000001160	Washer, $\phi 10$	1
39	8811000001161	Washer, $\phi 10$	1
40	8811000001162	Alternator	1
41	8811000001163	Clip	1
42	8811000001164	Bolt, M5x10	3
43	8811000001165	Crankcase Cover Shield	1

44	8811000001166	Damping Pad	2
45	8811000001167	Bolt, M10×1.25×40	2
46	8811000001168	Gasket, Drain Bolt	4
47	8811000001169	Control Panel	1
48	8811000001170	Tire	2
49	8811000001171	Binder Plate	1
50	8811000001172	Battery	1
51	8811000001173	Anode Wire	1
52	8811000001174	Cathode Wire	1
53	8811000001175	Pin, φ8×55	2
54	8811000001176	Circlip	2
55	8811000001177	Handle	2
56	8811000001178	Support Base	1
57	8811000001179	Support Base	2
58	8811000001180	Damping Pad	2
59	8811000001181	Bolt, M6×18	2
60	8811000001182	Nut, M8	2
61	8811000001183	Pin, φ16×100	2
62	8811000001184	Washer, φ17.5×3×φ30	2



No	Order Code	Name	Quantity
1	8811000001185	Bolt, M6x16	7
2	8811000001186	Valve Cover	1
3	8811000001187	Breather Hose	1
4	8811000001188	Gasket, Valve Cov	1
5	8811000001189	Rocker Arm Assen	2
6	8811000001190	Rocker Arm Base	1
7	8811000001191	Valve Locker	4
8	8811000001192	Valve Adjust Cap,	2
9	8811000001193	Valve Spring Seat	2
10	8811000001194	Valve Spring	2
11	8811000001195	Intake Valve Seal	1
12	8811000001196	Valve Spring Seat	2
13	8811000001197	Bolt, M10x1.25x87	4
14	8811000001198	Cylinder Head	1
15	8811000001199	Spark Plug	1
16	8811000001200	Stud, M8x35	2
17	8811000001201	Gasket, Muffler	1
18	8811000001202	Exhaust Pipe	1
19	8811000001203	Nut, M8	2
20	8811000001204	Shroud	1
21	8811000001205	Bolt, M6x10	1
22	8811000001206	Stud, M6-8x104	2
23	8811000001207	Gasket, Carbureto	1
24	8811000001208	Insulator	1
25	8811000001209	Gasket, Carbureto	1
26	8811000001210	Carburetor	1
27	8811000001211	Gasket, Air Filter	1
28	8811000001212	Air Filter Assembly	1
29	8811000001213	Air Filter Clip	2
30	8811000001214	Air Filter Base	1
31	8811000001215	Gasket, Air Filter	1
32	8811000001216	Air Filter Baffle	1
33	8811000001217	Air Filter Element	1
34	8811000001218	Air Filter Cover	1
35	8811000001219	Nut, M6	2
36	8811000001220	Gasket, Cylinder H	1
37	8811000001221	Pin, φ12x20	2
38	8811000001222	Push Rod	2
39	8811000001223	Tappet	2
40	8811000001224	Exhaust Valve	1
41	8811000001225	Intake Vavle	1
42	8811000001226	Piston Ring Set	1
43	8811000001227	Circlip	2

44	8811000001228	Piston Pin	1
45	8811000001229	Piston	1
46	8811000001230	Connecting Rod As	1
47	8811000001231	Governor Gear Bra	1
48	8811000001232	Bolt, M6×12	8
49	8811000001233	Oil Sensor	1
50	8811000001234	Bearing, TM6207	1
51	8811000001235	Crankshaft	1
52	8811000001236	Woodruff Key	1
53	8811000001237	Camshaft	1
54	8811000001238	Washer, φ16.2×0.3	1
55	8811000001239	Pin, φ8×12	2
56	8811000001240	Gasket, Crankcase	1
57	8811000001241	Crankcase Cover	1
58	8811000001242	Oil Seal, φ35×φ52	1
59	8811000001243	Bolt, M8×38	7
60	8811000001244	Dipstick	1
61	8811000001245	Dipstick	1
62	8811000001246	O-Ring, Dipstick	1
63	8811000001247	Governor Gear	1
64	8811000001248	Bearing, 6202	2
65	8811000001249	Balance Shaft	1
66	8811000001250	Electric Starter	1
67	8811000001251	Crankcase	1
68	8811000001252	Governor Gear Sh	1
69	8811000001253	Washer, φ8×0.8×φ	1
70	8811000001254	Oil Seal, φ8×φ14×	1
71	8811000001255	Cotter Pin	1
72	8811000001256	Governor Lever	1
73	8811000001257	Fuel Hose, φ4×φ10	1
74	8811000001258	Clamp	1
75	8811000001259	Governor Spring	1
76	8811000001260	Throttle Linkage	1
77	8811000001261	Idle Spring	1
78	8811000001262	Clip	1
79	8811000001263	Bolt, M8×35	2
80	8811000001264	Earth Bolt	2
81	8811000001265	Washer, φ12×2×φ	2
82	8811000001266	Wire Board	1
83	8811000001267	Bolt, M6×8	1
84	8811000001268	Ignition Module	1
85	8811000001269	Bolt, M6×28	4
86	8811000001270	Clip	1
87	8811000001271	Bush, φ8×φ12×8	1

88	8811000001272	Charging Coil	1
89	8811000001273	Oil Seal, $\phi 35 \times \phi 52$	1
90	8811000001274	Flywheel	1
91	8811000001275	Cooling Fan	1
92	8811000001276	Starter Cup	1
93	8811000001277	Nut, M16x1.5	1
94	8811000001278	Recoil Starter	1
95	8811000001279	Blower Housing	1
96	8811000001280	Recoil Starter	1
97	8811000001281	Washer, $\phi 6$	3
98	8811000001282	Bolt, M6x10	3