





Spare parts list Generator **GSEm 7000 SBE**





No.	Order Code	Name	Quantity
1	8811000001289	Frame Assembly	1
2	8811000001290		1
3	8811000001291	Fuel Switch	1
4	8811000001292	Fuel Tank	1
5	8811000001293	Fuel Meter	1
6	8811000001294	Oily Sense Clip	1
7	8811000001295	Washer, $\phi 6.5 \times 2 \times \phi 25$	4
8	8811000001296	Bolt, M6x25	4
9	8811000001297	Fuel Cap	1
10	8811000001298	Engine	1
11	8811000001299	Plug	1
12	8811000001300	Air Filter Bracket	1
13	8811000001301	Nut, M6	2
14	8811000001302	Nut, M5	2
15	8811000001303	Washer, $\phi 5$	3
16	8811000001304	Washer, $\phi 5$	3
17	8811000001305	Bolt, M5x198	2
18	8811000001306	Bolt, M8x16	2
19	8811000001307		1
20	8811000001308	Bolt, M8x32	2
21	8811000001309	Washer, $\phi 8$	2
22	8811000001310	Gasket, Muffler	1
23	8811000001311	Muffler	1
24	8811000001312	Bolt, M6x12	6
25	8811000001313	Brush	1
26	8811000001314	Bolt, M5x18	3
27	8811000001315	Bolt, M5x14	7
28	8811000001316	End Cover	1
29	8811000001317	Voltage Regulator	1
30	8811000001318	Bolt, M6x165	4
31	8811000001319	Rear Bracket	1
32	8811000001320	Nut, M10x1.25	4
33	8811000001321		1
34	8811000001322	Damping Pad	2
35	8811000001323	Nut, M8	4
36	8811000001324	Bolt, M10x1.25x250	1
37	8811000001325	Washer, $\phi 10$	1
38	8811000001326	Washer, $\phi 10$	1
39	8811000001327	Alternator	1
40	8811000001328	Clip	1
41	8811000001329	Bolt, M5x10	3
42	8811000001330	Crankcase Cover Shield	1
43	8811000001331	Damping Pad	2

44	8811000001332	Bolt, M10×1.25×40	2
45	8811000001333		1
46	8811000001334	Binder Plate	1
47	8811000001335	Battery	1
48	8811000001336	Anode Wire	1
49	8811000001337	Cathode Wire	1
50	8811000001338	Gasket, Drain Bolt	4
51	8811000001339	Control Panel	1
52	8811000001340	Washer, φ17.5×3×φ30	2
53	8811000001341	Tire	2
54	8811000001342	Nut, M8	2
55	8811000001343	Support Base	1
56	8811000001344	Support Base	1
57	8811000001345	Damping Pad	2
58	8811000001346	Bolt, M6×18	2
59	8811000001347	Nut, M6	2
60	8811000001348	Bolt, M8×16	2
61	8811000001349	Pin, φ8×55	2
62	8811000001350	Circlip	2
63	8811000001351	Handle	2
64	8811000001352	Pin, φ16×100	2



NO.	Order Code	Name	Quantity
1	8811000001539	Bolt, M6x16	7
2	8811000001540	Valve Cover	1
3	8811000001541	Breather Hose	1
4	8811000001542	Gasket, Valve Cover	1
5	8811000001543	Rocker Arm Assembly	2
6	8811000001544	Rocker Arm Base	1
7	8811000001545	Valve Locker	4
8	8811000001546	Valve Adjust Cap, Exha	2
9	8811000001547	Valve Spring Seat	2
10	8811000001548	Valve Spring	2
11	8811000001549	Intake Valve Seal	1
12	8811000001550	Valve Spring Seat	2
13	8811000001551	Bolt, M10x1.25x87	4
14	8811000001552	Cylinder Head	1
15	8811000001553	Spark Plug	1
16	8811000001554	Stud, M8x35	2
17	8811000001555	Gasket, Muffler	1
18	8811000001556	Exhaust Pipe	1
19	8811000001557	Nut, M8	2
20	8811000001558	Shroud	1
21	8811000001559	Stud, M6-8x110	2
22	8811000001560	Gasket, Carburetor Insu	1
23	8811000001561	Insulator	1
24	8811000001562	Gasket, Carburetor	1
25	8811000001563	Carburetor	1
26	8811000001564	Gasket, Air Filter	2
27	8811000001565	Air Filter Assembly	1
28	8811000001566	Air Filter Clip	2
29	8811000001567	Air Filter Base	1
30	8811000001568	Gasket, Air Filter	1
31	8811000001569	Air Filter Baffle	1
32	8811000001570	Air Filter Element	1
33	8811000001571	Air Filter Cover	1
34	8811000001572	Nut, M6	2
35	8811000001573	Gasket, Cylinder Head	1
36	8811000001574	Pin, φ12x20	2
37	8811000001575	Push Rod	2
38	8811000001576	Tappet	2
39	8811000001577	Exhaust Valve	1
40	8811000001578	Intake Vavle	1
41	8811000001579	Piston Ring Set	1
42	8811000001580	Circlip	2
43	8811000001581	Piston Pin	1

44	8811000001582	Piston	1
45	8811000001583	Connecting Rod Assem	1
46	8811000001584	Governor Gear Bracket	1
47	8811000001585	Bolt, M6x12	8
48	8811000001586	Oil Sensor	1
49	8811000001587	Bearing, TM6207	1
50	8811000001588	Crankshaft	1
51	8811000001589	Woodruff Key	1
52	8811000001590	Camshaft	1
53	8811000001591	Washer, $\phi 16.2 \times 0.3 \times \phi 2$	1
54	8811000001592	Pin, $\phi 8 \times 12$	2
55	8811000001593	Gasket, Crankcase	1
56	8811000001594	Crankcase Cover	1
57	8811000001595	Oil Seal, $\phi 35 \times \phi 52 \times 7$	1
58	8811000001596	Bolt, M8x38	7
59	8811000001597	Dipstick	1
60	8811000001598	Dipstick	1
61	8811000001599	O-Ring, Dipstick	1
62	8811000001600	Governor Gear	1
63	8811000001601	Bearing, 6202	2
64	8811000001602	Balance Shaft	1
65	8811000001603	Electric Starter	1
66	8811000001604	Crankcase	1
67	8811000001605	Governor Gear Shaft	1
68	8811000001606	Washer, $\phi 8 \times 0.8 \times \phi 20$	1
69	8811000001607	Oil Seal, $\phi 8 \times \phi 14 \times 4$	1
70	8811000001608	Cotter Pin	1
71	8811000001609	Governor Lever	1
72	8811000001610	Fuel Hose, $\phi 4 \times \phi 10 \times 19$	1
73	8811000001611	Clamp	1
74	8811000001612	Governor Spring	1
75	8811000001613	Throttle Linkage	1
76	8811000001614	Idle Spring	1
77	8811000001615	Clip	1
78	8811000001616	Temperature Sensor	1
79	8811000001617	Washer, $\phi 12 \times 2 \times \phi 20$	2
80	8811000001618	Earth Bolt	2
81	8811000001619	Bolt, M8x35	2
82	8811000001620	Wire Board	1
83	8811000001621	Bolt, M6x8	1
84	8811000001622	Bush, $\phi 8 \times \phi 12 \times 8$	1
85	8811000001623	Charging Coil	1
86	8811000001624	Bolt, M6x28	4
87	8811000001625	Ignition Module	1

88	8811000001626	Clip	1
89	8811000001627	Oil Seal, $\phi 35 \times \phi 52 \times 7$	1
90	8811000001628	Flywheel	1
91	8811000001629	Cooling Fan	1
92	8811000001630	Starter Cup	1
93	8811000001631	Nut, M16×1.5	1
94	8811000001632	Recoil Starter	1
95	8811000001633	Blower Housing	1
96	8811000001634	Recoil Starter	1
97	8811000001635	Washer, $\phi 6$	3
98	8811000001636	Bolt, M6×10	3
99	8811000001637	Screw, M4×8	2
100	8811000001284	Stepping Motor Cover	1
101	8811000001285	Stepping Motor	1
102	8811000001286	Stepping Motor Base	1
103	8811000001287	Guide Clamp	1
104	8811000001288	Spring	1