



EU70ISN

E-3 CYLINDER BARREL



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	12000-ZF6-Q20	BARREL ASSY., CYLINDER			001	0	0
2	19645-Z11-000	SHROUD COMP, ENGINE			001	0	0
3	35480-ZF6-003	SWITCH ASSY., OIL LEVEL			001	0	0
4	90045-ZG1-750	BOLT, STUD, 6X30			002	0	0
5	90121-952-000	BOLT, FLANGE, 6X25 (CT200)			001	0	0
6	90131-883-000	BOLT, DRAIN PLUG, 12X15			001	0	0
7	90674-ZV1-003	BAND, CABLE			001	0	0
8	91201-Z1C-003	OIL SEAL, 35X52X8 (NOK)			001	0	0
9	91353-671-004	O-RING, 14MM (NOK)			001	0	0
10	94050-10080	NUT, FLANGE, 10MM			001	0	0
11	94109-12000	WASHER, DRAIN PLUG, 12MM			001	0	0
12	95701-06012-08	BOLT, FLANGE, 6X12			002	0	0
13	96100-62020-00	BEARING, RADIAL BALL, 6202			001	0	0


EU70ISN
E-2 CYLINDER HEAD



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	12204-ZE2-306	GUIDE, IN. VALVE (O.S.)			001	0	0
2	12205-ZK6-305	GUIDE, EX. VALVE (O.S.)			001	0	0
3	12210-Z1C-406	HEAD COMP., CYLINDER			001	0	0
4	12216-ZE2-300	CLIP, VALVE GUIDE			001	0	0
5	12251-Z5T-003	GASKET, CYLINDER HEAD (NIPPON LEAKLESS)			001	0	0
6	12310-ZE3-791	COVER COMP., HEAD (BREATHER TUBE JOINT)			001	0	0
7	12391-ZE2-020	PACKING, HEAD COVER			001	0	0
8	15721-Z1C-C00	TUBE, BREATHER			001	0	0
9	18331-Z1C-C00	PIPE, EX.			001	0	0
10	18333-Z1C-901	GASKET, EX. PIPE			001	0	0
11	35655-Z1C-C01	SENSOR, OXYGEN			001	0	0
12	35657-Z1C-C01	CORD COMP., OXYGEN SENSOR			001	0	0
13	35673-ZF6-F42	SENSOR ASSY., TEMPERATURE			001	0	0
14	90014-Z5T-000	BOLT, HEAD COVER			001	0	0
15	90042-ZK6-E40	BOLT, STUD, 8X126.5			002	0	0
16	90441-ZE2-010	WASHER COMP., HEAD COVER			001	0	0
17	92900-08032-0E	BOLT, STUD, 8X32			002	0	0
18	94050-08080	NUT, FLANGE, 8MM			002	0	0
19	94102-08800	WASHER, PLAIN, 8MM			001	0	0
20	94301-12200	DOWEL PIN, 12X20			002	0	0
21	95701-10080-00	BOLT, FLANGE, 10X80			004	0	0
22	98079-56846	PLUG, SPARK (BPR6ES) (NGK)			001	0	0
22	98079-56876	PLUG, SPARK (BPR6ES) (NGK)			001	0	0

EU70ISN


E-3 CYLINDER BARREL



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	12000-ZF6-Q20	BARREL ASSY., CYLINDER			001	0	0
2	19645-Z11-000	SHROUD COMP, ENGINE			001	0	0
3	35480-ZF6-003	SWITCH ASSY., OIL LEVEL			001	0	0
4	90045-ZG1-750	BOLT, STUD, 6X30			002	0	0
5	90121-952-000	BOLT, FLANGE, 6X25 (CT200)			001	0	0
6	90131-883-000	BOLT, DRAIN PLUG, 12X15			001	0	0
7	90674-ZV1-003	BAND, CABLE			001	0	0
8	91201-Z1C-003	OIL SEAL, 35X52X8 (NOK)			001	0	0
9	91353-671-004	O-RING, 14MM (NOK)			001	0	0
10	94050-10080	NUT, FLANGE, 10MM			001	0	0
11	94109-12000	WASHER, DRAIN PLUG, 12MM			001	0	0
12	95701-06012-08	BOLT, FLANGE, 6X12			002	0	0
13	96100-62020-00	BEARING, RADIAL BALL, 6202			001	0	0

EU70ISN

E-7 CRANKSHAFT




FR. 
Z373E0700

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	13310-ZF6-F42	CRANKSHAFT COMP.			001	0	0
2	13351-Z1C-900	WEIGHT, BALANCER			001	0	0
3	90741-ZE2-000	KEY, SPECIAL WOODRUFF, 25X18			001	0	0
4	91001-ZF6-013	BEARING, RADIAL BALL, 6207SH			001	0	0

EU70ISN

F-15 MUFFLER




Z373F1500


Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	18318-Z25-R50	SEPARATOR, MUFFLER INNER			001	0	0
2	18320-Z25-000ZA	PROTECTOR COMP., MUFFLER OUTER *NH105* (NH105 MAT BLACK(#15-#20))			001	0	0
3	18322-Z25-000	SEAL, 10X5X785			002	0	0
4	18325-Z11-R30	PROTECTOR COMP., MUFFLER INNER			001	0	0
5	18329-Z25-000	SEAL, MUFFLER PROTECTOR			002	0	0
6	18333-ZB7-800	GASKET, EX. PIPE			001	0	0
7	18355-Z11-A30	ARRESTER, SPARK			001	0	0
8	18376-Z11-A60	INSULATOR, MUFFLER PROTECTOR (A)			001	0	0
9	18377-Z25-000	INSULATOR, MUFFLER PROTECTOR (B)			001	0	0
10	18378-Z25-000	INSULATOR, MUFFLER PROTECTOR (C)			001	0	0
11	18390-Z25-000	PIPE COMP., EX. TAIL			001	0	0
12	18510-Z25-000	GUIDE COMP., EX. AIR			001	0	0
13	18710-Z37-000	MUFFLER COMP.			001	0	0
14	50388-Z11-000	RUBBER, STOPPER			002	0	0
15	90013-883-000	BOLT, FLANGE, 6X12 (CT200)			002	0	0
16	91554-Z25-000	COLLAR, MUFFLER			002	0	0
17	93500-05016-4J	SCREW, PAN, 5X16			002	0	0
18	94050-06070	NUT, FLANGE, 6MM			006	0	0
19	94050-08080	NUT, FLANGE, 8MM			002	0	0
20	95701-08016-08	BOLT, FLANGE, 8X16			002	0	0
21	95701-08040-08	BOLT, FLANGE, 8X40			002	0	0

EU70ISN

F-14 AIR CLEANER




Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	17203-ZY1-000	TRAP, FLAME			001	0	0
2	17211-Z3S-003	ELEMENT, AIR CLEANER			001	0	0
3	17212-Z0A-010	GRID, AIR CLEANER			001	0	0
4	17218-Z0A-810	FILTER, OUTER			001	0	0
5	17220-Z37-000	CASE COMP., AIR CLEANER			001	0	0
6	17229-Z25-000	SEAL, AIR CLEANER CHAMBER			001	0	0
7	17231-Z37-000	COVER, AIR CLEANER			001	0	0
8	17232-Z25-000	RUBBER, AIR CLEANER			001	0	0
9	17233-Z37-000	BRACKET, AIR CLEANER			001	0	0
10	17252-Z37-000	SEAL, AIR CLEANER			002	0	0
11	17270-Z25-000	CASE COMP., AIR CLEANER CHAMBER			001	0	0
12	17273-Z25-010	COVER, AIR CLEANER CHAMBER			001	0	0
13	17274-Z25-000	TUBE, AIR CLEANER CONNECTING			001	0	0
14	63232-Z37-000	LEVER, FASTENER			002	0	0
15	63237-Z37-000	SPRING, FASTENER WIRE			002	0	0
16	90014-952-000	BOLT, FLANGE, 6X14 (CT200)			003	0	0
17	90659-Z35-000	CLAMP, CASE			004	0	0
18	90754-ZY9-000	PIN, 5X44.5			002	0	0
19	90852-Z23-F10	CAP, SEALING			001	0	0
20	94050-06080	NUT, FLANGE, 6MM			003	0	0
21	94540-04029	E-RING, 4MM			002	0	0
22	95018-54250	BAND, AIR CLEANER CONNECTING TUBE (54)			002	0	0
23	95701-06022-08	BOLT, FLANGE, 6X22			003	0	0

EU70ISN
E-9 CAMSHAFT**FR.**
Z373E0900

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	12209-ZE8-003	SEAL, VALVE STEM			001	0	0
2	14100-Z5T-910	CAMSHAFT COMP. (STD.)			001	0	0
3	14410-Z1C-000	ROD, PUSH			002	0	0
4	14431-ZE2-010	ARM, VALVE ROCKER			002	0	0
5	14441-ZE2-000	LIFTER, VALVE			002	0	0
6	14451-Z4M-000	PIVOT, ROCKER ARM			002	0	0
7	14711-Z1C-810	VALVE, IN.			001	0	0
8	14721-Z1C-C00	VALVE, EX. (FI)			001	0	0
9	14751-Z1C-000	SPRING, VALVE			002	0	0
10	14771-Z8S-000	RETAINER, IN. VALVE SPRING			002	0	0
11	14775-ZE2-010	SEAT, VALVE SPRING			001	0	0
12	14791-Z1D-000	GUIDE, PUSH ROD			001	0	0
13	90012-ZE0-010	BOLT, PIVOT, 8MM			002	0	0
14	90206-ZE1-000	NUT, PIVOT ADJUSTING			002	0	0

	EU70ISN
	E-19 FLYWHEEL




Z373E1900

Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	31110-ZF6-F40	FLYWHEEL COMP.			001	0	0
2	90201-ZE3-V00	NUT, SPECIAL, 16MM			001	0	0
3	90473-ZF6-F40	WASHER, FLYWHEEL			001	0	0
4	90741-ZE2-000	KEY, SPECIAL WOODRUFF, 25X18			001	0	0

EU70ISN


E-14 THROTTLE BODY



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	16080-KPH-701	BOLT, FLANGE, 5X20			002	0	0
2	16105-Z1C-C00	HOLDER, COUPLER			001	0	0
3	16211-Z1C-C00	INSULATOR, THROTTLE BODY			001	0	0
4	16212-Z5T-000	PACKING, CARBURETOR INSULATOR			001	0	0
5	16220-ZA0-702	SPACER COMP, CARBURETOR			001	0	0
6	16221-Z1C-C00	PACKING, THROTTLE BODY			001	0	0
7	16269-Z1C-D90	PACKING, AIR CLEANER			001	0	0
8	16400-Z1C-C01	THROTTLE BODY ASSY. (BLH0A A)			001	0	0
9	16450-Z1C-C01	INJECTOR ASSY., FUEL			001	0	0
10	16472-KPC-D50	RING, SEAL			001	0	0
11	16614-Z2E-003	GEAR, MIDDLE			001	0	0
12	16646-Z1C-C01	COVER ASSY., MOTOR			001	0	0
13	17560-GGL-J00	JOINT COMP., INJECTOR			001	0	0
14	91301-KZL-931	O-RING, 6.3X2.2			001	0	0

EU70ISN


F-2-4 CONTROL PANEL (5)



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	31426-ZA8-761	PLATE, CONSENT SETTING			002	0	0
2	31426-ZB7-691	PLATE SET, CONSENT			001	0	0
3	32100-Z37-A60	HARNESS ASSY., MAIN WIRE			001	0	0
4	32118-Z37-A60	SHEET, WATER PROOF			001	0	0
5	32138-Z07-E60	COVER, SOCKET			002	0	0
6	32139-Z37-A60	SOCKET, COMPOSITE			002	0	0
7	32150-Z37-A60	HARNESS ASSY., CONTROL WIRE			001	0	0
8	32196-Z25-A60	CORD ASSY., SUB (A)			001	0	0
9	32197-Z37-A60	CORD ASSY., SUB (B)			002	0	0
10	32330-Z11-A90	RECEPTACLE (16A/240V)			001	0	0
11	32331-Z25-A60	RECEPTACLE (16A-250V)			002	0	0
12	32335-875-610	PACKING, RECEPTACLE			002	0	0
13	32335-Z11-A90	PACKING			001	0	0
14	32345-Z37-A60	PANEL COMP., CONTROL			001	0	0
16	32366-Z37-A60	MARK, PANEL			001	0	0
17	32727-PE1-660	BAND, TUBE			001	0	0
18	34110-Z37-A61	CONTROL UNIT, GENERATOR		1112493	001	0	0
18	34110-Z37-A62	CONTROL UNIT, GENERATOR	1112494		001	0	0
19	35100-Z37-A31	SWITCH ASSY., COMBINATION			001	0	0
20	35110-766-003	KEY ASSY., COMBINATION SWITCH (RED)			002	0	0
21	35150-Z37-A32	SWITCH ASSY., START			001	0	0
22	35335-YR1-J01	CAP, SELECT SWITCH			001	0	0
23	36214-Z11-A01	SWITCH COMP., AUTO-THROTTLE (OTAX)			001	0	0
24	38206-797-A01	FUSE, BLADE (3A)			001	0	0
25	38240-Z25-A63	PROTECTOR, CIRCUIT (16A) (WHITE) (TYCO)			003	0	0
25	38240-Z25-F60	PROTECTOR, CIRCUIT (16A) (BLACK) (JOEMEX)			003	0	0
26	38242-Z25-A62	COVER COMP., CIRCUIT PROTECTOR			003	0	0
27	38398-Z07-C60	SUPPORTER, FILTER			003	0	0
28	38398-Z37-000	FILTER, SUB NOISE (AC)			003	0	0


29	90031-875-000	SCREW, TAPPING, 5X12	001	0	0
30	90083-ZY3-A01	CAP, BOLT, 6MM	001	0	0
31	90672-SB2-003	STRAP, CABLE, 105MM (BLACK)	009	0	0
32	91504-SD5-003	CLIP, WASHER MOUTH	006	0	0
33	91654-Z11-000	GROMMET, CONTROL HARNESS	001	0	0
34	93500-05008-3J	SCREW, PAN, 5X8	001	0	0
35	93500-05012-0G	SCREW, PAN, 5X12	002	0	0
36	93600-04016-1G	SCREW, FLAT, 4X16	008	0	0
37	93893-05020-17	SCREW-WASHER, 5X20	004	0	0
38	94050-04000	NUT, FLANGE, 4MM	001	0	0
39	94050-06080	NUT, FLANGE, 6MM	003	0	0
40	98200-31500	FUSE, BLADE (15A)	001	0	0
41	32130-Z37-000	COUPLER ASSY., SHORT	001	0	0
42	32174-VP7-000	COUPLER, DUMMY (4P)	001	0	0

EU70ISN
E-21 STARTER MOTOR



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	30201-PH9-004	RING, SNAP (DENSO)			001	0	0
2	30202-PZ1-003	COLLAR SET, CLUTCH STOP			001	0	0
3	31200-Z1C-C01	MOTOR ASSY., STARTER (DENSO)			001	0	0
4	31203-Z1C-C01	LEVER, PINION DRIVE			001	0	0
5	31204-Z2E-003	SWITCH ASSY., MAGNET			001	0	0
6	31207-ZF6-F41	CLUTCH COMP., OVERRUNNING			001	0	0
7	31208-ZF6-F41	HOUSING COMP., DRIVE SIDE			001	0	0
8	31209-PH9-004	BEARING A			001	0	0
9	31210-PH9-004	BEARING B			001	0	0
10	31211-PH9-004	BRUSH			004	0	0
11	31212-PH9-004	SPRING, BRUSH			004	0	0
12	31214-PH9-004	BOLT, THROUGH			002	0	0
13	31217-Z1C-C01	ARMATURE COMP.			001	0	0
14	31218-PH9-004	YOKE COMP.			001	0	0
15	31219-ZF6-F41	FRAME COMP., COMMUTATOR END			001	0	0
16	31220-PH9-004	NUT, HEX., 8MM			001	0	0
17	31223-RYE-A01	NUT			002	0	0
18	31231-PH9-004	HOLDER, BRUSH			001	0	0
19	31233-PH9-004	INSULATOR, BRUSH HOLDER			001	0	0
20	95701-10035-00	BOLT, FLANGE, 10X35			002	0	0


EU70ISN
F-14 AIR CLEANER



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	17203-ZY1-000	TRAP, FLAME			001	0	0
2	17211-Z3S-003	ELEMENT, AIR CLEANER			001	0	0
3	17212-Z0A-010	GRID, AIR CLEANER			001	0	0
4	17218-Z0A-810	FILTER, OUTER			001	0	0
5	17220-Z37-000	CASE COMP., AIR CLEANER			001	0	0
6	17229-Z25-000	SEAL, AIR CLEANER CHAMBER			001	0	0
7	17231-Z37-000	COVER, AIR CLEANER			001	0	0
8	17232-Z25-000	RUBBER, AIR CLEANER			001	0	0
9	17233-Z37-000	BRACKET, AIR CLEANER			001	0	0
10	17252-Z37-000	SEAL, AIR CLEANER			002	0	0
11	17270-Z25-000	CASE COMP., AIR CLEANER CHAMBER			001	0	0
12	17273-Z25-010	COVER, AIR CLEANER CHAMBER			001	0	0
13	17274-Z25-000	TUBE, AIR CLEANER CONNECTING			001	0	0
14	63232-Z37-000	LEVER, FASTENER			002	0	0
15	63237-Z37-000	SPRING, FASTENER WIRE			002	0	0
16	90014-952-000	BOLT, FLANGE, 6X14 (CT200)			003	0	0
17	90659-Z35-000	CLAMP, CASE			004	0	0
18	90754-ZY9-000	PIN, 5X44.5			002	0	0
19	90852-Z23-F10	CAP, SEALING			001	0	0
20	94050-06080	NUT, FLANGE, 6MM			003	0	0
21	94540-04029	E-RING, 4MM			002	0	0
22	95018-54250	BAND, AIR CLEANER CONNECTING TUBE (54)			002	0	0
23	95701-06022-08	BOLT, FLANGE, 6X22			003	0	0

EU70ISN

F-9 RECOIL STARTER



Refnr	Part Number	Description	from	to	Unit Qty.	Order Qty.	Repair Qty.
1	28400-Z37-003	STARTER ASSY., RECOIL			001	0	0
2	28410-Z11-003	CASE COMP, RECOIL STARTER			001	0	0
3	28421-ZE3-W01	PULLEY, RECOIL STARTER			001	0	0
4	28422-ZE2-W01	RATCHET, STARTER			002	0	0
5	28441-ZE2-W01	SPRING, FRICTION			001	0	0
6	28442-ZE2-W01	SPRING, STARTER RETURN			001	0	0
7	28443-ZE2-W01	SPRING, RATCHET			002	0	0
8	28444-ZE2-W01	RETAINER, SPRING			001	0	0
9	28451-Z25-R50	PULLEY, STARTER			001	0	0
10	28461-Z37-000	GRIP, STARTER			001	0	0
11	28462-ZK3-003	ROPE, RECOIL STARTER			001	0	0
12	90004-ZE2-W01	SCREW, CENTER			001	0	0
13	90409-952-000	WASHER, 10MM			001	0	0
14	94050-06080	NUT, FLANGE, 6MM			003	0	0
15	95701-10025-08	BOLT, FLANGE, 10X25			001	0	0