
EU10IT1


E-5 OIL CASE



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	11300-ZM7-415	CASE ASSY., OIL			001	0	0
2	15600-ZDF-000	CAP ASSY., OIL FILLER			001	0	0
3	15625-Z0T-800	PACKING, OIL FILLER CAP			001	0	0
4	35480-ZM7-D02	SWITCH ASSY., OIL LEVEL			001	0	0
5	90006-ZM7-000	BOLT, FLANGE, 5X23			008	0	0
6	90012-896-750	BOLT, FLANGE, 5X14			003	0	0
7	91202-HC5-003	OIL SEAL, 17X27X5 (ARAI)			001	0	0
8	91301-ZM7-003	O-RING, 34.6X2.5			001	0	0

EU10IT1


E-3 CYLINDER BARREL



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	12100-ZM7-425	BARREL COMP., CYLINDER			001	0	0
2	12311-ZM7-010	COVER, HEAD			001	0	0
3	12367-ZM7-000	FILTER, BREATHER			001	0	0
4	15571-ZM7-003	VALVE, OIL OUTLET			001	0	0
5	15572-ZM7-000	PLATE, STOPPER			001	0	0
6	31914-Z8Y-003	PLUG, SPARK (LR4C-E) (NGK)			001	0	0
7	90003-892-000	BOLT, FLANGE, 5X12			004	0	0
8	91101-Z0G-003	ROLLER, 6X14.8			002	0	0
9	93500-03005-0A	SCREW, PAN, 3X5			001	0	0

EU10IT1


E-6 CRANKCASE COVER



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	11340-ZM7-D02	COVER COMP., CRANKCASE SIDE			001	0	0
2	16512-ZM7-D00	HOLDER, GOVERNOR WEIGHT			001	0	0
3	90006-ZM7-000	BOLT, FLANGE, 5X23			006	0	0
4	90441-ZM7-000	WASHER, 4.2X13			001	0	0
5	90602-ZM7-000	CLIP, GOVERNOR HOLDER			001	0	0
6	94301-06100	DOWEL PIN, 6X10			002	0	0

EU10IT1


E-9 CAMSHAFT



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
no items found							

EU10IT1

F-13 CARBURETOR




Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	16010-ZM7-D01	GASKET SET			001	0	0
2	16011-ZE0-005	VALVE SET, FLOAT			001	0	0
3	16013-ZG0-811	FLOAT SET			001	0	0
4	16015-ZM7-003	CHAMBER SET, FLOAT			001	0	0
5	16016-ZH7-W01	SCREW SET, PILOT			001	0	0
6	16024-ZB9-005	SCREW SET, DRAIN			001	0	0
7	16028-ZG0-811	SCREW SET			001	0	0
8	16044-ZM7-D01	CHOKE SET			001	0	0
9	16100-ZM7-D28	CARBURETOR ASSY. (BF30C G/H)			001	0	0
10	16112-ZM7-D01	JOINT, AIR VENT TUBE			001	0	0
11	16124-ZE0-005	SCREW, THROTTLE STOP			001	0	0
12	16166-ZM7-D02	NOZZLE, MAIN			001	0	0
13	16211-ZM7-D10	INSULATOR, CARBURETOR			001	0	0
14	16212-ZM7-D00	PACKING, INSULATOR			001	0	0
15	16221-ZG0-801	PACKING, CARBURETOR			001	0	0
16	17274-ZT3-000	PACKING, AIR INTAKE JOINT			001	0	0
17	32765-PE0-000	CLAMP D, HIGH TENSION CORD			001	0	0
18	36160-ZM7-D01	MOTOR ASSY., THROTTLE CONTROL			001	0	0
19	36161-ZM7-D21	LEVER, LINK			001	0	0
20	36162-ZM7-D21	SPRING, COMPRESSION COIL			001	0	0
21	36165-ZL0-D31	MOTOR COMP., THROTTLE CONTROL			001	0	0
22	36168-Z39-C90	COVER, THROTTLE MOTOR	1041521		001	0	0
22	36168-ZT3-C01	COVER, THROTTLE MOTOR		1041520	001	0	0
23	90003-ZL0-D30	SCREW-WASHER, 3X8			002	0	0
24	93893-04010-18	SCREW-WASHER, 4X10			002	0	0
25	95003-05019-31	TUBE, VINYL, 3.5X6.5X190 (95003-05001-60M)			001	0	0
26	95003-07005-31	TUBE, VINYL, 4X7X50 (95003-07001-60M)			001	0	0
27	95003-07016-31	TUBE, VINYL, 4X7X160 (95003-07001-60M)			001	0	0
28	95003-07035-31	TUBE, VINYL, 4X7X350 (95003-07001-60M)			001	0	0

29	99101-ZG0-0520	JET, MAIN, #52	(1)	0	0
29	99101-ZG0-0550	JET, MAIN, #55	(1)	0	0
29	99101-ZG0-0580	JET, MAIN, #58	001	0	0
30	99204-ZE203-50	JET SET, PILOT, #35	001	0	0

EU10IT1


F-3-1 CONTROL PANEL (2)



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	30400-ZT3-C02	SPARK UNIT			001	0	0
2	31310-ZT3-E62	INVERTER UNIT		1100942	001	0	0
2	31310-ZT3-E63	INVERTER UNIT	1100943		001	0	0
3	31319-ZT3-000	RUBBER A, INVERTER			002	0	0
4	31324-ZT3-000	RUBBER B, INVERTER			001	0	0
5	31460-ZT3-C01	RECEPTACLE COMP., D.C.			001	0	0
6	31710-ZS9-A02	RECTIFIER ASSY.			001	0	0
7	32105-ZT3-E61	HARNESS ASSY., SUB WIRE			001	0	0
8	32118-ZT3-P10	SHEET, WATER PROOF			001	0	0
9	32138-Z07-E60	COVER, SOCKET			002	0	0
10	32139-ZC3-G01	SOCKET, COMPOSITE			002	0	0
11	32150-ZT3-E60	HARNESS ASSY., CONTROL WIRE	1055159		001	0	0
11	32150-ZT3-E61	HARNESS ASSY., CONTROL WIRE		1055158	001	0	0
12	32331-Z07-C90	RECEPTACLE (13A/250V)			001	0	0
13	32335-875-610	PACKING, RECEPTACLE			001	0	0
15	32345-ZT3-E61	PANEL COMP., CONTROL			001	0	0
17	32351-ZT3-000	COVER, CONTROL PANEL			001	0	0
18	32601-ZT3-S21	CABLE, EARTH			001	0	0
19	36214-Z11-A01	SWITCH COMP., AUTO-THROTTLE (OTAX)	1037306		001	0	0
19	36214-ZS9-A01	SWITCH COMP., AUTO-THROTTLE		1037305	001	0	0
21	93500-05016-3J	SCREW, PAN, 5X16			001	0	0
22	93600-04012-0G	SCREW, FLAT, 4X12			004	0	0
23	93891-05020-07	SCREW-WASHER, 5X20			002	0	0
24	94050-04000	NUT, FLANGE, 4MM			004	0	0
25	94101-05000	WASHER, PLAIN, 5MM			001	0	0
26	94111-05000	WASHER, SPRING, 5MM			001	0	0
27	95701-06010-08	BOLT, FLANGE, 6X10			001	0	0
28	95701-06012-08	BOLT, FLANGE, 6X12			001	0	0
29	91560-SE0-003	BAND A, HARNESS (NATURAL)			001	0	0

EU10IT1

F-15 MUFFLER




Z403F1500

Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	18310-ZT3-S11	MUFFLER COMP.			001	0	0
2	18331-ZT3-000	PIPE, EX.			001	0	0
3	18333-ZT3-010	GASKET, EX. PIPE			001	0	0
5	18382-ZC0-000	GASKET, MUFFLER			001	0	0
6	90004-ZC3-000	BOLT, FLANGE, 5X20			002	0	0
7	95701-06040-00	BOLT, FLANGE, 6X40			002	0	0
8	95701-06045-08	BOLT, FLANGE, 6X45			001	0	0

EU10IT1

F-9 RECOIL STARTER






Z403F0800

Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	28400-ZT3-P11	STARTER ASSY., RECOIL			001	0	0
2	28461-Z32-003	GRIP, STARTER			001	0	0
3	28462-ZT3-P11	ROPE, RECOIL STARTER			001	0	0
4	28464-Z32-003	COVER, GRIP			001	0	0
5	28475-ZT3-000	GUIDE, STARTER ROPE			001	0	0
6	90196-MN5-000	BOLT, FLANGE, 5X10			003	0	0
7	93891-05010-07	SCREW-WASHER, 5X10			001	0	0

EU10IT1


F-21-10 COOLING FAN



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	19511-ZT3-000	FAN, COOLING			001	0	0
2	19514-ZT3-000	BOSS, COOLING FAN			001	0	0
3	28451-ZM7-003	PULLEY, RECOIL STARTER			001	0	0
4	90029-888-000	BOLT, FLANGE, 6X16 (CT200)			001	0	0
5	94103-06800	WASHER, PLAIN, 6MM			001	0	0
6	95701-06016-08	BOLT, FLANGE, 6X16			002	0	0

EU10IT1


F-21 AIR CLEANER/SHROUD



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	15721-ZT3-000	TUBE, BREATHER			001	0	0
2	17211-ZT3-000	ELEMENT, AIR CLEANER			001	0	0
3	17230-ZT3-000	COVER COMP., AIR CLEANER			001	0	0
4	17231-ZT3-000	COVER, AIR CLEANER			001	0	0
5	17232-ZT3-000	RUBBER, AIR CLEANER			001	0	0
6	17233-ZT3-000	SEAL A, AIR CLEANER COVER			001	0	0
7	17234-ZT3-000	SEAL B, AIR CLEANER COVER			001	0	0
8	17251-ZT3-000	TUBE, AIR CLEANER CONNECTING			001	0	0
9	17270-ZT3-030	JOINT COMP., AIR INTAKE			001	0	0
10	19610-ZT3-000	COVER COMP., FAN			001	0	0
11	19630-ZT3-010	SHROUD ASSY., R.			001	0	0
12	19632-ZT3-010	SHROUD, R.			001	0	0
13	19640-ZT3-010	SHROUD ASSY., L.			001	0	0
14	19641-ZT3-010	SHROUD, L.			001	0	0
15	19643-ZT3-000	SEAL A, SHROUD			001	0	0
16	19644-ZT3-000	SEAL B, SHROUD			001	0	0
17	63713-ZT3-000	RUBBER, OIL CHECK			001	0	0
18	68337-ZT3-000	COLLAR D, INSULATOR			001	0	0
19	68338-ZT3-000	INSULATOR, SHROUD			002	0	0
20	68339-ZT3-000	COLLAR B, INSULATOR			001	0	0
21	90019-883-000	BOLT, FLANGE, 5X10 (CT200)			004	0	0
22	90101-ZT3-000	BOLT, STUD (A)			002	0	0
23	90102-ZT3-010	BOLT, STUD, 5X93			002	0	0
24	90103-ZT3-000	BOLT, STUD (B)			001	0	0
25	90129-463-770	COLLAR, REFLECTOR SETTING			003	0	0
26	90551-033-000	WASHER, SPROCKET SETTING			002	0	0
27	90851-ZC3-000	CLIP (28MM)			002	0	0
28	91551-ZT3-000	COLLAR, AIR CLEANER CASE			002	0	0
29	91554-ZT3-000	COLLAR, DISTANCE			001	0	0

EU10IT1

F-25 ENGINE BED




Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	51110-ZT3-010	BED COMP., ENGINE			001	0	0
2	68314-ZT3-000	INSULATOR, ENGINE BED			004	0	0
3	68333-ZT3-000	COLLAR A, INSULATOR			002	0	0
4	68336-ZT3-000	COLLAR C, INSULATOR			002	0	0
5	90029-888-000	BOLT, FLANGE, 6X16 (CT200)			003	0	0
6	90551-033-000	WASHER, SPROCKET SETTING			004	0	0
7	90672-SA0-003	STRAP, CABLE, 118MM (BLACK)			001	0	0

30	93500-04006-0H	SCREW, PAN, 4X6	002	0	0
31	94050-05080	NUT, FLANGE, 5MM	005	0	0
32	94101-05000	WASHER, PLAIN, 5MM	001	0	0

EU10IT1


F-23 FRONT COVER/SIDE COVER



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	16598-ZG1-750	COLLAR, CONTROL COVER			004	0	0
2	18320-ZT3-C60	PROTECTOR COMP., MUFFLER			001	0	0
3	18327-ZT3-300	SEAL RUBBER, PROTECTOR			002	0	0
4	63150-ZT3-C01	COVER ASSY., MAINTENANCE			001	0	0
6	63153-ZT3-000	SEAL A, MAINTENANCE COVER			001	0	0
7	63154-ZT3-000	SEAL B, MAINTENANCE COVER			001	0	0
8	63210-ZT3-C02	COVER COMP., R. SIDE			001	0	0
9	63218-ZT3-000	SEAL A, SIDE COVER			001	0	0
10	63219-ZT3-000	SEAL B, SIDE COVER			001	0	0
11	63220-ZT3-C02	COVER COMP., L. SIDE			001	0	0
12	63340-ZT3-C01	COVER ASSY., PLUG CHECK			001	0	0
13	63344-ZT3-000	SEAL, PLUG CHECK			002	0	0
15	63510-ZT3-E61	COVER ASSY., FR.			001	0	0
17	63512-ZT3-000	SEAL, FR. COVER			001	0	0
18	68325-ZT3-000	RUBBER, BOTTOM			004	0	0
19	90102-Z07-003	SCREW, SPECIAL, 6X16			001	0	0
20	90114-Z39-C30	SCREW, FR. COVER			004	0	0
21	90320-GE2-760	NUT, SPRING, 5MM			004	0	0
22	90485-286-000	WASHER, 6MM			002	0	0
23	93500-06100-0A	SCREW, PAN, 6X100			002	0	0
24	93891-05016-07	SCREW-WASHER, 5X16			004	0	0
25	93891-06020-07	SCREW-WASHER, 6X20			002	0	0
26	94514-10150	CIRCLIP, EXTERNAL, 10MM			001	0	0
27	96001-06010-07	BOLT, FLANGE, 6X10			004	0	0

EU10IT1


F-29 IGNITION COIL/GENERATOR



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	13331-ZM7-000	KEY, SPECIAL			001	0	0
2	30315-ZT3-003	COIL COMP., PULSER			001	0	0
3	30500-Z40-C91	COIL ASSY., IGNITION	1041521		001	0	0
3	30500-ZT3-023	COIL ASSY., IGNITION		1041520	001	0	0
4	30564-895-000	CLAMP A, CABLE			001	0	0
5	30700-Z39-C91	CAP ASSY., NOISE SUPPRESSOR	1041521		001	0	0
5	30700-ZT3-C02	CAP ASSY., NOISE SUPPRESSOR		1041520	001	0	0
6	31120-ZT3-E61	STATOR ASSY.			001	0	0
7	31130-ZT3-C01	ROTOR COMP.			001	0	0
8	32103-759-000	BRACKET, WIRE HARNESS CLIP			001	0	0
9	32157-ZT3-000	CORD, IGNITION EARTH			001	0	0
10	32158-ZT3-E61	HARNESS ASSY., GENERATOR WIRE			001	0	0
11	32196-Z40-C90	SUB CORD ASSY.	1041137		001	0	0
11	32196-ZT3-P10	SUB CORD ASSY.		1041136	001	0	0
12	35120-ZT3-023	SWITCH ASSY., ENGINE STOP			001	0	0
13	35123-ZT3-000	KNOB, ENGINE SWITCH			001	0	0
14	35127-ZT3-000	PLATE, ENGINE SWITCH			001	0	0
15	36135-ZA8-801	BAND, HARNESS			001	0	0
16	90002-MC7-000	BOLT, FLANGE, 5X8			001	0	0
17	90003-892-000	BOLT, FLANGE, 5X12			001	0	0
18	90014-KCZ-000	BOLT, FLANGE, 5X25 (CT200)			002	0	0
19	90105-ZT3-000	SCREW, PAN, 4X19			001	0	0
20	90652-KT1-771	BAND, WIRE (BLACK)			001	0	0
21	90683-SA0-003	CLIP, WIRE HARNESS, 25MM			001	0	0
22	91651-ZT3-C00	GROMMET, GENERATOR CORD			001	0	0
23	93500-05008-3J	SCREW, PAN, 5X8			001	0	0
24	93901-12220	SCREW, TAPPING, 3X10			001	0	0
25	93901-12420	SCREW, TAPPING, 3X16			001	0	0
26	93903-25220	SCREW, TAPPING, 5X12			001	0	0

EU10IT1


F-31 LABEL



Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
1	87101-ZT3-C32	EMBLEM			002	0	0
7	87501-ZT3-C61	MARK, ENGINE SWITCH			001	0	0
9	87525-ZT3-C60	MARK, D.C. CAUTION			001	0	0
10	87528-ZT3-C01	MARK, CHOKE			001	0	0
11	87531-ZT3-000	MARK, HONDA			001	0	0
13	87539-ZT3-C60	MARK, EX. CAUTION			001	0	0
14	87564-ZT3-E60	MARK, A.C. CAUTION			001	0	0
18	87578-ZT3-C60	LABEL, NOISE LEVEL (87)		1040119	001	0	0
19	87580-ZT3-C61	MARK, CIRCUIT PROTECTOR			001	0	0
21	87594-ZT3-010	MARK, OIL CAUTION			001	0	0
23	87709-Z07-S50	MARK, RECYCLE			001	0	0
24	87150-Z39-C61	MARK, CAUTION (EC)	1040120		001	0	0

EU10IT1

F-32 TOOL/OTHER PARTS



Z403F3200

Refnr	Part Number	Description	from	to	Unit Qty	Order Qty	Repair Qty
4	32650-892-013	CORD ASSY., CHARGE (2M)			(1)	0	0
5	32651-892-003	PLUG ASSY., RECEPTACLE			(1)	0	0
7	89216-130-690	WRENCH, SPARK PLUG			001	0	0
8	89219-805-000	HANDLE, BOX WRENCH			001	0	0

27	93903-26320	SCREW, TAPPING, 6X20	002	0	0
28	93913-25520	SCREW, TAPPING, 5X20 (PO)	002	0	0
29	94050-10080	NUT, FLANGE, 10MM	001	0	0
30	94103-05800	WASHER, PLAIN, 5MM	002	0	0