

iSC GmbH  
Customer Service  
Eschenstraße 6  
94405 Landau/Isar


Telephone:  
Email:

+49 9951 959 2019  
service-de@einhell.com



Cordless Sliding Mitre Saw  
TE-SM 36/210 Li - Solo

Article number: 4300880  
Ident number: 21032



## Spare parts

Pos	Art.	Ident number	Product Name	Pos	Art.	Ident number	Product Name
001	430088001001	00000	Screw ST4.2x13	081	430088001081	00000	Spring washer
002	430088001002	00000	Motor cover	089	430088001089	00000	Shoulder Screw M6x14
003	430088001003	00000	Brush pair	091	430088001091	00000	Moving guard spring
004	430088001004	00000	Screw ST4x10	092	430088001092	00000	Pivot shaft
005	430088001005	00000	Brush hold	093	430088001093	00000	Big torsion spring
006	430088001006	00000	Brush spring	094	430088001094	00000	Spring sleeve
007	430088001007	00000	Inductance	095	430088001095	00000	Socket head screw M5x16
008	430088001008	00000	Inductance	096	430088001096	00000	Nut M5
009	430088001009	00000	Motor housing	097	430088001097	00000	Hex grub screw M6x12
011	430088001011	00000	Spring washer	098	430088003098	00000	Pivot block (Black)
013	430088001013	00000	Stator	099	430088001099	00000	Led
014	430088001014	00000	Screw St4.2x65	101	430088001101	00000	Led support
015	430088001015	00000	Rubber boot	103	430088001103	00000	Led and laser cover
016	430088001016	00000	Bearing 607-2RS	105	430088001105	00000	Laser
017	430088001017	00000	Rotor	106	430088001106	00000	Screw ST4.2x9.5
018	430088001018	00000	Fan baffle	108	430088001108	00000	Laser support
019	430088001019	00000	Bearing 6000-2RS	110	430088001110	00000	Spring washer
020	430088001020	00000	O Ring	111	430088001111	00000	Screw M6x20
021	430088001021	00000	Inner conductor	112	430088001112	00000	Screw
022	430088001022	00000	Inner conductor	113	430088001113	00000	C clip
023	430088001023	00000	Inductance	114	430088001114	00000	Lock pin
030	430088001030	00000	Nut M6	116	430088001116	00000	Rubber pole
031	430088001031	00000	Socket head screw M6x25	120	430088001120	00000	Front bearing cover
032	430088001032	00000	Knurled thin nut M6	121	430088001121	00000	Linear bearing
033	430088003033	00000	Depth of cut adjust knob	122	430088001122	00000	Linear bearing
034	430088001034	00000	Carry handle cover	123	430088001123	00000	Nut M8
035	430088001035	00000	Carry handle	124	430088001124	00000	Hex grub screw M8x35
037	430088001037	00000	Lower handle	125	430088001125	00000	Spring loop
038	430088001038	00000	Trigger	126	430088003126	00000	Knob
039	430088001039	00000	Control panel	127	430088001127	00000	Slide housing
040	430088001040	00000	Upper handle	128	430088001128	00000	Back bearing cover
041	430088001041	00000	Screw ST4.2x16	129	430088001129	00000	Slide
042	430088001042	00000	Laser switch	130	430088003130	00000	Slide end cap (Black)
043	430088001043	00000	Electrode plate	131	430088001131	00000	Rubber ring
044	430088001044	00000	Switch	132	430088001132	00000	Allen key
045	430088001045	00000	Screw M5X45	135	430088001135	00000	Socket head screw M6x20
046	430088001046	00000	Spring	137	430088001137	00000	Slide housing cover
047	430088001047	00000	Screw M5X15	138	430088001138	00000	Screw M10x25
048	430088001048	00000	Screw M6X18	139	430088003139	00000	Bevel lock handle
050	430088001050	00000	button	140	430088001140	00000	Locknut
051	430088001051	00000	spanner	141	430088001141	00000	Washer
053	430088001053	00000	circlip	142	430088001142	00000	Bolt M10x80
054	430088001054	00000	Gear	143	430088001143	00000	Hex grub screw M8x35
055	430088001055	00000	Gear washer	145	430088001145	00000	Bever pointer
056	430088001056	00000	Output shaft	147	430088001147	00000	Limit pin
057	430088001057	00000	Key	149	430088001149	00000	Bevel pivot
058	430088001058	00000	Bearing 6001	151	430088001151	00000	Socket head screw M6x20
059	430088001059	00000	C clip	153	430088001153	00000	Locknut
060	430088001060	00000	Gear case cover	154	430088001154	00000	Locknut
061	430088001061	00000	C clip	155	430088001155	00000	Washer
062	430088001062	00000	Sunk screw M5x16	156	430088001156	00000	Screw M4x10
063	430088001063	00000	Blade flange inner	157	430088001157	00000	Mitre pointer
064	430088001064	00000	Blade	159	430088001159	00000	Sunk screw M4x12
065	430088001065	00000	Blade flange outer	160	430088001160	00000	Cutting insert
066	430088001066	00000	Washer f8xf22x3	161	430088001161	00000	Push button
067	430088001067	00000	Blade bolt M8x16	162	430088001162	00000	Push button spring
068	430088001068	00000	Sunk screw M4x12	163	430088001163	00000	Square nut
069	430088001069	00000	Anti-finger touch plate	164	430088001164	00000	Screw M4x32
070	430088001070	00000	Washer 6	165	430088001165	00000	Safety foot
073	430088001073	00000	Laser wire cover	167	430088001167	00000	Knob M6x20
074	430088001074	00000	Sunk screw M4x12	169	430088001169	00000	E clip
075	430088001075	00000	Retaining ring f5	170	430088001170	00000	Washer f5
076	430088001076	00000	Guard roller	171	430088001171	00000	Locknut
078	430088001078	00000	Moving guard	172	430088003172	00000	Left slide table trigger (Blac

Pos	Art.	Ident number	Product Name
173	430088001173	00000	Left work stop
174	430088001174	00000	Screw M5x14
175	430088001175	00000	Spring
177	430088001177	00000	Hex grub screw M6x16
179	430088001179	00000	Sunk screw M4x12
180	430088001180	00000	Screw M5x12
181	430088001181	00000	Support bar
182	430088001182	00000	Screw M4x10
183	430088001183	00000	Lock bolt
184	430088001184	00000	Detent pole
185	430088001185	00000	Washer
186	430088001186	00000	Detent pole spring
187	430088003187	00000	Lock handle
188	430088001188	00000	Screw M4x16
189	430088003189	00000	Lock handle cover
190	430088001190	00000	Left rubber foot
193	430088001193	00000	Clamping plate
195	430088001195	00000	Right rubber foot
196	430088001196	00000	Bolt M8x30
197	430088003197	00000	Right slide table (Black)
199	430088001199	00000	Right work stop
200	430088001200	00000	Fence
201	430088001201	00000	Socket head screw M6x16
202	430088001202	00000	Left attach fence
203	430088001203	00000	Screw M4x10
204	430088001204	00000	Clamp
205	430088001205	00000	Support arm
206	430088003206	00000	Workpiece knob
207	430088003207	00000	Knob
208	430088001208	00000	Support pole
209	430088001209	00000	Right attach fence
210	430088003210	00000	Long knob
211	430088003211	00000	Knob
213	430088001213	00000	Washer
214	430088001214	00000	Insert
215	430088001215	00000	LED switch
800	430088003800	00000	sawdust bag
899	430088003899	00000	color box
901	430088002901	00010	fixed guard assembly
902	430088001902	00010	Left slide table trigger assem
903	430088001903	00010	Right slide table trigger asse
904	430088003904	00010	Turntable assembly (Black)
905	430088001905	00010	Base assembly
906	430088001906	00010	Sems screw M4x20
907	430088001907	00010	Sems screw M5x16
908	430088001908	00010	Connecting rod assembly
909	430088001909	00010	Sems screw M4x10
910	430088001910	00010	Sems screw M4x16
911	430088001911	00010	Sems screw M4x12
912	430088001912	00010	Sems screw M4x16
913	430088001913	00010	Sems screw M4x10
914	430088001914	00010	Sems screw M4x14
915	430088001915	00010	Sems screw M4x10
916	430088001916	00010	Sems screw M4x10
917	430088001917	00010	Sems screw M4x14
918	430088001918	00010	Sems screw M4x10

fixed guard assembly

Article number: 430088002901  
Ident number: 00010

### Spare parts

Pos	Art.	Ident number	Product Name
049	430088002049	00000	Fixed guard
052	430088001052	00000	Bearing

Left slide table trigger assem

Article number: 430088001902  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
168	430088001168	00000	Flat support bar
176	430088001176	00000	Left slide table trigger
178	430088001178	00000	Rolled pin

Right slide table trigger asse

Article number: 430088001903  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
168	430088001168	00000	Flat support bar
178	430088001178	00000	Rolled pin
198	430088001198	00000	Right slide table trigger

Turntable assembly (Black)

Article number: 430088003904  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
150	430088001150	00000	Bevel scale
152	430088003152	00000	Turntable

Base assembly

Article number: 430088001905  
Ident number: 00010

### Spare parts

Pos	Art.	Ident number	Product Name
191	430088001191	00000	Miter scale
192	430088001192	00000	Base



Sems screw M4x20

Article number: 430088001906  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
010	430088001010	00000	Screw M4x20
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer

Sems screw M5x16

Article number: 430088001907  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
036	430088001036	00000	Screw M5x16

Connecting rod assembly

Article number: 430088001908  
Ident number: 00010

### Spare parts

Pos	Art.	Ident number	Product Name
079	430088001079	00000	Bearing 686-2RS
080	430088001080	00000	Connecting rod

Sems screw M4x10

Article number: 430088001909  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
090	430088001090	00000	Screw M4x10

Sems screw M4x16

Article number: 430088001910  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
102	430088001102	00000	Screw M4x16

Sems screw M4x12

Article number: 430088001911  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
104	430088001104	00000	Screw M4x14

Sems screw M4x16

Article number: 430088001912  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
107	430088001107	00000	Screw M4x16

Sems screw M4x10

Article number: 430088001913  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
119	430088001119	00000	Screw M4x10



Sems screw M4x14

Article number: 430088001914  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
136	430088001136	00000	Screw M4x14

Sems screw M4x10

Article number: 430088001915  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
144	430088001144	00000	Screw M4x10

Sems screw M4x10

Article number: 430088001916  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
158	430088001158	00000	Screw M4x10

Sems screw M4x14

Article number: 430088001917  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
166	430088001166	00000	Screw M4x14

Sems screw M4x10

Article number: 430088001918  
Ident number: 00010

## Spare parts

Pos	Art.	Ident number	Product Name
011	430088001011	00000	Spring washer
012	430088001012	00000	Washer
194	430088001194	00000	Screw M4x10