



HIKOKI

SABER SAW CR13VBY

Item No.	Code No.	Description	No. Used	Remarks
1	326575	BASE ASS'Y (C)	1	INCLUD.2
2	872971	RETAINING RING (E-TYPE) FOR D3 SHAFT	1	
3	327693	TAPPING SCREW D4X8 (BLACK)	1	
4	326595	HOLD SPRING (C)	1	
5	307028	TAPPING SCREW (W/FLANGE) D4X25 (BLACK)	9	
6A	326584	FRONT COVER (D).(E) SET	1	
7	326597	BASE LEVER (C)	1	
8	326596	PUSHING BUTTON (C)	1	
9	326594	PUSHING SPRING	1	
10		NAME PLATE	1	
11	303851	SEAL LOCK SCREW (W/WASHERS) M4X10 (BLACK)	1	
12	326593	CHANGE KNOB (C)	1	
13	872654	O-RING (1AP-10)	2	
14	327325	NUT M8	1	
15	327114	WASHER (G)	1	
16	318493	BOLT M10	2	
17	326574	BASE ADAPTER (C)	1	
18	326779	CUSHION RUBBER (C)	1	
19	326589	BLADE HOLDER (C)	1	
20	327116	GEAR COVER (D)	1	
21	318458	FELT WASHER	1	
22	326576	SEAL SLEEVE (C)	1	
23	318459	V-RING	1	
24A	334994	METAL (C)	1	
25	326578	GUIDE SLEEVE (C) ASS'Y	1	
26	949566	LOCK NUT M5 (10 PCS.)	1	
27	326580	PLUNGER (C)	1	
28	327123	RUBBER SPACER	2	
29	327122	COUNTER WEIGHT (D)	1	
30	327121	WEIGHT SHAFT (D)	2	
31	321130	CAP	1	
32	321134	HOLDER PIN (B)	1	
33	318483	SPRING (B)	1	
34	326590	SPECIAL BOLT M5	1	
35	326588	LEVER (C)	1	
36	326591	BLADE SPRING	1	
37	327124	SWING ROLLER	2	
38	326585	PIN D6	1	
39	6003DD	BALL BEARING 6003DD	1	
40	327118	SUB SHAFT (D)	1	
41	318476	BEARING COVER (B)	1	
42	326573	SEAL LOCK SCREW M4X10	2	
43	967261	RETAINING RING FOR D17 SHAFT	2	
44	326581	RECIPRO PLATE (C)	1	
45	327694	BALL BEARING 6003VVCM (NYLON RETAINER)	4	
46	939556	RETAINING RING FOR D35 HOLE (10 PCS.)	2	
47	327119	SECOND SHAFT (D)	1	
48	327115	RECIPRO PLATE (D)	1	
49	327120	SECOND SHAFT (E)	1	
50	318473	GEAR	1	
51	608VVM	BALL BEARING 608VVC2PS2L	2	
52	327117	INNER COVER (D)	1	
*53	326602	CHANGE SHAFT (C1)	1	

* ALTERNATIVE PARTS

HIKOKI

SABER SAW CR13VBY

Item No.	Code No.	Description	No. Used	Remarks
54	974577	RETAINING RING (E-TYPE) FOR D7 SHAFT	1	
55	314430	SLOTTED HD. SCREW (SEAL LOCK) M4X10	2	
56	6001VV	BALL BEARING 6001VV	1	
*57	360795E	ARMATURE 230V	1	
58	318467	FAN GUIDE	1	
59	953174	HEX. HD. TAPPING SCREW D5X55	2	
*60	340698E	STATOR ASS'Y 230V	1	INCLUD.61
61	930703	BRUSH TERMINAL	2	
62	327126	HOUSING	1	
63	945161	BRUSH CAP	2	
64	999043	CARBON BRUSH (1 PAIR)	2	
65	958900	BRUSH HOLDER	2	
66	307224	MACHINE SCREW (W/WASHERS) M5X60 (BLACK)	4	
*67A	326600	HANDLE (E).(F) SET	1	
68	322133	SWITCH TRIGGER	1	
*69	981373	TUBE (D)	2	EXCEPT FOR SIN,KUW,IND,USA,CAN
*70	930039	NOISE SUPPRESSOR	1	EXCEPT FOR SIN,KUW,IND,USA,CAN
71	981373	TUBE (D)	2	FOR CORD
72	326598	TRIAC HOLDER	1	
73	305490	TAPPING SCREW (W/FLANGE) D4X30 (BLACK)	2	
*74	321960	SWITCH (1P SCREW TYPE)	1	
*75	318505	SWITCH ASS'Y (1P SCREW TYPE)	1	INCLUD.74
76	984750	TAPPING SCREW (W/FLANGE) D4X16	2	
77	937631	CORD CLIP	1	
78		BRAND LABEL	1	
79	953327	CORD ARMOR D8.8	1	
*80	500234Z	CORD	1	(CORD ARMOR D8.8)
*80	500247Z	CORD	1	(CORD ARMOR D8.8) FOR FIN,NOR,SWE,DEN
81	334921	SPECIAL BOLT M5 SET	1	INCLUD.26,34
82		BRAND LABEL	1	
		STANDARD ACCESSORIES		
*501	327129	SABER SAW BLADES NO.341 150L P.14 (3 PCS)	1	
502	327054	CASE	1	
		OPTIONAL ACCESSORIES		
602	958182	SABER SAW BLADES NO.2 (5 PCS.)	1	
603	958183	SABER SAW BLADES NO.3 (5 PCS.)	1	
604	959611	SABER SAW BLADES NO.4 (5 PCS.)	1	
605	958185	SABER SAW BLADES NO.5 (5 PCS.)	1	
606	958188	SABER SAW BLADES NO.8 (5 PCS.)	1	
607	996427	SABER SAW BLADES NO.9 (3 PCS.)	1	
608	318611	SABER SAW BLADES NO.101 150L P.10 (5 PCS)	1	
609	318612	SABER SAW BLADES NO.102 228L P.10 (5 PCS)	1	
610	318613	SABER SAW BLADES NO.103 150L P.14 (5 PCS)	1	
611	318614	SABER SAW BLADES NO.104 228L P.14 (5 PCS)	1	
612	318617	SABER SAW BLADES NO.107 150L P.24 (5 PCS)	1	
613	318618	SABER SAW BLADES NO.108 228L P.24 (5 PCS)	1	
614	324818	SABER SAW BLADES NO.109 150L P.18 (5 PCS)	1	
615	324819	SABER SAW BLADES NO.110 228L P.18 (5 PCS)	1	
616	318619	SABER SAW BLADES NO.121 305L P.6 (5 PCS.)	1	
617	318620	SABER SAW BLADES NO.131 305L P.10/14(5PC)	1	
618	318621	SABER SAW BLADES NO.132 203L (5 PCS.)	1	
619	327691	SABER SAW BLADES NO.342 200L P.14 (3 PCS)	1	
620	327692	SABER SAW BLADES NO.343 250L P.14 (3 PCS)	1	

* ALTERNATIVE PARTS