


EXPLODED VIEW OF RD-JS28



PARTS LIST RD-JS28



Parts No.	Description	Qty
1	laser button	1
2	laser	1
3	screw ST4×45	2
4	screw ST4×16	11
5	right housing	1
6	ST screw	2
7	cable fixer	1
8	cable	1
9	cable sheath	1
10	spanner	1
11	stator	1
12	bearing 607	1
13	carbon brush	2
14	brush holder	2
15	holder cover	2
16	rotor	1
17	bearing 608	1
18	switch	1
19	wool ring	1
20	centre frame	1
21	pendulum bar	1
22	speed controller	1
23	balance bar	1
24	screw ST4×14	2
25	pin	1
26	wheel frame	1
27	reciprocating rod	1
28	locating bar	1
29	spring cover	1
30	sawblade	1
31	spring	1
32	transparent cover	1
33	gear	1
34	needle bearing	1
35	washer	1
36	circlip	1
37	frame fixer	2

Parts No.	Description	Qty
38	upper frame	1
39	guiding wheel	1
40	locating pin	4
41	left housing	1
42	button pin	1
43	steel ball	1
44	spring	1
45	circlip	1
46	pendulum button	1
47	upper fixer	1
48	base	1
49	screw	2
50	spring	2
51	down fixer	1
52	screw	2
53	guiding gauge	1