


## Exploded Drawing of RAIDER Electric Chain Saw RD-ECS21



**Spare part list of RAIDER Electric Chain Saw RD-ECS21**

1	screws	2	56	oil tank	1
2	tension disc	1	57	connecting block	1
3	micro switch	2	58	sponge	1
4	copper pipe	1	59	oil tank connector	1
5	capacitance	1	60	seal ring	1
6	cable sleeve	1	61	oil inlet tube	1
7	cable	1	62	screw	2
8	connecting line	1	63	oil pump	1
9	Trigger	1	64	oil out pipe	1
10	trigger spring	1	65	oilout mouth	1
11	self lock button	1	66	seal ring	2
12	screw	1	67	sponge	2
13	push rod	1	68	gear box cover	1
14	push rod spring	1	69	rubber block	1
15	screw	2	70	right handle	1
16	brake leaf spring	1	71	rubber block	1
17	nut	3	72	sproket	1
18	small gear	1	73	"E" circlip	1
19	gear sleeve	1	74	seal ring	1
20	left handle	1	75	thermal baffle	1
21	bearing	1	76	screws	2
22	armature	1	77	bar	1
23	bearing	2	78	saw chain	1
24	wind block plate	1	79	bar cover	1
25	stator	1	80	adjusting bolt	1
26	screws	2	81	adjust pin	1
27	screws	24	82	seal ring	1
28	brush holder cover	2	83	sproket cover	1
29	carbon brush	2	84	sleeves	2
30	brush holder	2			
31	Handle fixing plate	1			
32	back cover	1			
33	screw	1			
34	screw	1			
35	flat washer	1			
36	Front guard	1			
37	nut	1			
38	Big gear	1			
39	needle bearing	1			
40	washer	2			
41	brake torsion spring	1			
42	output shaft	1			
43	worm gear	1			
44	bearing	1			
45	dust cover	1			
46	screw	6			
47	screw	2			
48	brake fixing plate	1			
49	connecting rod	1			
50	brake rod	1			
51	brake spring	1			
52	washer	1			
53	oil tank cover	1			
54	washer	1			
55	hanger	1			