




Key#	DESCRIPTION	QTY/ UNIT	NOTE
A	Starter Assy		
1	Bolt M5×16	4	
2	Starter Housing	1	
3	Guide LH	1	
4	Recoil Spring	1	
5	Recoil Spring Case	1	
6	Reel	1	
7	Rope	1	
8	Starter Handle	1	
9	Washer	1	
10	Screw ST5×16	1	
11	Fan Cover	1	
B	Muffler Assy		
1	Nut	2	
2	Washer	2	
3	Cover	1	
4	Bolt M5×16	2	
5	Muffler	1	
6	Bolt M5×84	2	
7	Gasket	1	
C	Cylinder Assy		
1	Bolt M5×20	4	
2	Cylinder	1	
3	Gasket	1	
D	Inlet Assy		
1	Gasket	1	
2	Inlet Pipe	1	
3	Bolt M5×14	4	
4	Spacer	1	
5	Inner Guide	1	
6	Bracket	1	
7	Gasket	1	
8	Carburetor	1	
9	Bolt M5×50	2	

Key#	DESCRIPTION	QTY/ UNIT
10	Inlet Elbow	1
11	Supporter	1
12	Bolt M5×16	5
13	Cylinder Cover	1
14	Packing Ring	1
15	Air Filter	1
16	Hood	1
17	Knob	1
E	Guide Bar,Saw Chains	
1	Guide Bar	1
2	Saw Chains	1
3	Protector	1
F	Chain Cover Assy	
1	Pin	1
2	Brake Lever	1
3	Spacer	1
4	Ring	1
5	Spring	1
6	Washer	1
7	Pin	2
8	Brake Lever	1
9	Slide Arm	1
10	Pin	1
11	Plate	1
12	Ring	1
13	Pin	1
14	Front Guard	1
15	Nut	1
16	Bolt	1
17	Cover	1
18	Screw	1
19	Plate	1
20	Screw	1
21	Brake Band	1

22	Guide	1	16	Guide	1
23	Gear	1	17	Valve	1
24	Protector	1	18	Ring	1
25	Chain Cover	1	19	Filter	1
26	Spring	1	20	Bearing	1
27	Spring	1	21	Gasket	1
28	Nut	1	22	Grommet	1
29	Ring	1	23	Stopper	1
G	Clutch Assy		24	Grommet	1
1	Bearing	1	25	Choke Rod	1
2	Rim Sprocket	1	26	Damper	1
3	Clutch Drum	1	27	Cap	1
4	Disc	1	J	Crankshaft Assy	
5	Clutch Driving Disc	1	1	Snap Ring	2
6	Clutch Shoe	3	2	Washer	2
7	Spring	1	3	Piston Pin	1
H	Oil Pump Assy		4	Bearing	1
1	Pipe	1	5	Key	1
2	Oil Pump Assy	1	6	Crankshaft	1
3	Bolt M4×14	2	7	Piston	1
4	Pump Cover	1	8	Piston Ring	2
5	Bolt M4×8	3	K	Crankcase Side Left	
6	Worm Gear	1	1	Bolt M4×8	2
I	Crankcase Side Right		2	Plate	1
1	Oil Filter	1	3	Tank Cap	1
2	Pipe	1	4	Packing Ring	1
3	Pin	3	5	Stopper	1
4	Crankcase	1	6	Bolt M5×25	5
5	Spike Bar	1	7	Crankcase	1
6	Bolt M5×16	3	8	Elbow	1
7	Spacer	1	9	Clip	1
8	Spring	1	10	Pipe	1
9	Screw ST5×16	2	11	Bearing	1
10	Chain Catcher	1	12	Gasket	1
11	Bolt M4×8	1	13	Oil Seal	1
12	Guide Plate	1	14	Cap	2
13	Oil Seal	1	15	Screw ST5×16	2
14	Guide	1	16	Damper	2
15	Bolt	2	17	Snap Ring	1

18	Stopper	1	N	Left Handle Assy	
19	Guide LH	1	1	Left Handle	1
20	Bolt M5×10	1	2	Screw ST5×16	4
21	Switch Cover	1			
22	Plate	1			
23	Switch Assy	1			
L	Ignition Coil Assy				
1	Bolt M5×20	2			
2	Washer	2			
3	Ignition Coil	1			
4	Grommet	1			
5	Spark Plug	1			
6	Cord	1			
7	Nut	1			
8	Washer	1			
9	Rotor	1			
M	Tank Assy				
1	Holder	1			
2	Breather	1			
3	Fuel Filter	1			
4	Pipe	1			
5	Damper	1			
6	Fuel Tank Cap	1			
7	Packing Ring	1			
8	Stopper	1			
9	Knob	1			
10	Spring	1			
11	Pin	1			
12	Screw ST5×16	1			
13	Right Handle Assy	1			
14	Spring	1			
15	Pin	1			
16	Throttle Lever	1			
17	Arm	1			
18	Damper	2			
19	Bolt M5×12	2			
20	Cap	2			
21	Throttle Rod	1			
22	Grip Cover	1			