

TBE350** Spare Part List

1	Water hose plug	EOSM-121 01 034	10981925
2	Outer blade guard	EOSM-131 04 034	10981926
3	Inner blade guard	EOSM-113 02 034	10981927
4	Water flow "T" adapter	EOSM-123 04 005	10981928
5	Water valve	EOSM-130 01 005	10981929
6	Hose clip	EOSM-113 28 005	10981930
7	Water splash guard	EOSM-130 04 034	10981931
8	Motor bracket	EOSM-131 03 034	10981932
9	Switch 230 V	EOSM-132 01 041	10986216
	Switch 110 V	EOSM-132 05 034	10986025
10	Cable sleeve	EOSM-122 08 033	10981934
11	Back splash guard	EOSM-123 06 034	10986217
12	Splash guard holder	EOSM-112 25 034	10986218
13	Angle locking handle	EOSM-130 01 034	10981937
14	Cross beam	EOSM-131 06 034	10981938
15	U style hose clip	EOSM-113 37 033	10981939
16	Load spring	EOSM-112 18 034	10981940
17	Drain plug	EOSM-130 02 034	10981946
18	Guide rail	EOSM-113 03 041	10986219
19	Chain	EOSM-131 19 033	10981943
20	Main frame	EOSM-131 01 041	10986220
21	Height slot	EOSM-113 10 034	10981945
22	Height locking handle	EOSM-130 01 047	10986221
23	Multiple wrench	EOSM-113 28 034	10981947
24	Wrench bracket	EOSM-113 29 034	10981948
25	Bolt	EOSM-121 01 002	10986222
26	Leg with wheel	EOSM-130 06 034	10986223
27	Pump adapter	EOSM-121 11 001	10981951
28	Water pump 230 V	EOSM-132 03 005	10981952
	Water pump 110 V	EOSM-8000060101	10986026
29	Straight leg	EOSM-112 17 034	10981953
30	Roller wheel	EOSM-112 31 033	10981954
31	Sleeve	EOSM-112 13 005	10981956
32	Cutting table	EOSM-131 12 034	10986224
33	Cutting table fence	EOSM-113 20 034	10981958
34	Guide Wheel	EOSM-112 29 033	10981959
35	Cutting table locking assembly	EOSM-130 05 034	10981960
36	Rip guide	EOSM-130 03 005	10986225
37	Motor 230 V	EOSM-132 01 005	10981961
	Motor 110 V	EOSM-1900160101	10986027
38	Inner flange	EOSM-111 06 005	10986226
39	Blade		
40	Outer flange	EOSM-111 02 013	10981963
41	Lock Nut M20 (left)	EOSM-338019	977631
42*	Cable with connector CEE 16 110V	EOSM-7200020101	10986028

TBE350** EXPLODE VIEW

