


ANGLE GRINDER EXPLOSIVE VIEW



RDI-AG57 SPARE PARTS LIST

No.	Description of part	Qty	No.	Description of part	Qty
1	outer flange	1	28	baffle	1
2	inner flange	1	29	ST5*70A screw	1
3	wheel guard	1	30	stator	1
4	spindle		31	608 bearing	1
5	woodruff key	1	32	bearing sleeve	1
6	dustproof cover	1	33	motor housing	1
7	M5*16 screw	1	34	ST4*10F screw	2
8	fore cover	1	35	brush spring	1
9	6202 bearing	1	36	carbon brush	1
10	6202bearing retaining plate	4	37	brush holder	1
11	screw M4*8	1	38	ST4*12F screw	1
12	gear	1	39	Left and right side cover	2
13	external retainning ring	1	40	Left and right side handle	2
14	needle bearing HK091311	3	41	ST4*16F screw	2
15	screw ST5*30A	1	42	switch	2
16	spindle lock button	1	43	ST4*14A screw	4
17	spindle lock spring	1	44	cord clamp	2
18	spindle lock pin	4	45	speed controller	1
19	gearcase	1	46	capacitance	4
20	hex nut M6	1	47	Left and ringht handle card	1
21	pinion	1	48	buckle	1
22	NSK 6200 bearing	1	49	wiring connector	1
23	rubber ring	1	50	power cord	1
24	6200 bearing retaining plate	1	51	cord sleeve	2
25	Φ35 internal retaining ring	1	52	washer	1
26	armture	1	53	150#side handle	1
27	Φ8 washer	1	54	150#two feet spanner	1