


EXPLODED VIEW



SPARE PARTS LIST

No.	Description	qty/pc
1	button	1
2	button spring	1
3	pull rod	1
4	mandril	1
5	mandril spring	1
6	briquetting	1
7	screw	2
8	handle	1
9	screw	4
10	rating label	1
11	top cover	1
12	screw	4
13	lock catch	1
14	spring	1
15	spring base	1
16	screw	2
17	motor cover	1
18	screw	5
19	sealing ring	1
20	sealing ring	1
21	motor	
22	motor shockproof ring	1
23	floating column	1
24	airin cover	1
25	screw	2
26	Power cord press	
27	power line	1
28	tie	1
29	sealing ring	1
30	motor base	1
31	sponge	1
32	sealing ring	1
33	HEPA	1
34	lock catch	1
35	power line	
36	paper bag	1
37	airout spring	1
38	airout valve	1
53	socket board	1
54	switch	1
55	socket	1
56	screw	4
57	screw	1
58	socket board	1
59	power line	1
60	sealing ring	1