


EXPLODED VIEW



SPARE PARTS

No.	Description
1	Switch
2	Handle
3	Top cover
4	Middle cover
5	Motor
6	Base cover
7	HEPA filter
8	Protect cover
9	Safety valve
10	Basket of the valve
11	Water tube(in)
12	Clip
13	Water tank
14	Wheel support
15	Wheel
16	Universal wheel
17	Base
18	PP tank
19	Paper bag
20	Sponge filter
21	Crevice nozzle
22	Water tube
23	Water pump
24	Hose
25	Control switch
26	Sofa spray nozzle
27	Spray brush
28	Plastic tube
29	Airflow controller
30	Wet&dry floor brush
31	Drainage
32	Sofa brush