




## Прахосмукачки

	Модел	Название	За модел	Количество (бр./ комплект)
	451243-1	Тесен накрайник	CL100DZX, DCL140	1
	50080B0N	Черен накрайник	440, 445X, 448, 449	1
	50089B0N	Черен накрайник	440, 445X, 448, 449	1
	60005B5N	Четка за под	449	1
	60006B5N	Четка за килим	449	1
	60277B0N	Накрайник за четка	440, 445X, 448	1
	60278B0N	Четка за течности	440, 445X, 448	1
	60279B0N	Четка за под	440, 445X, 448	1
	P-70471	Четка	446L, 447L	1
	P-72958	Накрайник	447L, 447M, 446L, VC2010L, VC2511, VC3511L	1
	P-72964	Накрайник	446L, 447L	1
	W14295	Универсален накрайник	446L, 447L, 447MX	1
	W29541	Дюза	VC2511, VC3511L	1
	W5067	Гъвкав накрайник	446L, 447L	1
	W6084	Накрайник за почистване на ъгли	446L, 447L, 447MX	1
	W8046	Накрайник	446L, 447L, VC2010L, VC2511, VC3511L	1