


PPR Cross-over



Description

It allows for crossings of individual tracks of a water and heating distribution system. It is most often used for distribution systems in the floor or when avoiding vertical pipes.

Features List

							D, D1	D2	A	B	A2, C	
16	pcs	50	1	0,03	0,24	233016	16		35,00	380,00	100,00	
20	pcs	50	1	0,07	0,32	233020	20		42,00	400,00	110,00	
25	pcs	25	1	0,09	0,64	233025	25		30,00	400,00	100,00	
32	pcs	20	1	0,16	0,80	233032	32		35,00	400,00	90,00	
40	pcs	10	1	0,33	1,60	233040	40		35,00	400,00	90,00	