Spare Parts Exploded View Of Electric Stapler RDP-SST20



Part No	Description	Qty	Part No	Description	Qty	Part No	Description	Qty	Part No	Description	Qty	Part No	Description	Qty	Part No	Description	Qty
59	Spring	2	48	Decorative sleeve	1	37	Screw	2	26	Nut	1	15	Impact spring	1	4	PCB Components	1
58	Locking seat	1	47	Nozzle Plate	1	36	Shim	1	25	Hook Rack	1	14	Spring sleeve	1	3	Battery pack	1
57	Screw	2	46	Stapler Mouth	1	35	Inner Gear Ring	1	24	Screw	1	13	Screw	1	2	Right Housing	1
56	Steel wire	1	45	Spring Washer	2	34	Planet Gear	3	23	Sliding block	1	12	Shift knob seat	1	1	Screw	14
55	Spring	1	44	Screw	2	33	Ratchet helical shaft	1	22	Cylindrical Pin	1	11	Gear shift knob	1			
54	Round pin	1	43	Screw	2	32	Reed	1	21	Striking Pin	1	10	Lamp cover	1			
53	Nail Pusher	1	42	Cover	1	31	Washer	1	20	Dampening Pad	1	9	Left Housing	1			
52	Outer magazine	1	41	Motor	1	30	Oil Bearing	1	19	Plate	1	8	Trigger	1			
51	Inner magazine	1	40	Gear	1	29	Ring	1	18	Chute	1	7	Spring	1			
50	Spring	1	39	Motor fixing plate	1	28	Helical gear	1	17	Screw	1	6	Trigger	1			
49	Bumper	1	38	Spring Washer	2	27	Fixed shaft	1	16	Chute Plate	1	5	Spring	1			