Exploded drawing of Electric Impact Wrench RD-EIW04



Spare Parts List of Electric Impact Wrench RD-EIW04

No.	Description	Spec.	Qty
1	socket		1
2	gear box		1
3	screw	ST5*45	4
4	spring washers	φ5	4
5	circlip	φ5	4
6	steel ball		1
7	ball circlip		1
8	impactor		1
9	steel ball	Sφ5	25
10	anvil assembly		1
11	steel ball	Sφ7.15	2
12	spindle		1
13	spring		1
14	gear		1
15	circlip	φ10*φ16*15	1
16	steel ball		1
17	gear case cover		1
18	pin		1
19	small steel ball		2
20	gear		1
21	circlip	φ8*φ16*1	1
22	screw	ST3.9*14	4
23	rear cowl		1
24	brush cap		2
25	brush holder		2
26	spring		2
27	carbon brush		2
28	inductance		2
29	housing		1

No.	Description	Spec.	Qty
30	stator		1
31	screw	ST5*60	2
32	fan baffle		1
33	leather collar	608	1
34	bearing 608	608-2Z	1
35	rotor		1
36	bearing 6001	6001	1
37	bearing clamp		1
38	handle cover		1
39	switch		1
40	circuit board		1
41	screw	ST3.9*16	2
42	cable plug		1
43	cord sheath		1
44	screw	ST3.9*14	2
45	cord clamp		1
46	screw	ST3.9*8	1