











Art. 39

Art. 40 Curve from 100 square Ø 80



Art. 41 Curve from 100 square Ø 100



Art. 44 Leaf-grate for angle roof drains



**Art. 42** Curve mm. 100x100



**Art. 43** Reducer mm. 100x100 Ø 100



Art. 118G Art. 118M Drain box



**Art. 315** Curve Ø 100




**Art. 320** Curve Ø 110








The **RIGHT ANGLED DRAIN OUTLET 90° with round pipe (Art. 304 - 305 - 307 - 309 - 310 - 311 - 312)** offers as one of its main characteristics that it can be used either as an external or internal drain and especially for horizontal drains through thick outer walls. The unit is used in conjunction with bends or fittings having seal rings and thus the joint can be within the wall and the down pipe can be placed at a minimum distance from the wall. It is particularly suitable for application with all kinds bituminous membranes APP SBS, spread bitumen.




**ANGLED ROOF DRAIN SQUARE in IGOM EE Art. 39 - 39.2**: the main characteristics of the angled roof drain is the possibility to be used for both inside and outside drains, for horizontal drains with free waterfall, terraces, industrial shelds, flat roofs, and roofs covered with bitumen, tarred felt or polymeric bitumen, APP SBS. Installation should be carried out at 3° slope.



## 90° ANGLED ROOF DRAIN ROUNDED PIPE IN IGOM EE

# ITALPROFILI

# laying technology



#### Art. 304 - 305 - 307 - 309 - 310 - 311 - 312

- 1 Apply a coat of primer to the deck for approximately 40 to 50 cm around the hole where the drain unit is to be installe.
- 2 Torch apply a 50x50 cm piece of thin membrane. If the waterproofing is a multi-layer system the drain unit is installed after the first layer and there is no need for the 50x50 cm piece of membrane. Ensure a pitch of 3°.

fitted with seal

- 3 Try the drain in the hole marking the point where it has to be cut with regards to the thickness of the wall. The stem must be cut so that the top edge extends 5 mm less than the bottom edge. When being used with elbows Art. 320 315, whereas, if it is fitted into box culvert Art. 118 it should be cut at 45° (see drawing A).
- 4 Heat he piece of membrane (point 2), or the first layer of waterproofing and adhere the flange.
- 5 Heat a piece of modified bitumen membrane and spread the liquid compound with a trowel over the ribbed flange.
- 6 Install the cap sheet of the waterproofing system taking care especially around the flange area that it is properly heated and adheres correctly over the whole of the surface area.
- 7 Before installing the elbow place some bituminous type mastic. Where diameters permit, use an elbow fitted with a seal.
- 8 Insert leaf guard or gravel grate Art. 26.


#### **DESCRIPTION OF SPECIFICATIONS**


Supply and install ITALPROFILI® round 90° angle drain unit made from flexible synthetic rubber IGOM CE having the following dimensions: tail piece 500 mm long, Ø ......, a flexible flange fitted with an elbow for fitting to the drain unit Ø 80 可知识的问题中间的图点 correct fitting to catchment box with leaf guard or gravel grate.


www.tashev-galving.com











### **INSTALLATION METHOD (same application for Art. 117)**

#### Art. 45

- 1 Apply a coat of primer to the deck around the hole where the unit is to be installed.
- 2 Torch apply a 50x50 cm piece of thin membrane. If the waterproofing is a multi-layer system the drain unit is installed after the first layer and there is no need for the 50x50 cm piece of membrane. Ensure a pitch of 3°.
- 3 Try the drain in the hole marking the point where it has to be cut with regards to the thickness of the wall. The stem must be cut so that the top edge extends 5 mm less than the bottom edge, when being used with elbows Art. 46 and 47. If it is fitted into box culvert Art. 118 it should be cut at 45° (see drawing A).
- 4 Heat he piece of membrane (point 2), or the first layer of waterproofing and adhere the flange.
- 5 Heat a piece of modified bitumen membrane and spread the liquid compound with a trowel over the ribbed flange
- 6 Install the cap sheet of the waterproofing system taking care especially around the flange area that it is properly heated and adheres correctly over the whole of the surface area.
- 7 Before installing the elbow apply some bituminous type mastic, "Boston" or similar. After inserting the elbow into the drain unit, make sure that the four tabs inside the elbow are aligned. The elbow can be installed in the drain pipe (item 3), drawing B.
- 8 Insert leaf guard or gravel grate Art. 44.1.

#### **DESCRIPTION OF SPECIFICATIONS**

Supply and install ITALPROFILI® 90° discharge drain unit made from flexible synthetic rubber IGOM CE having the following dimensions: tail piece 500 mm long 65 mm high, and 100 mm wide, a flexible flange fitted with an elbow for fitting to the drain complete with leaf guard or gravel grate.

WWW.tashev-galving.com